



CDCNET Terminal Interface

Usage



60463850

 CONTROL DATA

CDCNET

Terminal Interface

Usage

This product is intended for use only as described in this document. Control Data cannot be responsible for the proper functioning of undescribed features and parameters.

Manual History

Revision	System Version PSR Level	Date
A	1.0/647	December 1985
B	1.2/678	April 1987
C	1.2.5/688	September 1987
D	1.3/700	April 1988
E	1.4/716	December 1988
F	1.5.1/739	December 1989

This manual is revision F, printed in December 1989, reflecting CDCNET version 1.5.1 at PSR level 739, for operation on NOS version 2.7.1 and NOS/VE version 1.5.1. It includes the following changes and additions:

- New connection attributes: ATTENTION_CHARACTER_ENABLE, ECHO_ENABLE, INPUT_FLOW_CONTROL_ENABLE, OUTPUT_FLOW_CONTROL_ENABLE, PARITY_ENABLE, and TRANSPARENT_PROTOCOL_MODE have been added to chapter 4.
- A new gateway, the X.25 interactive terminal gateway, is documented in chapter 8.
- Resolving Communications Problems, previously chapter 8, is now chapter 9.
- Added new SCL command, DISPLAY_TERMINAL_MODEL to appendix D.
- Updated tables in appendix E.
- Technical corrections have been made throughout the manual. Change bars indicate altered text.

©1985, 1987, 1988, 1989 by Control Data Corporation
All rights reserved.
Printed in the United States of America.

Contents

About This Manual	9	Connection Attributes	4-1
Audience	9	Displaying and Changing	
Prerequisites	9	Connection Attributes	4-1
Terminology	9	Connection Attributes	
Organization	10	and Protocols	4-2
Conventions	11	Connection Attributes	
Related CDCNET		and Input Editing	
Manuals	12	Modes	4-4
Additional Related		Connection Attribute	
Manuals	12	Descriptions	4-5
Ordering Manuals	13		
Submitting Comments	14		
		CDCNET Terminal	
Introduction	1-1	Concepts	5-1
Accessing and Leaving a		Data Modes and Data	
Service	1-1	Types	5-1
Using CDCNET	1-4	Role of Attribute	
Understanding		Settings	5-3
Configuration Options	1-8	Virtual Line Mode: Data	
		Placement	5-5
		Virtual Line Mode:	
		Normal Input	5-8
		Virtual Line Mode:	
		Output	5-16
		Transparent Mode:	
		Transparent Input	5-28
		Transparent Mode:	
		Output	5-30
		Virtual Line and	
		Transparent Modes:	
		Flow Control	5-30
		Terminal User Exception	
		Processing	6-1
		User Interrupts	6-1
		Special Sequences	6-5

Interactive Terminal	
Passthrough	7-1
Becoming a Passthrough	
Server	7-2
Becoming a Passthrough	
Client	7-4
Managing Passthrough	
Connections	7-4
Passthrough Attributes ...	7-9
X.25 Interactive Terminal	
Gateway	8-1
X.25 Interactive	
Terminal Gateway	
Modes	8-1
Gateway Command	
Mode	8-2
Data Transfer Mode	8-3
X.3 Packet	
Assembler/Disassembler	
(PAD) Parameters	8-5
Connecting to the X.25	
Interactive Terminal	
Gateway	8-6
Connecting to the X.25	
Service	8-7
Managing the X.25	
Service Connection	8-9
X.25 Interactive	
Terminal Gateway	
Commands	8-11
Resolving	
Communications	
Problems	9-1
Network Failures	9-1
Automatic Recognition	
Difficulties	9-2
Inadvertent Flow	
Control	9-3
Accidental Transparent	
Input	9-3

Passthrough Service	
Difficulties	9-4
Service Failures	9-6
Cursor Positioning	
Delays	9-6
Glossary	A-1
ASCII Coded Character	
Set	B-1
Changing an Attribute ...	B-2
Using Examples	B-3
Messages	C-1
Understanding Messages .	C-1
List of Messages	C-2
Migrating from CCP	D-1
Using NOS/VE and NOS	
Commands	D-2
Migrating from CCP to	
CDCNET	D-4
Terminal Attribute	
Settings via	
TERMINAL_MODEL	E-1
DO Command (CDCNET	
Procedure Call)	E-2
CHANGE_TERMINAL_	
ATTRIBUTE (CDCNET)	
Command	E-5
NOS/VE Commands	E-7
NOS Commands	E-8
Terminal Attribute	
Settings for Selected	
Terminals	E-8
3270 Binary Synchronous	
Communications	
Protocol	F-1

Your Display Station	F-2	Mode 4 Protocol	I-1
Attribute Support	F-4	Your Mode 4 Terminal ...	I-2
Migrating from CCP	F-12	Supported Features	I-3
X.25 Asynchronous		Attribute Support	I-10
Protocol.....	G-1	Migrating from CCP	I-14
The Protocol	G-2	3270 SNA	
The Environment	G-2	Communications	
Attribute Support and		Protocol.....	J-1
PAD Parameters	G-5	The Protocol	J-2
X.PC Communications		The Environment	J-4
Protocol.....	H-1	Attribute Support	J-5
The Protocol	H-2	Program Attention Key	
The Environment	H-2	Processing.....	J-13
Attribute Support	H-7	Index	Index-1

Figures

3-1. Asynchronous Protocol Terminal Attribute Defaults.....	3-2	FORWARD_CHARACTER Settings.....	D-20
4-1. Asynchronous Protocol Connection Attribute Defaults.....	4-2	D-3. Corresponding TRANSPARENT_ TERMINATE_ CHARACTER Settings....	D-20
8-1. X.25 Interactive Gateway Environment.....	8-1	D-4. Corresponding TRANSPARENT_ LENGTH_MODE Settings.....	D-21
8-2. Gateway Command Mode Connection Attribute Defaults.....	8-2	D-5. Corresponding TRANSPARENT_ TIMEOUT_MODE Settings.....	D-21
8-3. Data Transfer Mode Connection Attribute Defaults.....	8-4	F-1. 3270 Binary Synchronous Communications Protocol Terminal Attribute Defaults.....	F-4
8-4. Connecting to a DTE on an X.25 Network.....	8-7	F-2. 3270 Binary Synchronous Communications Protocol	
D-1. Corresponding TRANSPARENT_ CHARACTER_MODE Settings.....	D-20		
D-2. Corresponding TRANSPARENT_ CHARACTER_MODE Settings.....	D-20		

Connection Attribute Defaults.....	F-10	I-2. Mode 4 Protocol Connection Attribute Defaults.....	I-12
G-1. X.25 Environment	G-2	J-1. 3270 SNA Environment.....	J-4
H-1. X.PC Environment	H-3	J-2. 3270 SNA Communications Protocol Terminal Attribute Defaults.....	J-5
H-2. X.PC Protocol Terminal Attribute Defaults.....	H-8	J-3. 3270 SNA Communications Protocol Connection Attribute Defaults.....	J-8
H-3. X.PC Protocol Connection Attribute Defaults.....	H-12		
I-1. Mode 4 Protocol Terminal Attribute Defaults.....	I-10		

Tables

2-1. Using CDCNET Commands.....	2-6	B-4. ASCII Characters Available for CLC and EPC.....	B-14
3-1. Terminal Attributes and Input Editing Modes....	3-3	B-5. ASCII Characters Available for ELC.....	B-16
4-1. Connection Attributes and Input Editing Modes....	4-4	B-6. ASCII Characters Available for NCC.....	B-18
5-1. Positioning Before Output.....	5-19	D-1. Changing CDCNET Attributes with a TRMDEF Command.....	D-10
5-2. Positioning After Output.....	5-20	D-2. Selected Terminal Attribute Settings for NOS Terminal Classes 1, 2, 3, 5, 6, 7, and 8.....	D-14
8-1. PAD Parameter Mapping Supporting the X.25 Asynchronous Protocol.....	8-5	D-3. Mapping of FN/FV Pairs to CDCNET Attributes.....	D-16
8-2. PAD Parameter Mapping Supporting Non-X.25 Asynchronous Protocols.....	8-5	E-1. Procedure Names.....	E-2
B-1. Complete ASCII Coded Character Set (Characters Available for CRS, EOS, FFS, LFS, TFC, and TTC).....	B-6	E-2. NOS TERMINAL_ MODEL Names.....	E-6
B-2. ASCII Characters Available for AC and BLC.....	B-10	E-3. Selected Terminal Attribute Settings: CDC Terminals.....	E-9
B-3. ASCII Characters Available for BC.....	B-12	E-4. Selected Terminal Attribute Settings: IBM Computers.....	E-10

E-5. Selected Terminal Attribute Settings: Macintosh.....	E-11	H-2. Connection Attribute Differences.....	H-13
E-6. Selected Terminal Attribute Settings: DEC Terminals.....	E-12	I-1. Mode 4 Console Format Effectors.....	I-7
E-7. Selected Terminal Attribute Settings: Zenith Computers.....	E-13	I-2. Terminal Attribute Differences.....	I-11
F-1. Terminal Attribute Differences.....	F-5	I-3. Connection Attribute Differences.....	I-13
F-2. Data Link Control Characters.....	F-8	I-4. CCP and CDCNET Differences.....	I-14
F-3. Connection Attribute Differences.....	F-11	J-1. Terminal Attribute Differences.....	J-6
F-4. CCP and CDCNET Differences.....	F-12	J-2. Program Attention Key Processing, Virtual Line Mode.....	J-13
G-1. PAD Parameter Values.....	G-8	J-3. Program Attention Key Processing, Transparent Mode.....	J-13
H-1. Terminal Attribute Differences.....	H-9		

About This Manual

This manual describes how to access Control Data services through the CDC® Control Data Distributed Communications Network (CDCNET).

Audience

If you are an application programmer, a microcomputer user, a site administrator, or a customer-service analyst who needs to know details about CDCNET's terminal user interface, this manual will be useful to you. The degree of detail in this manual is intended to give you maximum control over CDCNET's terminal user interface. As such, it is not intended for the average terminal user, but for someone providing support for the terminal user's activities.

Prerequisites

This manual assumes that:

- You have detailed information about the terminals you intend to connect to the network.
- You are experienced in your technical areas, but might not be familiar with CDCNET.
- You might come from diverse operating system environments.

NOTE

If you are a TELNET user, consult the CDCNET TCP/IP manual.

Terminology

Terminal in this manual means any interactive device used to access a service through CDCNET. Information on batch devices is described in the CDCNET Batch Device User Guide.

The term **network** is used interchangeably with CDCNET.

Organization

This manual contains introductory, quick-reference, and explanatory materials that are organized as follows:

- Chapter 1 introduces you to basic network concepts as they apply to CDCNET.
- Chapter 2 contains quick-reference descriptions of CDCNET terminal user commands. These include commands to establish new service connections, switch between existing connection, change and display terminal and connection attributes, and obtain help in using CDCNET.
- Chapters 3 and 4 describe CDCNET's terminal and connection attributes, respectively. Terminal attributes are provided so that you can describe the physical aspects of your terminal to the network. Connection attributes are provided so that your application can select a specific style of operation for your session.
- Chapter 5 describes virtual line mode (VLM), transparent mode, and flow control. CDCNET treats your input and output differently, depending upon which mode your connection is using, and whether or not flow control is being used.
- Chapter 6 describes user interrupts processed by CDCNET.
- Chapter 7 describes the interactive terminal passthrough feature.
- Chapter 8 describes the X.25 interactive terminal gateway feature.
- Chapter 9 contains notes and cautions that can help you to resolve terminal-related communications problems.


In addition to the chapters listed above, this manual contains ten appendixes. Appendixes A, B, and C provide general reference information: a glossary, the ASCII coded character set, and terminal interface messages. Appendixes D and E supply service-specific information for NOS/VE and NOS users. Appendixes F, G, H, I, and J discuss unique features of the following protocols: 3270 Binary Synchronous Communications Protocol, X.25 Asynchronous Protocol, X.PC Protocol, Mode 4 Protocol, and 3270 SNA Communications Protocol.

Conventions

The following conventions are used in this manual.

boldface	Command names and required parameters are shown in boldface type when illustrating a format. Chapter 2 describes the syntax of CDCNET commands.
<i>italics</i>	Optional parameters (in some cases, called attributes) in quick-reference command descriptions are shown in italics.
boolean values	ON and OFF represent boolean values in quick-reference descriptions and examples.
examples	Examples of user entries and computer responses are shown in a font that resembles computer output. These examples use abbreviated commands. Unless specified for a particular terminal, you can recreate the examples on any terminal.
network command character	This manual uses the default character (%).
numbers	All numbers are decimal unless otherwise noted.
UPPERCASE	Uppercase is used to depict names of commands, parameters (in some cases, called attributes) and key names. For example, the RETURN key is the carriage-return key.

Related CDCNET Manuals



Available on line only.

Additional Related Manuals

The following Control Data publications provide further information about some of the topics described in this manual.

<u>Title</u>	<u>Publication Number</u>
CDCNET TCP/IP	60000214
CDCNET Configuration Guide	60461550
CDCNET Batch Device User's Guide	60463863
CDCNET Commands Reference Manual	60000414
Network Configuration Utility (NETCU) Online Manual	60000268
CYBIL File Management	60464114

Title	Publication Number
Network Products, Network Access Method, Version 1, Host Application Programming Reference Manual	60499500
NOS Version 2 Reference Set Volume 3, System Commands	60459680
NOS Version 2 Reference Set, Volume 4, Program Interface	60459690
NOS/VE System Usage	60464014
Network Job Entry Facility Installation Manual	15190118

Ordering Manuals

Control Data manuals are available through Control Data sales offices or through:

Control Data
Literature and Distribution Services
308 North Dale Street
St. Paul, MN 55103-2495

Submitting Comments

The last page of this manual is a comment sheet. Please use it to give us your opinion of the manual's usability, to suggest specific improvements, and to report technical or typographical errors. If the comment sheet has already been used, you can mail your comments to:

Control Data
Technical Publications ARH219
4201 Lexington Avenue North
St. Paul, MN 55126-6198

Please indicate if you would like a written response.

You can also submit your comments through SOLVER, an online facility for reporting problems. To submit a documentation comment through SOLVER, do the following:

1. Select option 3 from the main SOLVER menu:

Report a new problem or change an existing PSR.

2. Respond to the prompts for site-specific information.
3. Select option 4 from the new menu:

Write a comment about a manual.

4. Respond to the prompts.

(For information on accessing SOLVER, contact your local Control Data sales office.)

Introduction

1

Accessing and Leaving a Service	1-1
Connecting to CDCNET	1-1
Connecting to a Service	1-3
Disconnecting from a Service	1-3
Disconnecting from CDCNET	1-4
Using CDCNET	1-4
When You Need To Know More About CDCNET	1-4
Your Network	1-5
Terminals	1-5
Using Other Networks	1-6
Using Slave Devices	1-6
CDCNET Features	1-7
Understanding Configuration Options	1-8
Terminal Interface Program (Protocol)	1-9
Line Type	1-12
Line Speed	1-13
Automatic Recognition	1-14
Connect Timeout	1-14
Disconnect Timeout	1-15
Terminal Definition Procedure (TDP)	1-15
Terminal User Procedure (TUP)	1-15
Connection Limit	1-16
EIA Flow Control	1-16
Parity	1-16

The Control Data Distributed Communications Network (CDCNET) connects your terminal to the service you want to use. This chapter describes:

- Accessing and leaving a service
- Using CDCNET
- Understanding configuration options

Accessing and Leaving a Service

CDCNET (also called the network) provides a path called a connection that enables you to access and communicate with your computing service. The following instructions describe the four actions you must take to use your service.

1. Connect to CDCNET
2. Connect to a Service
3. Disconnect from a Service
4. Disconnect from CDCNET

Connecting to CDCNET

To connect your terminal to CDCNET:

1. Have your computer identification information available. This includes phone numbers, service names, terminal model names, and validation information that you have received from your management or your site administrator.
2. Turn your terminal on. If you have any questions about how it operates, consult your terminal documentation or a terminal resource person at your site.
3. If your terminal is connected directly to your network (dedicated), you are ready for the next step. If not, follow your local procedure for connecting a terminal through a modem or data set to the network (switched). This may involve manually dialing a phone number you have been given.

4. Press your RETURN key (or its equivalent) twice.¹ CDCNET responds with a message that looks something like this:

```
9600 bps ASCII, parity: odd
```

```
Copyright Control Data Corporation, 1985, 1989  
DI System Name is 080025100081, TDI_A1  
Terminal Name is 5300000000, $CONSOLE_100081_5300000000  
You may enter CDCNET commands.
```

This message identifies the network equipment (DI System Name) and your terminal (Terminal Name). Make a note of this information, as it can be useful in solving communications problems. The site administrator assigns the *logical* names for this equipment; these are the names that appear after the commas in the display. In the example above, the logical DI name is TDI_A1 and the logical terminal name is \$CONSOLE_100081_5300000000.

NOTE

If you do not receive any messages or receive only garbled (unreadable) messages, consult your site administrator.

You are now connected to CDCNET by way of the \$NET connection. This is not a service connection, but a special connection that allows you to communicate directly with CDCNET by entering CDCNET terminal user commands.

5. If you are working at a facility where network security is a concern, enter the secure access sequence, described in chapter 6, to ensure that you are connected directly to CDCNET.

1. If you are using APL, press an APL right parenthesis [)], instead of pressing the RETURN key a second time. For the typewriter-pairing ASCII coded character set with APL print, this parenthesis corresponds to an ASCII asterisk [*]. For the bit-pairing ASCII coded character set with APL print, the parenthesis corresponds to an ASCII quotation mark ["].

Connecting to a Service

To connect to a service:

1. Some sites may have a special procedure that automatically configures your terminal and/or accesses your computing service. If your management or site administrator gave you the name of a procedure, execute it by entering a DO command followed by the procedure name.

DO procedure name

2. If your procedure (step 1) automatically accesses your service, skip to step 3. Otherwise, using the service name provided by your site administrator, enter the following CDCNET command to access your service.

CREC service name

CREC is the abbreviation for the CREATE_CONNECTION command.

3. Enter any validation information (such as username and password) required by the service, and then begin your processing.

Disconnecting from a Service

When you are ready to stop processing, log off of the service you are connected to by entering the appropriate service-specific command. For example, enter LOGOUT to terminate your NOS/VE session.

Logging out of the service causes CDCNET to delete the associated connection and display the following prompt:

You may enter CDCNET commands.

If you have other service connections on hold when you log off, CDCNET displays these connections before displaying its prompt. This service connection display is formatted as follows:

Connection_Name	Service_Name
\$A	ABC
EDIT	XYZ

Disconnecting from CDCNET

To disconnect from CDCNET, do one of the following:

- If your terminal is using a switched line, hang up the phone.
- If your terminal is using a dedicated line, turn off your terminal.

Using CDCNET

When you are working at a terminal connected to a service, you can normally begin processing tasks without further regard to CDCNET connections and terminal characteristics. However, if you are working as a customer service analyst, writing application programs, or using a microcomputer, you may need to know more about CDCNET features.

When You Need To Know More About CDCNET

Customer service analysts frequently help users resolve problems with terminal characteristics. Some terminals do require additional changes when their characteristics differ from the default settings established for the site's network. Sometimes users need help in changing their terminal characteristics to benefit from different network capabilities.

If you are writing programs or applications, you may need to know more about changing terminal characteristics so that users can successfully work with your products.

If you are using a microcomputer, you may want to tailor the network to your specific needs. For example, file transfers may require you to use different network options.

Although this manual specifically describes how to control network capabilities, you may want to be aware of other options to ensure efficient and correct operation. Changes in the overall presentation of data to the service and to the user can be made from the service, network, and terminals, especially microcomputers, as shown in the following table.

Area	Example
Service	<p>On some services, you can use commands to change the terminal characteristics called terminal attributes. For example, NOS/VE services support the following:</p> <pre>CHANGE_TERMINAL_ATTRIBUTE SET_TERMINAL_ATTRIBUTE IFP\$CHANGE_TERMINAL_ATTRIBUTE</pre> <p>(See appendixes D and E.)</p>
CDCNET	<p>You can also manipulate terminal attributes with the CHANGE_TERMINAL_ATTRIBUTE command.</p>
Microcomputer	<p>As with most terminals, you may change the physical attributes of microcomputers by resetting switches or software parameters. Depending upon the intelligence of the microcomputer, you may also translate data (filter or suppress it) via communication packages (such as CONNECT).</p>

Your Network


This section discusses the following network components:

- Terminals
- Other networks
- Slave devices

Terminals

As mentioned earlier, the word **terminal** in this manual means any interactive device used to access a service through CDCNET. It may be a microcomputer, batch console, video-display terminal, hardcopy terminal, display station, or workstation that you can use to conduct an interactive dialog with your service. It is not a batch device with

only an input or output mechanism. (See the CDCNET Batch Device User Guide for batch information.)



Using Other Networks

Your site may use a local area network (LAN) or a public data network (PDN) between your terminal and CDCNET. In other words, your terminal may go through another network to connect with CDCNET and subsequently access a service. If so, observe these guidelines to expedite CDCNET processing.

- Be aware of any parameter setting on the LAN or PDN that may affect your CDCNET processing.
- Follow your local procedure for accessing and using the LAN or PDN.
- Work with your site administrator to solve any difficulties you may encounter.

Using Slave Devices

Although terminals can have multiple input or output mechanisms on a connection at any time, CDCNET is aware of only one. Such mechanisms operate in series and are called **slave devices**. For example, microcomputer users frequently use printers and disk drives as slave devices. In these cases, the network does not distinguish the input of a microcomputer's disk unit from keyboard input. Similarly, the network treats output to a hardcopy printer the same as display output.

CDCNET Features

CDCNET capabilities, designed to simplify control of your processing, are provided by four types of features.

Type of Feature	Description
Commands	The network recognizes commands that control the way it operates your terminal and service. (See chapter 2.)
Terminal attributes	The network supports terminal attributes that you may display and change. These attributes set characteristics that affect how your terminal communicates with the network, and that apply to all of your connections. (See chapter 3.)
Connection attributes	The network also supports connection attributes that you can display and change. These regulate certain aspects of a <i>connection</i> between your terminal and the service. Each connection has its own set of connection attributes. ² (See chapter 4.)
Procedures	Your site administrator uses procedures in configuring your network. One of these procedures may establish special terminal-attribute and connection-attribute defaults for your terminal. (See the section on Understanding Configuration Options next in this chapter.)

2. \$NET connection attributes (IEM=NORMAL, IOM=SOLICITED) cannot be displayed or changed.

Understanding Configuration Options

Certain operating characteristics can be explicitly set by the site administrator when configuring the network. Some of the characteristics established by the `DEFINE_LINE` command (used by your site administrator) directly affect how you access your service and how your terminal operates. These characteristics are controlled strictly by the site administrator and, in most cases, you cannot override them. Specifically, the site administrator sets parameters on the `DEFINE_LINE` command that determine the following:

- Terminal interface program (protocol)
- Line type
- Line speed
- Automatic recognition
- Connect timeout
- Disconnect timeout
- Terminal definition procedure
- Terminal user procedure
- Connection limit
- EIA flow control
- Parity

`DEFINE_LINE` is described in the CDCNET Configuration Guide.

The following sections describe the configuration options.

Terminal Interface Program (Protocol)

CDCNET supports a number of communication protocols. Each supported protocol has an associated terminal interface program (TIP) that allows users of that protocol to interface with CDCNET. CDCNET provides the following terminal interface programs, supporting their respective protocols.

TIP Name	Supported Protocol	Description
ASYNCTIP	Asynchronous	ASYNCTIP supports the use of teletype-compatible terminals connected through dedicated or switched asynchronous communication lines via the Asynchronous protocol. The TIP supports one device per communication line, and expects each device to have both an input and output mechanism (terminal), or an output mechanism (printer) only.
HASPTIP	HASP	HASPTIP supports the use of consoles that are attached to HASP workstations through the HASP protocol. This TIP enables your communication line and allows you to perform limited data editing and cursor positioning. (See the CDCNET Batch Device User Guide for information on card readers, line printers, card punches, and plotters.)

TIP Name	Supported Protocol	Description
MODE4TIP	Mode 4	MODE4TIP lets users of Mode 4 terminals connect to services through CDCNET via the Mode 4 protocol. There are two versions of the protocol: Mode 4A and Mode 4C. Mode 4A supports a group of devices, such as a console, line printer, and card reader. Mode 4C supports several clusters of consoles and line printers. See appendix I for more information.
URITIP	Unit Record Interface (URI)	URITIP supports character and line printers using the URI protocol. The protocol is managed by the network, and user action is not necessary. See the CDCNET Batch Device User Guide for further information.

TIP Name	Supported Protocol	Description
XPCTIP	X.PC	XPCTIP lets personal computer users access CDCNET services over switched or dedicated asynchronous lines using the packet-switching communications techniques of the X.PC protocol. The TIP supports up to 15 simultaneous connections over a single link, providing the personal computer user with powerful, advanced capabilities, such as windowing and error-free data transfers. See appendix H for more information.
X25_ASYNC_TIP	X.25 Asynchronous	X.25_ASYNC_TIP supports asynchronous terminals that are connected to CDCNET through an X.29 PAD (Packet Assembler/Disassembler) using the X.25 Asynchronous protocol. See appendix G for more information. The TIP also supports use of the X.PC protocol over X.25 asynchronous lines.
BSC3270TIP	3270 Binary Synchronous Communications	BSC3270TIP enables users of IBM 3270 Information Display Systems (terminals) to connect to CDCNET and use NOS and NOS/VE services via the 3270 Binary Synchronous Communications protocol. See appendix F for more information.

TIP Name	Supported Protocol	Description
SNA3270_TIP	3270 SNA Communications	SNA3270_TIP enables IBM 3270 Information Display Systems (terminals), connected to an SNA network, to access CDCNET through the 3270 SNA Communications protocol and use NOS and NOS/VE services. See appendix J for more information.

The protocol you use determines which terminal attributes and connection attributes are available to you in the associated TIP. Each protocol has its own subset of attributes and defaults. For example, the Asynchronous protocol uses all of the available attributes, while the HASP and 3270 Binary Synchronous Communications protocols use small subsets of ASYNCTIP attributes.

In addition, the network has provisions for site-defined TIPs supporting protocols currently not supported by CDCNET TIPs. If a site-defined TIP is used at your site, your site administrator is responsible for documenting it.

Line Type

The network recognizes two types of communication lines.

Type of Line	Description
Switched	A switched line typically requires a dial-in procedure and modem.
Dedicated	A dedicated line is usually connected directly to the network.

Line Speed

The site administrator defines the speed of a communication line in bits per second (bps) or, alternatively, the site administrator can enable automatic recognition of line speed. The network accepts the following line speeds for the Asynchronous, HASP, Mode 4, X.PC, and 3270 Binary Synchronous Communications protocols.³

	50	
	75	
	110	Asynchronous and X.PC Protocols
	150	
	300	
	600	
	1200	
Mode 4 Protocol	2400	3270 Binary Synchronous Communications Protocol
	4800	
	9600	
	19200	
	38400	
HASP Protocol	48000	
	56000	
	64000	

When transmitting data to CDCNET, terminals using the asynchronous protocol send a signal, called a stop bit, at the end of each character to prepare the network for the following character. The network assumes that terminals operating at 110 bits per second or slower use two stop bits, and terminals with speeds of 150 bits per second or higher use one. You may have to change a setting on your terminal to match the network's expectation.

3. Trunk speeds for X.25 Asynchronous and 3270 SNA Communications protocols are not described here, because terminals using these protocols are not directly connected to CDCNET.

Automatic Recognition

If you are using the asynchronous protocol, your site administrator may request CDCNET to determine certain things about your terminal when it joins the network. The administrator can specify automatic recognition of any of the following:

- Line speed only
- Line speed and coded character set
- Line speed, coded character set, and parity

If the site administrator omits this parameter, the network does not perform any automatic recognition. However, it does force the following settings when automatic recognition of coded character set and parity is not requested.

```
CODE_SET=ASCII  
PARITY=EVEN
```

On a switched line, you have 90 seconds to complete automatic recognition before the network disconnects your terminal.

Terminals reaching CDCNET through another network usually do not use the CDCNET automatic recognition process. However, the other network may have a corresponding process.

Connect Timeout

After you access CDCNET, you have a specified amount of time to create a connection to a service. If you do not establish one within that time, the network disconnects the communication line.

Your site administrator can specify any limit from 20 through 1000 seconds. If the administrator omits this setting, the network sets the connect timeout at 2 minutes (120 seconds) for a switched line and INFINITE for a dedicated line.

If you are also using automatic recognition, the network allows 90 seconds for that process, plus the time specified on this parameter, before disconnecting the communication line.

Disconnect Timeout

When you are using the \$NET connection and do not have any other connection, you have a specified amount of time to establish a new connection to a service. If you do not enter a CREATE_CONNECTION command within that time, the network disconnects the communication line.

Your site administrator can specify any limit from 20 through 1000 seconds. If the administrator omits this setting, the network sets the disconnect timeout at 2 minutes (120 seconds) for a switched line and INFINITE for a dedicated line.

Terminal Definition Procedure (TDP)

A site administrator can configure the network for the type of equipment on a communication line by creating a terminal definition procedure (TDP) that the network associates with the communication line. If the site administrator creates both a TDP and a terminal user procedure (TUP) (described next) on the DEFINE_LINE command, the network executes only the TDP. However, if the site administrator defines a TUP on a DEFINE_TERMINAL_DEVICE command within the TDP, the network executes both the TDP and that TUP.

Terminal User Procedure (TUP)

If the site administrator wants to change your access procedure or establish individual attribute defaults for your terminal, the administrator can create a terminal user procedure (TUP). When you access the network, it automatically executes this procedure. A TUP may contain any terminal user commands described in this manual, except ACTIVATE_AUTO_RECOGNITION.

The network executes both the TUP and the TDP if the site administrator has defined the TUP on a DEFINE_TERMINAL_DEVICE command within the TDP. Otherwise, the network executes only the TDP.

For more information on TDP and TUP, see the CDCNET Configuration Guide.

Connection Limit

CDCNET allows you to create and use a number of connections to link your terminal to computing services. The connection you are currently using is called your working connection. When you initially access CDCNET, your working connection is the default connection, \$NET.

You can have multiple connections to one or more services. The site administrator can configure the maximum number of connections. If the administrator omits this parameter, the network allows each terminal four connections. For the X.PC protocol, a virtual circuit with no service connections is counted as having one connection for the purposes of checking against this limit.

EIA Flow Control

The site administrator specifies whether or not you can use EIA flow control to control the flow of input. (See chapter 5 for additional information on flow control.) If the administrator omits this parameter on the DEFINE_LINE command, the network does not use EIA flow control for input. However, the network always responds to EIA flow control received from a terminal for output.

Parity

The site administrator can specify parity for data received and transmitted on this line if the administrator has not selected automatic recognition of parity. The setting of the DEFINE_LINE parameter is also the setting of the PARITY terminal attribute when automatic recognition of parity is not specified. If the site administrator does not select one of the following settings, the network uses EVEN.

EVEN
ODD
MARK
ZERO
NONE

(See Connecting to CDCNET earlier in this chapter and the description of the PARITY terminal attribute in chapter 3 for more information.)

CDCNET Terminal Interface Commands 2

Command Conventions	2-2
Command Format	2-2
Abbreviations	2-3
Parameter Position	2-4
Position Independent	2-4
Position Dependent	2-4
Parameter Values	2-5
Command Summary	2-6
ACTIVATE_AUTO_RECOGNITION (ACTAR)	2-8
ACTIVATE_X_PERSONAL_COMPUTER (ACTXPC)	2-11
CHANGE_CONNECTION_ATTRIBUTE (CHACA)	2-13
CHANGE_TERMINAL_ATTRIBUTE (CHATA)	2-15
CHANGE_WORKING_CONNECTION (CHAWC)	2-17
CREATE_CONNECTION (CREC)	2-19
DELETE_CONNECTION (DELC)	2-22
DISPLAY_COMMAND_INFORMATION (DISCI)	2-25
DISPLAY_COMMAND_LIST (DISCL)	2-26
DISPLAY_CONNECTION_ATTRIBUTES (DISCA)	2-27
DISPLAY_CONNECTIONS (DISC)	2-28
DISPLAY_SERVICE (DISS)	2-32
DISPLAY_TERMINAL_ATTRIBUTE (DISTA)	2-35
DO	2-36
REQUEST_NETWORK_OPERATOR (REQNO)	2-37

This chapter describes CDCNET terminal interface commands. Most of these commands can be entered either from an interactive session or from within a terminal procedure (exceptions are noted in the command descriptions). For information about constructing and using terminal procedures, refer to the CDCNET Configuration Guide.

CDCNET terminal user commands can be entered at any time, whether you are connected to the default CDCNET connection (called \$NET) or to a service. The way you enter a CDCNET command on a service connection depends on whether the INPUT_EDITING_MODE connection attribute is set to NORMAL or TRANSPARENT. The differences are summarized in the following table:

Type of Connection	How to Enter a CDCNET Terminal User Command
\$NET	You can enter the CDCNET terminal user commands described in this chapter <i>without prefixing them with the network command character</i> .
Service Connection, Normal Mode	You can enter the CDCNET terminal user commands described in this chapter <i>by prefixing them with the network command character</i> . CDCNET looks for the network command character on normal input and tries to execute what follows as a user interrupt or command.
Service Connection, Transparent Mode	You can enter the CDCNET terminal user commands described in this chapter only after using one of the user break sequences described in chapter 6.

Command formats and examples in this chapter assume you are using a service connection that is in normal input editing mode. The default network command character, a percent sign (%), is used in all formats and most examples. You can change the network command character with the CHANGE_TERMINAL_ATTRIBUTE command described later in this chapter.

Command Conventions

CDCNET commands use NOS/VE System Command Language (SCL) conventions. The following sections describe the general structure of these commands, as used interactively and in procedures. The following conventions apply to all CDCNET commands.

- Each command must appear on a separate line.
- A command can contain as many as 256 characters.
- With the exception of strings, uppercase and lowercase letters are interchangeable in commands. (See the discussion of parameter values later in this chapter.)

Command Format

CDCNET command names consist of a verb that describes the operation, followed by an object that represents the target of the operation. The verb and object are concatenated by an underline character (), which is part of the name and cannot be omitted or replaced by a space. For example:

```
CREATE_CONNECTION
```

In this example, the underline connects the verb (CREATE) to its object (CONNECTION).

CDCNET commands entered on a service connection operating in NORMAL input editing mode must be preceded by the network command character. This manual uses the default network command character for the Asynchronous protocol, a percent sign (%). For example:

```
%CREATE_CONNECTION
```

When you enter a command from the \$NET connection, you can omit the NETWORK_COMMAND_CHARACTER because this connection handles only CDCNET communications. It does not communicate with a service.

Like command names, parameter names are concatenated if they have more than one word. In the following example, the underline joins the two parts of the parameter name (SERVICE_NAME).

```
%CREATE_CONNECTION SERVICE_NAME=service name
```

After you enter a command and its parameters, press the RETURN key (or equivalent) to execute the command.

NOTE

Separate the command name and each parameter with spaces or commas. For example:

```
%CREATE_CONNECTION SERVICE_NAME=service name OUTPUT_ACTION=output action
```

```
%CREATE_CONNECTION, SERVICE_NAME=service name, OUTPUT_ACTION=output action
```

Abbreviations

When you enter commands and parameters, you can use their spelled-out names, their abbreviations, or a combination of the two. For example:

```
CREATE_CONNECTION SN=service_name OUTPUT_ACTION=output_action
```

CDCNET commands are abbreviated by taking the first three characters from the verb portion of the command name and concatenating them with the first character from each subsequent word in the command name (CREATE_CONNECTION is abbreviated CREC). Generally, the first character from each word in a parameter name is used to abbreviate parameters (SERVICE_NAME is abbreviated SN).

If a command has a singular and plural form, the abbreviation applies to both. For example, DISTA is the abbreviation for DISPLAY_TERMINAL_ATTRIBUTE and DISPLAY_TERMINAL_ATTRIBUTES.

Parameter Position

When you enter CDCNET commands at a terminal, you can specify position-independent or position-dependent parameters.

Position Independent

Position-independent parameters consist of a parameter name or abbreviation, an equal sign, and a value. That is,

```
PARAMETER_NAME=value
```

You can place these parameters in any order. For example:

```
%CREC OA=output action SN=service name
```

Position Dependent

Position-dependent parameters contain only the value, not the parameter name or equal sign. You specify them in the order shown in the command description. If you omit a parameter, separate the parameters with commas and insert an extra comma for the missing parameter. In the following CREATE_CONNECTION examples, the extra comma skips over the second parameter, the CONNECTION_NAME parameter.

```
%CREATE_CONNECTION service_name,,output_action
```

```
%CREC service_name,,output_action
```

Parameter Values

Network commands define the kinds of values you can assign parameters, and the ranges these values can have.

CDCNET commands use the following kinds of System Command Language (SCL) parameter values:

- Name
- String
- Integer
- Boolean
- Keyword

In addition, the commands use the following CDCNET-defined parameter values.

- Character
- Sequence
- List
- Message

These parameter value types are described in the following sections.

Command Summary

Table 2-1 summarizes the commands described in this chapter.

Table 2-1. Using CDCNET Commands

Command	Purpose
ACTIVATE_AUTO_RECOGNITION	Resets your terminal's line speed, coded character set, and/or parity.
ACTIVATE_X_PERSONAL_COMPUTER	Switches a microcomputer connection from asynchronous protocol to X.PC protocol.
CHANGE_CONNECTION_ATTRIBUTE	Changes any of the attributes the network uses to control your working connection.
CHANGE_TERMINAL_ATTRIBUTE	Changes any of the attributes the network uses to control your terminal device. These attributes apply to all active connections.
CHANGE_WORKING_CONNECTION	Changes your working connection from one existing connection to another.
CREATE_CONNECTION	Creates a new CDCNET connection.
DELETE_CONNECTION	Deletes an existing CDCNET connection.
DISPLAY_COMMAND_INFORMATION	Displays summary information about any of the CDCNET terminal user commands.

(Continued)

Table 2-1. Using CDCNET Commands (Continued)

Command	Purpose
DISPLAY_COMMAND_LIST	Displays a list of the CDCNET terminal user commands.
DISPLAY_CONNECTION_ATTRIBUTES	Displays the connection attributes associated with the working connection.
DISPLAY_CONNECTIONS	Displays summary information about existing CDCNET connections.
DISPLAY_SERVICE	Displays a list of some or all of the computing services available on the network.
DISPLAY_TERMINAL_ATTRIBUTE	Displays the attributes associated with your terminal device.
DO	Executes a terminal user or terminal definition procedure.
REQUEST_NETWORK_OPERATOR	Sends a message to the network operator.

The following pages describe the CDCNET terminal user commands, in alphabetical order. These commands are presented in a quick-reference format that includes purpose, format, parameters, remarks, and examples, when applicable. Each description begins with a command name followed by its abbreviation, enclosed in parentheses. Under the parameter descriptions, each parameter name is followed by its abbreviation, in parentheses.

ACTIVATE_AUTO_RECOGNITION (ACTAR)

Purpose Directs the network to test your terminal's line speed, coded character set, and/or parity, and to adjust the line's settings accordingly. This command can only be entered interactively; it cannot be used in a terminal user procedure (TUP).

NOTE

The level of automatic recognition varies, depending upon how the line was defined. The possibilities are as follows:

1. Automatic recognition of line speed, code set and parity
2. Automatic recognition of line speed and code set
3. Automatic recognition of line speed only
4. No automatic recognition

Ask your site administrator what level of automatic recognition your line uses.

Format %ACTIVATE_AUTO_RECOGNITION

- Remarks**
- If the site administrator defined your line for automatic recognition of speed, coded character set, and parity, here is what happens when you use the ACTAR command:
 1. After you enter the ACTAR command (complete with a single RETURN), the network is ready for you to change your terminal's line speed, and/or code set and parity.
 2. After you make the desired changes to your terminal's settings, press the RETURN key again. The network uses this character (usually CR) to detect line speed, and returns two line-feed characters in the original PARITY setting (some terminals may report parity errors on these two characters).

3. Now change your terminal's code set and parity settings (if you haven't already done so).
4. If you are using the ASCII coded character set, press the RETURN key once more. The network uses this character to determine coded character set and parity, and it changes its settings of the CODE_SET and PARITY terminal attributes to match your terminal's new settings.

If you are using APL, press an APL right parenthesis [)] instead of pressing the RETURN key again. For the typewriter-pairing ASCII coded character set with APL print, this parenthesis is an ASCII asterisk (*). For the bit-pairing ASCII coded character set with APL print, the parenthesis is an ASCII quotation mark (").

5. The network returns a message that indicates your terminal's new line speed, coded character set and parity. Depending upon the line speed, the network issues NUL characters before displaying the message, as follows:

<u>Line Speed</u>	<u>Number of NUL Characters</u>
110 through 600 bps	2 NUL characters
1200 through 9600 bps	1 NUL character
19200 through 38400 bps	None

The network inserts 2 NUL characters after each message.

- If the site administrator defined your line for automatic recognition of your terminal's parity, the network sets the PARITY terminal attribute to the following:

Terminal's Parity	Terminal Attribute PARITY Setting
EVEN	EVEN
MARK	EVEN
ODD	ODD
ZERO	ODD
NONE	ODD

- X.PC line speed can be automatically recognized. However, character set and parity are ignored during automatic recognition. The X.PC character set is always ASCII, and parity is set by the X.PC protocol.
- Devices such as PCs, which use procedures to perform auto-recognition, should use a 2-second delay between the first and second carriage returns of the auto-recognition sequence.
- See Automatic Recognition Difficulties, chapter 8, for additional information about automatic recognition.

Examples

If you use the ASCII coded character set and your line was defined for automatic recognition, you can change the line speed to 9600 bits per second (bps) in the following three steps:

1. Enter the following command (complete with a single carriage return):

```
%ACTAR
```

2. Switch the terminal's line speed to 9600 bps (consult your terminal's user guide).
3. Press the RETURN key twice.

The network responds with a message that identifies your terminal speed, coded character set, and parity. For example:

```
9600 bps ASCII, parity: even
```

ACTIVATE_X_PERSONAL_COMPUTER (ACTXPC)

Purpose Switches a microcomputer's connection to operate in the X.PC protocol mode (it is not necessary to use this command if your microcomputer's CDCNET line is configured specifically for the X.PC protocol). When the connection is switched to the X.PC protocol mode, the microcomputer is directed to start the X.PC protocol. See appendix H for a description of the CDCNET support of the X.PC protocol.

Format **%ACTIVATE_X_PERSONAL_COMPUTER**
TIMEOUT = integer
OPTIMIZE_PACKETS = boolean

TIMEOUT (T)

Specifies the time limit during which the network retransmits unacknowledged packets. Default is 4 seconds.

OPTIMIZE_PACKETS (OP)

Specifies whether or not the network must reduce the size of the X.PC packet to a more optimum size for X.25 packets. Default is FALSE.

- Remarks**
- Your microcomputer must be connected to CDCNET using the asynchronous or X.25 asynchronous protocol. If connected using the asynchronous protocol, the DI must be configured for the X.PC protocol. If connected to the X.25 asynchronous protocol, the DI does not have to be configured for the X.PC protocol. The microcomputer software must switch to X.PC mode upon notification that the network is activating the X.PC protocol.
 - When the network receives this command, it verifies the correct protocol is currently in use, and that the coded character set is ASCII. The X.PC protocol is then started for that line. X.PC informs you that the command completed successfully by sending the following message:

X.PC protocol being activated.

ACTIVATE_X_PERSONAL_COMPUTER (ACTXPC)

- If your microcomputer does not start the X.PC protocol within 1.5 minutes of receiving this message, the microcomputer is disconnected. If connected using the asynchronous protocol, the line is then disconnected. If connected using the X.25 asynchronous protocol, the virtual circuit is then cleared.
- You do not need to use the ACTXPC command if your microcomputer is directly configured to the X.PC protocol (the site administrator defined your line for use with X.PC), or if your microcomputer's data communications software issues this command automatically. Ask your site administrator how your data communications line is configured and refer to your microcomputer data communications software documentation to understand how X.PC is activated on your microcomputer system.

CHANGE_CONNECTION_ATTRIBUTE (CHACA)

Purpose Specifies changes you want made to your current connection attributes.

Format **%CHANGE_CONNECTION_ATTRIBUTE**
ATTENTION_CHARACTER_ACTION = integer
ATTENTION_CHARACTER_ENABLE = keyword
BREAK_KEY_ACTION = integer
ECHO_ENABLE = keyword
INPUT_BLOCK_SIZE = integer
INPUT_EDITING_MODE = keyword
INPUT_FLOW_CONTROL_ENABLE = keyword
INPUT_OUTPUT_MODE = keyword
OUTPUT_FLOW_CONTROL_ENABLE = keyword
PARITY_ENABLE = keyword
PARTIAL_CHARACTER_FORWARDING = keyword
STORE_BACKSPACE_CHARACTER = keyword
STORE_NULS_DELS = keyword
TRANSPARENT_CHARACTER_MODE = keyword
TRANSPARENT_FORWARD_CHARACTER = list
TRANSPARENT_LENGTH_MODE = keyword
TRANSPARENT_MESSAGE_LENGTH = integer
TRANSPARENT_PROTOCOL_MODE = keyword
TRANSPARENT_TERMINATE_CHARACTER = list
TRANSPARENT_TIMEOUT_INTERVAL = integer
TRANSPARENT_TIMEOUT_MODE = keyword

Parameters Each CHACA parameter has a corresponding connection attribute description in chapter 4.

- Remarks**
- The CHACA command does not apply when your working connection is \$NET.
 - Use of a DO command may change your connection attributes if the procedure contains a CHACA command. You should be aware of the effects of a procedure before you execute it.
 - When writing application programs, you must change connection attributes by using commands available to your application via the service you are using.

CHANGE_CONNECTION_ATTRIBUTE (CHACA)

Examples The following CHACA command changes the values of STORE_BACKSPACE_CHARACTER and STORE_NULS_DELS from OFF to ON.

```
%CHACA SBC=ON SND=ON
```

The network makes the changes and responds with a message:

```
Attributes changed.
```

CHANGE_TERMINAL_ATTRIBUTE (CHATA)

Purpose Specifies changes you want to make to your current terminal attributes.

Format **%CHANGE_TERMINAL_ATTRIBUTE**
ATTENTION_CHARACTER = character
BACKSPACE_CHARACTER = character
BEGIN_LINE_CHARACTER = character
CANCEL_LINE_CHARACTER = character
CARRIAGE_RETURN_DELAY = integer
CARRIAGE_RETURN_SEQUENCE = sequence
CHARACTER_FLOW_CONTROL = keyword
CODE_SET = name or keyword
ECHOPLEX = keyword
END_LINE_CHARACTER = character
END_LINE_POSITIONING = keyword
END_OUTPUT_SEQUENCE = sequence
END_PAGE_ACTION = keyword
END_PARTIAL_CHARACTER = character
END_PARTIAL_POSITIONING = keyword
FOLD_LINE = keyword
FORM_FEED_DELAY = integer
FORM_FEED_SEQUENCE = sequence
HOLD_PAGE = keyword
HOLD_PAGE_OVER = keyword
LINE_FEED_DELAY = integer
LINE_FEED_SEQUENCE = sequence
NETWORK_COMMAND_CHARACTER = character
PAGE_LENGTH = integer
PAGE_WIDTH = integer
PARITY = keyword
RESPONSE_ACTION = keyword
STATUS_ACTION = keyword
TERMINAL_MODEL = name
BACKSPACE_WINDOW = integer
CONTROL_CODE_REPLACEMENT = list
FUNCTION_KEY_CLASS = name

Parameters Each CHANGE_TERMINAL_ATTRIBUTE parameter has a corresponding terminal attribute description in chapter 3.

CHANGE_TERMINAL_ATTRIBUTE (CHATA)

- Remarks**
- Use of a DO command may change your terminal attributes if the procedure contains a CHANGE_TERMINAL_ATTRIBUTE command. You should be aware of the effects of a procedure before you execute it.
 - You can change a terminal attribute with the CHANGE_TERMINAL_ATTRIBUTE command even if the protocol your terminal uses does not support it. The changed value for the nonsupported terminal attribute, however, has no effect and is not validated by your terminal's protocol.

Examples By specifying a series, you can change several terminal attributes using a single command. The following CHANGE_TERMINAL_ATTRIBUTE command changes the values of PAGE_LENGTH and HOLD_PAGE. These changes extend the page length to 30 lines and display output one page at a time.

```
%CHATA PL=30 HP=ON
```

You can also change a single attribute.

```
%CHATA PL=0
```

In this example, the CHANGE_TERMINAL_ATTRIBUTE command changes PAGE_LENGTH to 0 so that your output is continuous, without page breaks.

CHANGE _WORKING _CONNECTION (CHAWC)

Purpose Makes an alternate existing connection the working connection, without deleting the connection you are leaving. The working connection is the connection your terminal currently uses to exchange information on the network.

Format `%CHANGE_WORKING_CONNECTION`
`CONNECTION_NAME=connection name`
`OUTPUT_ACTION=output action`

Parameters `CONNECTION_NAME (CN)`

Identifies the new working connection. If you do not specify a new working connection, CHAWC makes the \$NET connection your working connection.

`OUTPUT_ACTION (OA)`

Specifies one of the following entries:

`DISCARD (D)` Discards new output from the connection you are leaving.

`HOLD (H)` Holds new output from the connection you are leaving. When you return to this connection, the output is displayed.

If you do not enter an output action, the network uses `HOLD`.

- Remarks**
- This command lets you use multiple connections simultaneously. You can move from one connection to another to obtain job output, display status reports, edit, and perform other activities just as you can between terminals.
 - Using the `CHANGE_WORKING_CONNECTION` command to switch your working connection does not delete the connection you are leaving.
 - You cannot select a connection that has a connection status of `PENDING` as your working connection.

CHANGE_WORKING_CONNECTION (CHAWC)

Examples The following command changes your working connection to an existing connection named `EDIT`, on a service named `ABC`, and holds output from the connection you are leaving:

```
%CHAWC EDIT
```

The network responds with the following message:

```
Working connection changed to EDIT, service name ABC.
```

You can retrieve the output from the previous working connection by changing the current (working) connection to the previous connection.

The following command changes your connection to `$NET`, which is not connected to any service:

```
%CHAWC
```

CDCNET responds with a display of all existing service connections, and a prompt for CDCNET terminal user commands. The display is formatted as follows:

Connection_Name	Service_Name
\$A	ABC
EDIT	XYZ

You may enter CDCNET commands.

CREATE_CONNECTION (CREC)

Purpose Creates a connection to the service you select and automatically makes it your working connection. This command is necessary to access a service through CDCNET.

Format **%CREATE_CONNECTION**
SERVICE_NAME=service name
CONNECTION_NAME=connection name
OUTPUT_ACTION=output action
WAIT=boolean
SERVICE_DATA=string

Parameters **SERVICE_NAME (SN)**

Specifies the name of the service or gateway to which you wish to connect. See your site administrator for the names of services and gateways on your network.

CONNECTION_NAME (CN)

Assigns a unique name to the connection. This name can be 1 through 31 characters long. It must begin with a non-numeric, but can contain a combination of letters, numerics, and special characters (**_**, **\$**,¹ **#**, **@**). If you do not enter a connection name, the network assigns a system-reserved name beginning with a dollar sign (**\$**).

OUTPUT_ACTION (OA)

Specifies one of the following:

DISCARD (D)	Discards new output from the working connection you are leaving.
HOLD (H)	Holds new output from the connection you are leaving. When you return to this connection, the output is displayed.

Default is **HOLD**.

1. The dollar sign (**\$**) cannot be used to begin a user-specified connection name, but can be used anywhere else in the name.

CREATE_CONNECTION (CREC)

WAIT (W)

Specifies one of the following:

- | | |
|-----|--|
| YES | If the service you requested is unavailable, a connection is created and put in a state where it waits for the service to become available. If and when the service becomes available, you receive a message indicating the requested connection has been completed. |
| NO | If the service is unavailable, the connection request is terminated, and you receive a message indicating the requested service is unavailable. |

The default is NO.

SERVICE_DATA (SD)

Specifies a string of 1 to 63 characters that is interpreted or required by the service to which you are requesting the connection.

Remarks

- You can create more than one connection to the same service.
- If creating another connection would cause you to exceed the connection limit your site administrator set, the network issues an error message instead of connecting your terminal to the service. Use the `DISPLAY_CONNECTION` command to check your connection limit.
- Use the `CHANGE_WORKING_CONNECTION` command to alternate between existing CDCNET connections.

Examples The following command, in response to the CDCNET prompt, creates an initial service connection to a service named ABC:

```
CREC SN=ABC
```

The network command character is not required with this command because the working connection is still \$NET. The following message is displayed prior to any banner message supplied by the ABC service:

```
Connection $A created.
```

While connected to service ABC, a second connection is created by prefixing the CREC command with the network command character (%). For example, the following command creates a connection to service XYZ, and assigns this connection the name EDIT.

```
%CREC XYZ EDIT
```

The following message is displayed prior to any banner message supplied by service XYZ:

```
Connection EDIT created.
```

The following is an example of how the SERVICE_DATA parameter is used in the CREC command to create a CDCNET connection to a User TELNET gateway named TELNET. After the connection is made to the User TELNET gateway, the gateway uses the information provided in the SERVICE_DATA parameter to establish a TELNET connection to a remote TCP/IP host.

```
CREC,TELNET, SD='128.2.53.7'
```

The following example shows CREC command used with the WAIT parameter specified to YES.

```
CREC ARHNOS W=YES
```

The following message is displayed if ARHNOS is unavailable.

```
Searching for ARHNOS.  
Connection $A pending.
```


DELETE_CONNECTION (DELC)

Purpose Deletes the specified connection. If you delete a connection other than the current working connection, the session on your current working connection continues. If you delete the current working connection, you are connected to the \$NET connection and you receive a list of all other connections currently on HOLD. This display also occurs when you log off the service and other connections are currently on HOLD. You can then create a new connection (using CREC) or change to another existing connection (using CHAWC).

Format %DELETE_CONNECTION
CONNECTION_NAME=\$NET *or connection name*

Parameters CONNECTION_NAME (CN)
Specifies the name of the connection to be deleted. This parameter is required only when you want to delete the \$NET connection. The parameter value defaults to the current working connection when entered on a connection other than the \$NET connection.

- Remarks**
- This command disconnects you from the associated service, but does not necessarily cause the processes you were using on that service to be terminated. For this reason, it is usually better to log off of the service instead of using DELC. If the service does not disconnect you from CDCNET after you log off, use the DELC command.
 - This command can be used to delete a connection when you have reached the user connection limit and need to create another connection. This command can also be used to discontinue a logon sequence in the event that you create a connection to a service that you cannot, or don't care to, log onto.
 - This command can be used to delete a passthrough connection (refer to chapter 7).
 - If you delete the only remaining connection, a switched line times out (as determined by a network definition parameter) and disconnects.

- \$NET can only be deleted if you are at a terminal connected by the Asynchronous and X.25 protocols. In the case of the asynchronous protocol, all connections are deleted and the line disconnected (modem signals are dropped). If you are connected to CDCNET through a front-end communication device, you may, depending on the device, still be controlled by that device. In the case of X.25 protocol, your virtual circuit is deleted and you are back under the control of the X.25 PAD (such as TELENET or TYMNET) to which you were first connected.

Examples The following command deletes a connection named EDIT, without affecting the working connection:

```
%DELC EDIT
```

The following message is displayed to the session in progress on the working connection:

```
Connection EDIT deleted.
```

The following command deletes the working connection and connects the terminal to the default connection, \$NET:

```
%DELC
```

If you do not have other service connections on hold, the working connection is deleted and CDCNET issues the following message:

```
You may enter CDCNET commands.
```

If you *do* have other service connections on hold, the working connection is deleted and CDCNET issues a message that identifies the remaining connections. This message is formatted as follows:

Connection_Name	Service_Name
\$A	ABC
EDIT	XYZ

```
You may enter CDCNET commands.
```

DELETE_CONNECTION (DELC)

The following command, entered on the \$NET connection, disconnects your terminal from CDCNET:

```
%DELC $NET
```

If you specify an invalid CONNECTION_NAME parameter value, the network issues the following message:

```
Connection <connection_name> is unknown.
```

If you enter a DELC command on the \$NET connection, but do not specify a CONNECTION_NAME parameter, the network issues the following message:

```
Parameter CONNECTION_NAME is required when  
DELC is entered from the $NET connection.
```

DISPLAY_COMMAND_INFORMATION (DISCI)

Purpose Displays the parameters for a CDCNET terminal user command. The information includes the names and abbreviations of parameters, their types (including allowed keyword values), and their default values (if the parameter is not required). This command is similar to the NOS/VE command of the same name.

Format %DISPLAY_COMMAND_INFORMATION
COMMAND=name

Parameters COMMAND (C)

This parameter specifies the full or abbreviated name of the command for which information is to be displayed.

Remarks Command parameter displays from this command are written for users of the Asynchronous protocol. Not all parameters and parameter value ranges are necessarily valid for other protocols.

Examples The following command displays information about the CREATE_CONNECTION command:

```
% DISCI CREC
```

Output from this command is formatted as follows:

```
service_name, sn      : name = $required
connection_name, cn  : name = $optional
output_action, oa    : key discard, d, hold, h = hold
wait, w              : boolean = false
service_data, sd     : string, 1..63 = $optional
```

Each line of the display provides information about one of the command's parameters. The parameter name, and its abbreviation, appear to the left of the colon (:). Valid parameter values are listed to the right of the colon. Default values are listed to the right of the equal sign (=).

For example, the third parameter of the CREC command (see above) is OUTPUT_ACTION, or OA. Its value is of type *key*, with the allowed values *discard* (or *d*), and *hold* (or *h*). The default value for the OA parameter is *hold*.

DISPLAY_COMMAND_LIST (DISCL)

DISPLAY_COMMAND_LIST (DISCL)

Purpose Displays an alphabetically ordered list of the valid CDCNET terminal user commands, which includes all of the commands documented in this chapter.

Format %DISPLAY_COMMAND_LIST or
%HELP

Examples The following command displays a list of the CDCNET commands that can be entered from a terminal:

```
%DISCL
```

Output from this command is formatted as follows:

```
activate_auto_recognition  
activate_x_personal_computer  
change_connection_attribute  
change_terminal_attribute  
change_working_connection  
create_connection  
delete_connection  
display_command_information  
display_command_list  
display_connection  
display_connection_attribute  
display_service  
display_terminal_attribute  
do  
help  
request_network_operator
```

DISPLAY_CONNECTION_ATTRIBUTES (DISCA)

- Purpose** Displays your connection attributes. If you do not list one or more of the attributes, the network displays the complete list.
- Format** **%DISPLAY_CONNECTION_ATTRIBUTES**
DISPLAY_OPTION=connection attribute or
CONNECTION_ATTRIBUTE=connection attribute
- Parameters** *DISPLAY_OPTION (DO)* or *CONNECTION_ATTRIBUTE (CA)*
 Specifies a connection attribute. See the connection attribute descriptions in chapter 4.
- Remarks**
- The network displays connection attributes in the order that you list them. If you do not specify any attributes, all are listed alphabetically.
 - You can use the **DISPLAY_CONNECTION_ATTRIBUTES** command on any connection except **\$NET**.
- Examples** Entering a single connection attribute with the **DISPLAY_CONNECTION_ATTRIBUTES** command produces the following type of display:

```
%DISCA ACA
```

```
Attention_Character_Action      : 2
```

You can also specify a list of attributes as shown in the following example:

```
%DISCA (ACA BKA IBS)
```

```
Attention_Character_Action      : 2
```

```
Break_Key_Action               : 0
```

```
Input_Block_Size               : 160
```

DISPLAY_CONNECTIONS (DISC)

Purpose Displays your terminal's existing CDCNET connections and identifies the current working connection. The display also names your terminal and the device interface (DI) system through which your CDCNET connections are managed. This information can be very useful to your site administrator or network operator when you contact them about a connection problem.

Format %DISPLAY_CONNECTIONS

- Remarks**
- The DISPLAY_CONNECTIONS command identifies your connections and equipment. You can use this command to recall connection names, to review how the network handles output from each connection, and to check your connection limit.
 - The display presents information about your working connection. Next, it lists all existing connections, including your working connection.
(\$NET may be the *working* connection, but is not listed as an *existing* one.)
 - The CONNECTION_STATUS line in the output display is useful to monitor a connection that you made to an unavailable service, with the WAIT parameter set to YES.

Examples The following command displays information about the current status of connections to CDCNET:

```
%DISC
```

Output from this command is formatted as follows:

```
DI System Name      : 080025100081, TDI_81
Terminal Name      : 5300000000,$CONSOLE_100081_5300000000
Working_Connection : EDIT
User_Connection_Limit : 4
Status_Action      : SEND
Connection_Name     : $A
Connection_Status   : PENDING(01)
Service_Name        : ABC
Output_Action       : HOLD(0)

Connection_Name     : EDIT
Connection_Status   : CONNECTED
Service_Name        : XYZ
Output_Action       : SEND
```

The first part of this display is composed of five lines that identify your working connection and supply additional information about network communications.

DI System Name

Identifies the device interface (DI) you are using. This line of the display has two parts: system identifier (080025100081) and its logical system name (TDI_81). The first is a unique network name. The second is an optional, site-specified name.

Both names identify the same components. They also appear in the CDCNET banner when you sign on. You should make a note of them in case you need to report communications problems.

Terminal Name

Displays the name that the network uses for your terminal (5300000000,\$CONSOLE_100081_5300000000). Like the DI system name, it is made up of two parts: the network name (5300000000) and the logical name (\$CONSOLE_100081_5300000000).

The network name is unique, and indicates how your terminal is connected to the network: LIM number (5), port (3), cluster address (0000), and device address (0000).

The site administrator can specify a logical name when your terminal device is configured on the network; otherwise, the network assigns a default logical name. A default logical name is composed of the following three parts:

- The first part (\$CONSOLE) identifies the type of terminal used.
- The second part (100081) is made up of the last six digits of the DI system identifier.
- The third part (5300000000) is the same as your terminal's network name.

Working Connection

Identifies the connection you are currently using (EDIT, in the example). This connection (unless it is \$NET) is also listed in the second part of the display as one of your existing connections.

User Connection Limit

Displays the number of simultaneous connections (4) the network administrator permits you to have in addition to \$NET.

Status Action

Reports the setting of the STATUS_ACTION terminal attribute for the working connection (SEND). Possible entries are DISCARD, HOLD, and SEND.

The second and subsequent parts of the display list your existing connections. Each part includes the connection, its service, and the OUTPUT_ACTION for that connection. In the example, you have two connections (\$A and EDIT).

Connection Name

Identifies the name either you or the network assigned this connection when it was created.

Connection Status

Reports the status of connections created. Possible values are CONNECTED, DISCONNECTED, and PENDING. The DISCONNECTED status identifies connections that have timed out or have disconnected but have output being held. PENDING is displayed when a connection to an unavailable service is made with WAIT parameter specified to YES.

Next, the network shows, in parentheses, how many users have been waiting for the service to become available. A value of 01 means you are the next user to get connected to the service when it becomes available. A value of 99 means 99 or more users are waiting for the service to become available.

Service Name

Identifies the service at the other end of the connection.

Output Action

Reports the last setting of STATUS_ACTION that you specified on a CREATE_CONNECTION or CHANGE_WORKING_CONNECTION command for each connection, except your working connection. The network uses SEND for the output action on the working connection. Possible entries for the other connections are DISCARD and HOLD. If the output action is HOLD, the network also gives the number of messages held, in parentheses.

DISPLAY_SERVICE (DISS)

Purpose Displays information about the set of services selected for display by the site administrator, including service availability. These are some of the service names that you can specify on a `CREATE_CONNECTION` command. The display shows service names, service status, and other information.

Format `%DISPLAY_SERVICE` or `DISPLAY_SERVICES`
SERVICE = service name or keyword
DISPLAY_OPTION = display option

Parameters *SERVICE (S)*

Identifies the service(s) about which you want information. If you specify more than one service for display, enclose the names in parentheses and separate them with spaces. If you omit this parameter, the network displays information about all of the services selected by the site administrator for display.

DISPLAY_OPTION (DO)

Specifies one of the following entries:

- | | |
|--------------|--|
| BRIEF | Displays status for each service name listed. |
| FULL | Displays status and additional information for each service name listed. |

Default is **FULL**.

Remarks The network assigns each service one of the following status options:

Option	Description
UP	Service is available.
DOWN	Service is not available.
BUSY	Service is available, but needed resources are currently in use. Try again later.
UNKNOWN	The network does not recognize the service name you specified. Either the site administrator has not selected the name for display, or you entered an incorrect name.

NOTE

Whenever a **CREATE_CONNECTION** command is entered for a given service (not including connections made using an alias), the network updates data used in creating the **DISPLAY_SERVICE** display for that service. The network also updates this data at intervals specified by your site administrator. This command provides accurate information only to the extent that service status changes have been updated in one of these two ways.

DISPLAY_SERVICE (DISS)

Examples The following command displays information in the brief format about services VE_001 and VE_002:

```
%DISS S=(VE_001 VE_002) DO=BRIEF

VE_001                               : UP
VE_002                               : UP
```

If you enter DISS without parameters, the network alphabetically lists all services that your site administrator specified for the display. The display is in full format, so it includes any special information your site administrator specified for the display, such as alternate names or troubleshooting messages. For example:

```
VE_001                               : UP
  Alternate title : RED.
VE_002                               : UP
  Alternate title : GREEN.
VE_003                               :DOWN
  Alternate titles : BLUE, NAOMI, LAB.
```

For each service, the first line displayed is the same as what would be displayed in the brief format. Any additional lines of display for a service are specified for display by the site administrator.

DISPLAY_TERMINAL_ATTRIBUTE (DISTA)

Purpose Displays your terminal's characteristics. The complete list is displayed if you do not list one or more attributes.

Format `%DISPLAY_TERMINAL_ATTRIBUTE`
DISPLAY_OPTION=terminal attribute or
TERMINAL_ATTRIBUTE=terminal attribute

Parameters *DISPLAY_OPTION (DO)* or *TERMINAL_ATTRIBUTE (TA)*
 Specifies a terminal attribute. See the terminal attribute descriptions in chapter 3.

Remarks The network displays your attributes in the order that you list names in the *DISPLAY_OPTIONS* parameter. If you do not specify any names, all attributes except *CONTROL_CODE_REPLACEMENT (CCR)* are listed alphabetically. *CCR* is displayed only when the command is entered with *DISPLAY_OPTION* set to *ALL* or *CCR*.

Examples The following example shows how you can display a selected list of attributes using the *DISPLAY_TERMINAL_ATTRIBUTE* command.

```
%DISTA (CRS CS LFS)
```

```
Carriage_Return_Sequence      :CR
Code_Set                       :ASCII
Line_Feed_Sequence            :LF
```

If you prefer, you can display one attribute at a time.

```
%DISTA CRS
```

```
Carriage_Return_Sequence      :CR
```

DO

DO

Purpose Executes a network procedure. (Refer to the CDCNET Configuration Guide for more information about network procedures.)

Format **%DO**
PROCEDURE_NAME=*procedure name*
PROCEDURE_TYPE=*procedure type*

Parameters **PROCEDURE_NAME (PN)**

Specifies the procedure name.

PROCEDURE_TYPE (PT)

Identifies the type of procedure.

TDP Specifies a terminal definition procedure.

TUP Specifies a terminal user procedure.

Default is TUP.

Remarks The site administrator might configure your network so that it automatically executes any procedure needed to access a service.

Examples The following command executes a terminal user procedure called **SERVIC1**:

```
%DO SERVIC1
```

REQUEST_NETWORK_OPERATOR (REQNO)

Purpose Sends a message from your terminal to the network operator.

Format `%REQUEST_NETWORK_OPERATOR
MESSAGE= string`

Parameters MESSAGE (M)

Specifies a 1- through 15-line message. Each line is enclosed in single quotes. If more than one line is to be sent, enclose the lines in parentheses and separate lines from each other with a space. You can use as many as 255 characters in the entire command.

Remarks

- When you come to the end of the physical line on your screen while entering the MESSAGE parameter, your terminal (or CDCNET) folds the line so that you can continue typing the message on the next line.
- CDCNET tells you when it sends your message. However, it does not tell you if it successfully delivered the message, or whether a network operator received the message. The network logs the message even if no network operator is connected to CDCNET when your message arrives.

Examples The following command sends three lines of a message to the network operator:

```
%REQNO M=('What is the new holiday schedule?' 'Will
the laser printer be available then?' 'When will the
overnight printing be completed?')
```

The network operator sees the following message:

```
What is the new holiday schedule?
Will the laser printer be available then?
When will the overnight printing be completed?
```

Displaying and Changing Terminal Attributes	3-1
Terminal Attributes and Protocols	3-2
Terminal Attributes and Input Editing Modes	3-3
Terminal Attribute Descriptions	3-4
ATTENTION_CHARACTER (AC)	3-5
BACKSPACE_CHARACTER (BC)	3-7
BACKSPACE_WINDOW (BW)	3-10
BEGIN_LINE_CHARACTER (BLC)	3-11
CANCEL_LINE_CHARACTER (CLC)	3-12
CARRIAGE_RETURN_DELAY (CRD)	3-14
CARRIAGE_RETURN_SEQUENCE (CRS)	3-16
CHARACTER_FLOW_CONTROL (CFC)	3-17
CODE_SET (CS)	3-21
CONTROL_CODE_REPLACEMENT (CCR)	3-25
ECHOPLEX (E)	3-27
END_LINE_CHARACTER (ELC)	3-29
END_LINE_POSITIONING (ELP)	3-30
END_OUTPUT_SEQUENCE (EOS)	3-32
END_PAGE_ACTION (EPA)	3-33
END_PARTIAL_CHARACTER (EPC)	3-35
END_PARTIAL_POSITIONING (EPP)	3-37
FOLD_LINE (FL)	3-39
FORM_FEED_DELAY (FFD)	3-41
FORM_FEED_SEQUENCE (FFS)	3-43
FUNCTION_KEY_CLASS (FKC)	3-44
HOLD_PAGE (HP)	3-45
HOLD_PAGE_OVER (HPO)	3-47
LINE_FEED_DELAY (LFD)	3-49
LINE_FEED_SEQUENCE (LFS)	3-51
NETWORK_COMMAND_CHARACTER (NCC)	3-52
PAGE_LENGTH (PL)	3-54
PAGE_WIDTH (PW)	3-56
PARITY (P)	3-58
RESPONSE_ACTION (RA)	3-61
STATUS_ACTION (SA)	3-62
TERMINAL_MODEL (TM)	3-63

Input and output from your terminal are handled by CDCNET according to a set of characteristics called terminal attributes. Every terminal connected to CDCNET has one set of terminal attributes. These attributes maintain a constant value across all connections.

Displaying and Changing Terminal Attributes

You can display and change your terminal attributes with the following two CDCNET commands:

DISPLAY_TERMINAL_ATTRIBUTE

CHANGE_TERMINAL_ATTRIBUTE

The DISPLAY_TERMINAL_ATTRIBUTE command lists all your terminal's attribute settings or just selected ones. Use this command to review the list or verify that a particular setting is correct.

Normally, you can access CDCNET, create a service connection, and begin using that service with the default terminal attribute settings. If your terminal or your processing require that you use different settings, use the CHANGE_TERMINAL_ATTRIBUTE command to make the changes.

The DISPLAY_TERMINAL_ATTRIBUTE command lists only those attributes supported by your terminal's protocol; the CHANGE_TERMINAL_ATTRIBUTE command can be used to change any terminal attribute, even if the attribute is not supported by the protocol. A nonsupported attribute cannot be displayed or validated by your terminal's protocol and has no effect on your terminal.

Both of these terminal attribute commands are described in chapter 2.

Terminal Attributes and Protocols

Figure 3-1 shows the default terminal attribute settings for the Asynchronous protocol. For the default terminal attribute settings for the 3270 Binary Synchronous Communications, X.PC, Mode 4, and 3270 SNA communications protocols see appendixes F, H, I, and J, respectively.

Attention_Character	:NUL
Backspace_Character	:BS
Backspace_Window	:PW
Begin_Line_Character	:NUL
Cancel_Line_Character	:CAN
Carriage_Return_Delay	:0
Carriage_Return_Sequence	:CR
Character_Flow_Control	:ON
Code_Set	:ASCII
Echoplex	:OFF
End_Line_Character	:CR
End_Line_Positioning	:LFS
End_Output_Sequence	:
End_Page_Action	:NONE
End_Partial_Character	:LF
End_Partial_Positioning	:CRS
Fold_Line	:ON
Form_Feed_Delay	:0
Form_Feed_Sequence	:FF
Function_Key_Class	:NONE
Hold_Page	:OFF
Hold_Page_Over	:ON
Line_Feed_Delay	:0
Line_Feed_Sequence	:LF
Network_Command_Character	:%
Page_Length	:24
Page_Width	:80
Parity	:EVEN
Response_Action	:SEND
Status_Action	:SEND
Terminal_Model	:NONE

Figure 3-1. Asynchronous Protocol Terminal Attribute Defaults

Terminal Attributes and Input Editing Modes

The terminal attributes that apply to your input and output processing depend upon whether the `INPUT_EDITING_MODE` connection attribute is set to `NORMAL` or `TRANSPARENT`. See table 3-1. Chapter 5 describes normal and transparent modes in more detail.

Table 3-1. Terminal Attributes and Input Editing Modes

Terminal Attribute	Normal	Transparent
Attention_Character	I	I
Backspace_Character	I	
Backspace_Window	I	
Begin_Line_Character	I	
Cancel_Line_Character	I	
Carriage_Return_Delay	I/O	
Carriage_Return_Sequence	I/O	I
Character_Flow_Control	I/O	I/O
Code_Set	I/O	
Control_Code_Replacement	O	O
Echoplex	I	I
End_Line_Character	I	
End_Line_Positioning	I	
End_Output_Sequence	O	O
End_Page_Action	O	
End_Partial_Character	I	
End_Partial_Positioning	I	
Fold_Line	O	
Form_Feed_Delay	O	
Form_Feed_Sequence	O	
Function_Key_Class		I
Hold_Page	O	
Hold_Page_Over	O	
Line_Feed_Delay	I/O	
Line_Feed_Sequence	I/O	I
Network_Command_Character	I	
Page_Length	O	

(Continued)

Table 3-1. Terminal Attributes and Input Editing Modes
(Continued)

Terminal Attribute	Normal	Transparent
Page_Width	I/O	
Parity	I/O	I/O
Response_Action	O	
Status_Action	O	
Terminal_Model ¹		

Attributes marked I apply to input. Those marked O apply to output.

1. This attribute does not affect input or output processing.

Terminal Attribute Descriptions

The following pages describe the terminal attributes provided by CDCNET for use with the Asynchronous protocol. Refer to appendixes F through I for terminal attribute support for other protocols.

The individual attribute descriptions contain purpose, format, remarks, and examples, when applicable. Each description begins with an attribute name followed by its abbreviation enclosed in parentheses. The format description lists the values that you can assign a specified terminal attribute. It also provides an explanation of each value and its abbreviation.

ATTENTION_CHARACTER (AC)

Purpose Identifies the key you press to perform the action specified by `ATTENTION_CHARACTER_ACTION`. (See chapter 4 for a description of the `ATTENTION_CHARACTER_ACTION` connection attribute and chapter 6 for more information on interrupts.)

Format `ATTENTION_CHARACTER=character or NUL`

character Specifies an ASCII character. (See appendix B for detailed information about defining characters.)

NUL Specifies that no character is recognized as an attention character.

The default is NUL.

- Remarks**
- The `ATTENTION_CHARACTER` can serve as a substitute for the `BREAK` key when your terminal does not have a `BREAK` key.
 - The specified attention character action is executed whenever the character is received from your terminal; the character does not have to occur at the beginning of a line.
 - The terminal attribute `ATTENTION_CHARACTER` is interpreted as data when the connection attribute `ATTENTION_CHARACTER_ENABLE=NO`.
 - You can perform different actions with the `BREAK` key and `ATTENTION_CHARACTER` if you already have a `BREAK` key. You define these actions by specifying different values for the `ATTENTION_CHARACTER_ACTION` and `BREAK_KEY_ACTION` connection attributes.
 - `CDCNET` recognizes the attention character irrespective of the parity bit setting and the `PARITY` terminal attribute setting.
 - When `CHARACTER_FLOW_CONTROL` (described later in this chapter) is `ON`, `CDCNET` treats the `ATTENTION_CHARACTER` as an implied `X-ON`.

ATTENTION_CHARACTER (AC)

Examples Suppose you want a quick way to execute a level 2 user interrupt. You can create one by setting your `ATTENTION_CHARACTER_ACTION` connection attribute to 2, and then setting your `ATTENTION_CHARACTER` terminal attribute. For example, the following command sets your attention character to ASCII DC4, which can be entered by holding down the CONTROL key and pressing T.

```
%CHATA AC=20
```

After this command executes, CDCNET recognizes received values of 14(16) and 94(16) as the attention character.

BACKSPACE_CHARACTER (BC)

- Purpose** Identifies the key you press to backspace over (delete) the last character(s) you entered on your current line.
- Format** *BACKSPACE_CHARACTER=character*
- character Specifies an ASCII character. (See appendix B for detailed information about defining characters.)

The default is BS.

- Remarks**
- You can only delete characters with a BACKSPACE key when these connection attribute settings apply to your connection.


```
INPUT_EDITING_MODE=NORMAL
STORE_BACKSPACE_CHARACTER=OFF
```

 With these settings, the character you entered by mistake and the BACKSPACE_CHARACTER are not sent to your service as input.
 - If the backspace character you specify for CDCNET does not match the terminal's backspace character, you cannot overstrike on the screen or page: what you see is not what your service receives.

If the terminal's backspace character and BACKSPACE_CHARACTER are the same, the service receives what you see.
 - You can backspace until you encounter a backspacing boundary, from which no further backspacing is allowed. This boundary is either the beginning of the current input, or the character position in the current input equal to the BACKSPACE_WINDOW, whichever comes first. The boundary moves as each BACKSPACE_WINDOW number of characters are input.
 - You cannot backspace over characters that forward data: END_PARTIAL_CHARACTER (when PARTIAL_CHARACTER_FORWARDING is set to ON) and END_LINE_CHARACTER.

BACKSPACE_CHARACTER (BC)

Examples If you enter the following characters and then realize you have typed Q instead of C, you can correct the mistake.

ABQ

Press the BACKSPACE key (often a reverse arrow) and enter C. As with all entries, press the RETURN key (or equivalent) to send your entry to the service. If your terminal's backspace character is the same as the BACKSPACE_CHARACTER, you see the following on your screen.

ABC

As a result of your entry, CDCNET sends the following characters to your service.

ABC

Now change your BACKSPACE_CHARACTER (CDCNET) to an exclamation point (!) so that it is different from your terminal's backspace character.

```
%CHATA BC='!'
```

Reenter the first example using your newly defined BACKSPACE key. To do this, retype the original characters, ABQ, backspace using the exclamation point, and then enter a C. The following series of characters, including the new BACKSPACE_CHARACTER, appears on your screen.

ABQ!C

The difference between what is shown on your screen in these examples, the BACKSPACE_CHARACTER, does not affect the actual characters your service receives.

ABC

In both examples, CDCNET edits your input and removes the BACKSPACE_CHARACTER and the preceding character before it forwards the input.

A third example illustrates how far you can backspace. Suppose that your terminal has a `PAGE_WIDTH` of 80 characters and a `BACKSPACE_WINDOW` of 120 characters. You can enter up to 120 characters of input and backspace over any of them. Once 120 characters are input, you cannot backspace past the 120th character. In this example, by setting `BACKSPACE_WINDOW` greater than `PAGE_WIDTH`, input can be backspaced over past a `PAGE_WIDTH` boundary.

A fourth example is with a `PAGE_WIDTH` of 80 characters and a `BACKSPACE_WINDOW` of 30 characters. You can enter up to 30 characters and backspace over any of them. Once 30 characters are input, you cannot backspace past the 30th character. You can continue to input up to 30 more characters and backspace over them. In this example, the portion of your input over which you can backspace changes as each `BACKSPACE_WINDOW` number of characters are input.

BACKSPACE_WINDOW (BW)

Purpose Defines the maximum number of characters on the current input line that can be backspaced over using the BACKSPACE_CHARACTER (BC). That is, you can backspace across an input line until you encounter a backspacing boundary, which is either the beginning of the current input line, or the character position specified as the BACKSPACE_WINDOW, whichever comes first.

Format *BACKSPACE_WINDOW = integer*

integer Specifies the character position of the backspace boundary. You can use any integer from 10 through 255. If you enter 0, the network uses the value of the PAGE_WIDTH terminal attribute (if the PAGE_WIDTH attribute is 0, the network uses 255).

The default is PW.

Remarks If CDCNET is echoing your entries and you try to backspace past the BACKSPACE_WINDOW, CDCNET does not move your cursor back any further, because you have already "edited" the specified maximum number of characters.

If your terminal is echoing the entries, you might see the cursor move past the BACKSPACE_WINDOW boundary, but CDCNET ignores the additional backspacing.

Examples See the preceding BACKSPACE_CHARACTER description for examples of using BACKSPACE_WINDOW.

BEGIN_LINE_CHARACTER (BLC)

Purpose Identifies a character that your terminal automatically transmits at the beginning of every input line. When CDCNET receives this character, it discards the character.

Format *BEGIN_LINE_CHARACTER = character*

character Specifies an ASCII character. (See appendix B for detailed information about defining characters.)

The default is NUL.

- Remarks**
- Some terminals automatically send a special character after each END_LINE_CHARACTER and before any additional input.
 - If you do not want your service to receive this special character, you can have CDCNET discard it before forwarding input data to your service. Specifying the character as the BEGIN_LINE_CHARACTER ensures that CDCNET discards it.

Examples If you are working at a terminal that allows you to edit a screen of information locally before sending it to CDCNET, you can change BEGIN_LINE_CHARACTER to STX.

```
%CHATA BLC=2
```

Defining BEGIN_LINE_CHARACTER, as a special character that precedes each screen, enables you to edit an entire screen before forwarding any information. Since CDCNET removes STX from your input, it does not affect communications between CDCNET and your service.

CANCEL_LINE_CHARACTER (CLC)

Purpose Identifies the key you press to cancel the line you are currently typing.

Format `CANCEL_LINE_CHARACTER=character or NUL`

character Specifies an ASCII character. (See appendix B for detailed information about defining characters.)

NUL Specifies that no character cancels a line.

The default is CAN.

Remarks

- Cancelling a line involves only the line you are currently entering. It does not affect output being displayed or printed at your terminal.
- In order to correct a mistake you have just made, press these two keys: the CANCEL_LINE_CHARACTER, followed by the END_LINE_CHARACTER. CDCNET then forwards both the line you are removing and a cancel indication. Your service defines the action taken by the indication.

CDCNET also sends your terminal the following message.

Input cancelled.

Examples When you use the following attribute settings, you may want to change your CANCEL_LINE_CHARACTER so that your terminal echoes the CANCEL_LINE_CHARACTER on the screen.

```
CANCEL_LINE_CHARACTER=CAN
END_LINE_CHARACTER=CR
```

To do this, change the CANCEL_LINE_CHARACTER to an ampersand (&).

```
%CHATA CLC='&'
```

Then enter some data to test your new CANCEL_LINE_CHARACTER.

```
ABCDE
```

Cancel the incomplete line by entering an ampersand and then press the RETURN key.

ABCDE&

The network forwards the line with a cancel indication to your service. It also sends you this message:

Input cancelled.

However, if you mistype and enter an ampersand followed by a *space* and then press the RETURN key, the line is forwarded without the cancel indication. When the CANCEL_LINE_CHARACTER is followed by a space and not an END_LINE_CHARACTER, CDCNET treats the entire line, including the ampersand, as (uncancelled) data. As a result, the network forwards it to your service.

CARRIAGE_RETURN_DELAY (CRD)

Purpose Increases or decreases idle time after a CARRIAGE_RETURN_SEQUENCE. (During this time, the network sends your terminal NUL characters.)

If information is sent to your terminal faster than it can position the carriage (or cursor), you can avoid losing data by increasing the idle time with CARRIAGE_RETURN_DELAY. This additional time allows your terminal and any slave printer to perform a return before more output data is transmitted. (See chapter 5 and the description of the CARRIAGE_RETURN_SEQUENCE terminal attribute later in this chapter for more information.)

NOTE

Carriage return delays are typically used for older, nonbuffered devices that do not support X-ON/X-OFF flow control.

Format CARRIAGE_RETURN_DELAY = *integer*

integer Specifies the idle time in number of milliseconds. You can use any integer from 0 through 1000.

The default is 0.

Remarks

- Whenever any of the following occurs, CDCNET inserts enough NUL characters in the output to fill the milliseconds you specify with CARRIAGE_RETURN_DELAY:
 - Output from your service contains a character (such as a format effector or CR) that the network converts to the CARRIAGE_RETURN_SEQUENCE.
 - PAGE_WIDTH is reached; the NUL characters for the delay are sent whether it is CDCNET or your terminal that folds the line.

- The network performs END_LINE_POSITIONING or END_PARTIAL_POSITIONING and, as a result, sends your terminal a CARRIAGE_RETURN_SEQUENCE.
 - o A combination of factors determines the delay you enter for the CARRIAGE_RETURN_DELAY. The amount of time needed to reposition the carriage (or cursor) depends upon the terminal's page width, the speed at which the device moves the carriage, and line speed.
- | Factor | Delay Time |
|--|------------|
| Page width increases. | Increases. |
| Device performs cursor positioning faster. | Decreases. |
| Line speed increases. | Decreases. |
- o Certain terminals, such as the Lear Siegler ADM3A and ADM5, do not ignore NUL characters. In these cases, you should set CARRIAGE_RETURN_DELAY to 0.
 - o Using both the CARRIAGE_RETURN_DELAY and LINE_FEED_DELAY provides a maximum combined delay of 2 seconds for repositioning, if needed.

Examples

Slave printers that repeat information exchanged by CDCNET and a terminal are often attached to microcomputers. In this situation, you can avoid losing data on your printed listing by changing the CARRIAGE_RETURN_DELAY.

```
%CHATA CRD=200
```

Specifying a delay of one-fifth second provides additional time for repositioning the carriage. During the time CDCNET is inserting NUL characters after each CARRIAGE_RETURN_SEQUENCE, your printer is repositioning its carriage.

CARRIAGE_RETURN_SEQUENCE (CRS)

Purpose Defines the sequence of characters that positions the cursor or carriage at the beginning of a line. (See the descriptions of the END_LINE_POSITIONING and END_PARTIAL_POSITIONING terminal attributes later in this chapter for more information. Also see chapter 5.)

Format *CARRIAGE_RETURN_SEQUENCE = sequence*

sequence Defines a sequence of 0 through 2 characters. (See appendix B for detailed information about defining characters.)

The default is CR.

- Remarks**
- CDCNET sends a CARRIAGE_RETURN_SEQUENCE to your terminal whenever a CR (ASCII character) appears in your data.
 - When the service uses a format effector that requires a return, CDCNET substitutes the sequence defined by CARRIAGE_RETURN_SEQUENCE.
 - CDCNET inserts a CARRIAGE_RETURN_SEQUENCE when PAGE_WIDTH is reached and either CDCNET or your terminal folds the line (depending upon the setting of FOLD_LINE).

Examples If your terminal automatically performs both a line feed and carriage return, you can set the CARRIAGE_RETURN_SEQUENCE to NUL to avoid duplication. To do so, enter the following CHANGE_TERMINAL_ATTRIBUTE command.

```
%CHATA CRS=''
```

CHARACTER_FLOW_CONTROL (CFC)

Purpose Specifies whether your terminal and CDCNET control the flow of data using X-ON/X-OFF protocol (DC1 and DC3 characters).

You can lose data if CHARACTER_FLOW_CONTROL is set to OFF and if your terminal cannot operate at high speeds. (See chapter 5 for more information.)

Format *CHARACTER_FLOW_CONTROL=ON*
CHARACTER_FLOW_CONTROL=OFF
CHARACTER_FLOW_CONTROL=INPUT
CHARACTER_FLOW_CONTROL=OUTPUT

ON Uses the X-ON/X-OFF protocol to regulate both input data from your terminal and output data to your terminal.

OFF Does not use the X-ON/X-OFF protocol to regulate the flow of data to/from your terminal.

INPUT Uses the X-ON/X-OFF protocol to regulate the flow of input data from your terminal.

OUTPUT Uses the X-ON/X-OFF protocol to regulate the flow of output data to your terminal.

The default is ON.

CHARACTER_FLOW_CONTROL (CFC)

- Remarks**
- The X-ON/X-OFF protocol controls movement of both input and output data with ASCII characters.

<u>Protocol</u>	<u>ASCII Mnemonic</u>	<u>Control Character</u>	<u>Meaning</u>
X-ON	DC1	Q	Send more data.
X-OFF	DC3	S	Stop sending data.

- To use CHARACTER_FLOW_CONTROL effectively, you must know how your terminal handles flow control.
If your terminal supports automatic flow control, it may use the X-ON/X-OFF protocol, EIA flow control, or both. Most terminals support the X-ON/X-OFF protocol.
- If your site administrator has defined the communication line you are using with EIA flow control turned on, CDCNET uses EIA flow control to control your input regardless of the CFC setting.
- When CHARACTER_FLOW_CONTROL is ON, CDCNET does the following:
 - Recognizes DC1 and DC3 characters as flow control from your terminal, starts and stops sending output data accordingly, and discards the DC1 and DC3 characters.
 - Sends DC1 and DC3 characters to your terminal to tell it to start and stop sending input data.
- When CHARACTER_FLOW_CONTROL is OFF, CDCNET does the following:
 - Forwards any DC1 and DC3 characters that it receives as input data to the service.
 - Does not send DC1 and DC3 characters to your terminal for flow control.

- When CHARACTER_FLOW_CONTROL is ON and the network has sent the terminal a DC3 character to stop the flow of input, the network is unable to handle more characters. The network continues to accept a line-speed dependent number of input characters after sending the DC3 character to the terminal. When this number is reached, each subsequent character that the terminal sends the network is discarded and a BEL character is sent to the terminal instead.
- When CFC=ON, CDCNET recognizes received values 11(16) and 91(16) as X-ON signals, and 13(16) and 93(16) as X-OFF signals. Therefore, CDCNET recognizes X-ON and X-OFF characters regardless of the parity bit setting and the PARITY terminal attribute setting.
- When CFC=ON, CDCNET transmits X-ON and X-OFF characters with the parity bit set as specified by the PARITY terminal attribute setting.
- If the service sends DC1 or DC3 characters to your terminal, CDCNET does not detect them and does not edit them out. The effect of the service sending DC1 or DC3 characters is terminal dependent.
- When CHARACTER_FLOW_CONTROL is ON, the DC1 and DC3 characters that the network generates to regulate output are based on the PARITY setting. If this setting does not match the terminal's setting, some terminals such as the CDC 721 ignore DC1 and DC3 characters.

If this happens, it may appear that the network has not changed the CHARACTER_FLOW_CONTROL setting. Instead, CHARACTER_FLOW_CONTROL seems to remain either ON or OFF. This problem is most likely to occur when you are using automatic recognition, and the terminal's setting is not even or odd. If it is none, change PARITY to NONE. If the terminal's setting is different, experiment with various PARITY settings to determine what works best for your terminal.
- When CHARACTER_FLOW_CONTROL is ON, the ATTENTION_CHARACTER and BREAK key function implicitly as X-ON.

CHARACTER_FLOW_CONTROL (CFC)

Examples When you use a file transfer protocol, such as XMODEM, it disables flow control during a file transfer. The protocol accomplishes this internally with a terminal redefinition command. You can accomplish the same by changing CHARACTER_FLOW_CONTROL to OFF via the following command.

```
%CHATA CFC=OFF
```

Some file transfer protocols do not use X-ON/X-OFF, permitting you to transfer DC1 and DC3 as data within a file.

CODE_SET (CS)

Purpose Identifies the coded character set that your terminal uses (usually ASCII).

If you receive garbled (unreadable) messages when you try to access the network, the communication line that connects your terminal to the computer site probably requires a different coded character set (or parity setting). At this point, you have two choices:

1. Call your site administrator to determine your terminal's proper setting. Then enter a `CHANGE_TERMINAL_ATTRIBUTE` command with your terminal's setting for `CODE_SET` (or `PARITY`).
2. Turn off your terminal and consult your terminal documentation to verify the setting.

If necessary, reset your terminal switch to match the characteristics of your communication line.

Format

```

CODE_SET=ASCII
CODE_SET=ASCII48
CODE_SET=ASCII64
CODE_SET=ASCII95
CODE_SET=ASCII128
CODE_SET=ASCII256
CODE_SET=BPAPL
CODE_SET=EBCDIC
CODE_SET=TPAPL
CODE_SET=name

```

ASCII Uses the 7-bit ASCII-coded character set. ASCII-coded character set is identical to the ASCII128-coded character set.

ASCII48 Uses a translation table to map the 7-bit ASCII-coded character set to ASCII48. See CDCNET Configuration Guide for the translation table.

ASCII64 Uses a translation table to map the 7-bit ASCII-coded character set to ASCII64. See CDCNET Configuration Guide for the translation table.

CODE_SET (CS)

ASCII95	Uses a translation table to map the 7-bit ASCII-coded character set to ASCII95. See CDCNET Configuration Guide for the translation table.
ASCII128	Uses the 7-bit ASCII-coded character set. This is identical to the ASCII-coded character set.
ASCII256	Uses the 8-bit ASCII-coded character set.
BPAPL	Uses the bit-pairing ASCII-coded character set with APL print.
EBCDIC	Uses the 8-bit EBCDIC-coded character set.
TPAPL	Uses the typewriter-pairing ASCII-coded character set with APL print.
name	Uses the name of a site-defined code set.

The default is ASCII.

- Remarks**
- The following table shows how the CODE_SET attribute affects your terminal's input and/or output. This table gives information about only interactive input and output. For information about batch input and output, see the CDCNET Site Configuration Guide.

<u>Input and Output</u>	<u>Output Only</u>
ASCII 128	ASCII 48 ¹
ASCII 256	ASCII 64 ¹
BAPL	ASCII 95 ¹
EBCDIC	Site-defined code sets ²
TPAPL	Site-defined code sets ²

- Most terminals operate with ASCII; however, if you need to work with APL and if your terminal handles APL, you can switch to an APL character set. Depending on how your terminal attributes are set and which ones are relevant to your APL work, you can use the `ACTIVATE_AUTO_RECOGNITION` or `CHANGE_TERMINAL_ATTRIBUTE` command.
- Your site may have defined its own code set. Call your site administrator for the code set name. See CDCNET Site Configuration Guide for information on how to define a code set for your site.

1. The associated input code-set for these is ASCII 128.

2. The associated input code-set for these depends on the terminal's protocol. For example, the associated input code-set for a 3270 terminal is EBCDIC.

CODE_SET (CS)

Examples Suppose you have a Bubble APL terminal that you normally use with the coded character set switch on ASCII. To use the NOS APL interpreter, you need to change the NETWORK_COMMAND_CHARACTER and ATTENTION_CHARACTER as well as this setting and CODE_SET.

1. Enter the command:

```
%CHATA NCC=ESC AC=DC4 CS=TPAPL
```

2. Set your terminal's switch on APL to select the typewriter-pairing ASCII coded character set with APL print.

When you have completed your APL work and want to use ASCII again, repeat the steps.

1. Enter the command:

```
ESC CHATA NCC=% AC=NUL CS=ASCII
```

2. Set your terminal's switch on ASCII.

In the following example, a site-defined code set named ALPHALOW is being specified as a value for the CODE_SET parameter. ALPHALOW translates all uppercase ASCII alpha characters to lowercase alpha characters.

```
%CHATA CS=ALPHALOW
```

CONTROL_CODE_REPLACEMENT (CCR)

Purpose Specifies a list of control and replacement code pairs.

Format *CONTROL_CODE_REPLACEMENT=list*

list Defines a list of 1 through 64 control code and/or replacement code pairs.

Remarks

- The first element of each pair contains a range of one or more control codes that are not to be transmitted to the terminal. The second element of the pair is optional and specifies the replacement code which is to be transmitted to the terminal instead of the specified control code(s). When the second element is omitted, the control code is discarded and no replacement code is transmitted.

The acceptable values for the first element of this pair are code values in the ranges 0 through 31 and 128 through 159. The permitted value for the second element is any value in the range 0 through 255.

- The CCR attribute affects both transparent and nontransparent output.
- Replacement codes apply only to output received from the connected service and not to output generated by CDCNET, such as `LINE_FEED_SEQUENCE` characters and `END_OUTPUT_SEQUENCE` characters.
- Replacement code cannot be applied to the backspace (BS) control character on terminals using asynchronous protocol.
- The `DISPLAY_TERMINAL_ATTRIBUTE (DISTA)` command displays the value of the terminal attribute `CONTROL_CODE_REPLACEMENT` only when specifically selected by the `DO=CCR` or `DO=ALL` parameter values of the `DISTA` command. (See `DISPLAY_TERMINAL_ATTRIBUTE` command description in chapter 2 for more information.)

CONTROL_CODE_REPLACEMENT (CCR)

Examples In the following command, BEL code is discarded from the output and codes SOH through ACK are replaced by SP codes.

```
%CHATA CCR=( BEL, (SOH..ACK, SP))
```

The following command is rejected because it contains BEL as the first element of one list and the second element of another list.

```
%CHATA CCR=( BEL, (FS,BEL))
```

No attributes changed. Conflict in the use of control code BEL.

ECHOPLEX (E)

Purpose Specifies whether information you enter from your keyboard is sent back to your terminal by the network.

Format *ECHOPLEX=ON*
ECHOPLEX=OFF

ON Displays input at terminal. This setting is overridden by the connection attribute setting *ECHO_ENABLE=NO*. (See chapter 4 for a description of the *ECHO_ENABLE* connection attribute.)

OFF Does not display input at terminal.

The default is **OFF**.

- Remarks**
- When you enter data at your terminal, the terminal, a modem, CDCNET, or the service echoes it back to you. That is, data is displayed or printed so that you can see your entries.
 - If CDCNET or the service echoes your entries instead of your terminal or modem, you may notice a short pause between pressing a key and seeing the character appear on the screen.
 - You can control whether or not your terminal echoes if it has a duplex switch. Setting the switch to *HALF* means the terminal echoes; *FULL* means it does not. How you set *ECHOPLEX* and the terminal duplex switch controls echoing. Specifying these settings affects the number of times an entry is echoed.

Terminal**Setting****E = ON****E = OFF**

Full-duplex

Entry is
echoed once.

Entry is not echoed.

Half-duplex

Entry is
echoed twice.

Entry is echoed once.

- You can use character echoing by CDCNET to verify that the network is receiving your data correctly. To do this, put your terminal in full-duplex and set ECHOPLEX to ON.
- When ECHOPLEX is ON, CDCNET echoes all the characters you enter with a few exceptions:
 - If CHARACTER_FLOW_CONTROL is also ON, CDCNET does not echo DC1 and DC3 characters.
 - If connection attribute STORE_BACKSPACE_CHARACTER is OFF, CDCNET echoes BACKSPACE_CHARACTER entries until it encounters a backspacing boundary. A backspacing boundary is defined as either the beginning of the current input line, or the number of characters specified for the BACKSPACE_WINDOW terminal attribute, whichever comes first.

If ECHOPLEX is OFF, you can backspace your cursor across a backspacing boundary. However, the additional backspacing does not affect data past the backspacing boundary.

- If CDCNET echoes, what you see on your screen is what is sent to the service. However, this is not necessarily true when the terminal echoes. If your terminal's backspace character is different than the one defined for BACKSPACE_CHARACTER, pressing the BACKSPACE key on your terminal moves the cursor, but does not affect the data being forwarded to your service.

Examples

Suppose a Zenith Z29 terminal set up for full-duplex operation does not perform character echoing, and nothing you enter at the keyboard appears on the screen.

To remedy this situation, change ECHOPLEX to ON.

```
%CHATA E=ON
```

END_LINE_CHARACTER (ELC)

- Purpose** Identifies the key you press to forward data you have entered for processing. This key is labeled with various symbols (for example, ENTER, NEXT, ↵, and RETURN). In this manual, the RETURN key is used to mean any key that performs this carriage-return function.
- Pressing the key transmits the character code that causes CDCNET to end and forward a complete transmission to the service. (The END_LINE_CHARACTER is not treated as data.) Your service normally acts on this input. END_LINE_CHARACTER also causes CDCNET to do END_LINE_POSITIONING. (See chapter 5 for more information.)
- Format** *END_LINE_CHARACTER=character*
- character** Specifies an ASCII character. (See appendix B for detailed information about defining characters.)
- The default is CR.
- Remarks** CDCNET does END_LINE_POSITIONING when it encounters an END_LINE_CHARACTER in your input by sending your terminal a sequence. This produces appropriate cursor positioning for the next line of data.
- Examples** You can define END_LINE_CHARACTER as a different key than the terminal's RETURN key. For example, if your terminal has a key labeled EOT, you might want to use it. Change the ELC character with the following command:

```
%CHATA ELC=4
```


END_LINE_POSITIONING (ELP)

Purpose Defines the character string that the network sends to your terminal to perform cursor positioning when you have entered a complete transmission. (The network sends this string after receiving an END_LINE_CHARACTER. See chapter 5 for more information.)

Format *END_LINE_POSITIONING=CRS*
END_LINE_POSITIONING=LFS
END_LINE_POSITIONING=CRSLFS
END_LINE_POSITIONING=NONE

CRS Uses the setting you specified with CARRIAGE_RETURN_SEQUENCE.

LFS Uses the setting you specified with LINE_FEED_SEQUENCE.

CRSLFS Uses the settings you specified with both CARRIAGE_RETURN_SEQUENCE and LINE_FEED_SEQUENCE.

NONE Does not use any character string.

The default is LFS.

- Remarks**
- If your terminal automatically repositions the cursor where you want it after an END_LINE_CHARACTER, END_LINE_POSITIONING is NONE.
 - If your terminal does not position the cursor where you want it after an END_LINE_CHARACTER, reset END_LINE_POSITIONING. Select the setting that describes what positioning the network should do when it receives an END_LINE_CHARACTER in your input.

Examples Suppose you access your service by going through CDCNET and a public data network. The latter performs a line feed when you press the RETURN key. Since CDCNET is using the following attribute setting, it also performs a line feed after each return.

```
END_LINE_POSITIONING=LFS
```

As a result, your data is double-spaced. To remove the extra line, enter the following command:

```
%CHATA ELP=NONE
```

Now your data is single-spaced; only the public data network issues a line feed.

END_OUTPUT_SEQUENCE (EOS)

END_OUTPUT_SEQUENCE (EOS)

Purpose Defines the sequence of characters the network appends to each complete line of output from the service. Some microcomputers look for this prompting string after receiving output as a signal to begin sending input.

Format *END_OUTPUT_SEQUENCE=sequence*

sequence Defines a sequence of 0 through 4 characters. (See appendix B for detailed information about defining characters.)

Remarks When the service indicates that its output has ended, CDCNET sends additional characters to your terminal before expecting input. These characters are defined by END_OUTPUT_SEQUENCE.

Examples You can define END_OUTPUT_SEQUENCE so that you always know when your output ends. To turn END_OUTPUT_SEQUENCE into a prompt, enter the following CHANGE_TERMINAL_ATTRIBUTE command:

```
%CHATA EOS=7
```

With your END_OUTPUT_SEQUENCE set to BEL, your terminal's bell rings after each command has executed.

END_PAGE_ACTION (EPA)

Purpose Specifies whether the network divides your output into pages. What the network does when the specified PAGE_LENGTH (minus a line) has been displayed depends upon the setting of this attribute. (See the descriptions of the FORM_FEED_SEQUENCE, HOLD_PAGE, and PAGE_LENGTH terminal attributes later in this chapter for additional information. See also chapter 5.)

Format *END_PAGE_ACTION=FFS*
END_PAGE_ACTION=NONE

FFS Uses the setting you specified for FORM_FEED_SEQUENCE.

NONE Does not take any action.

The default is NONE.

Remarks

- CDCNET performs an END_PAGE_ACTION after the network has displayed PAGE_LENGTH minus one line of data. The last line is reserved for the END_PAGE_ACTION and related information. If PAGE_LENGTH is infinite (PAGE_LENGTH=0), CDCNET does not use END_PAGE_ACTION.

- If you set the following attributes, HOLD_PAGE and the <OVER> prompt occur before the END_PAGE_ACTION.

- You receive page length minus one physical line, whether or not HOLD_PAGE=ON, because a line is needed for the <OVER> prompt and the page turn signal sent to your terminal.

HOLD_PAGE=ON
 HOLD_PAGE_OVER=ON
 END_PAGE_ACTION=FFS

END_PAGE_ACTION (EPA)

Examples Suppose your terminal does not support a paging function. That is, it does not wrap when data fills the screen. You can correct this situation by changing END_PAGE_ACTION to FFS.

```
%CHATA EPA=FFS
```

Each time output reaches PAGE_LENGTH, this entry causes the network to perform the FORM_FEED_SEQUENCE. If you have set this attribute to an appropriate value, the network clears the screen and starts writing again at the top.

END_PARTIAL_CHARACTER (EPC)

Purpose Specifies the character that causes CDCNET to end and forward a partial transmission to the service (and does not treat the END_PARTIAL_CHARACTER as data). A *service usually does not act on this data until it receives a complete transmission.* END_PARTIAL_CHARACTER also causes CDCNET to do END_PARTIAL_POSITIONING. (See chapter 5 for more information and chapter 4 for a description of the PARTIAL_CHARACTER_FORWARDING connection attribute.)

Format *END_PARTIAL_CHARACTER=character or NUL*

character Specifies an ASCII character. (See appendix B for detailed information about defining characters.)

NUL Causes the network to deactivate the transmission of partial data.

The default is LF.

Remarks

- The network recognizes this attribute only when INPUT_EDITING_MODE=NORMAL.
- When the following attribute setting applies to your connection, CDCNET uses the END_PARTIAL_CHARACTER to forward input.

PARTIAL_CHARACTER_FORWARDING=ON

If it is OFF, CDCNET does not forward partial transmissions until it receives an END_LINE_CHARACTER.

- When CDCNET encounters an END_PARTIAL_CHARACTER in your input (and PARTIAL_CHARACTER_FORWARDING is ON), it does END_PARTIAL_POSITIONING by sending your terminal a sequence. This produces appropriate cursor positioning for the next line of data.

END_PARTIAL_CHARACTER (EPC)

- When CDCNET encounters an END_PARTIAL_CHARACTER in your input following an END_LINE_CHARACTER (and INPUT_EDITING_MODE=NORMAL), it discards the EPC character that immediately *precedes* or *follows* the ELC.
- Deactivate this terminal attribute for a specific connection with the connection attribute PARTIAL_CHARACTER_FORWARDING.
- Normally you change the END_PARTIAL_CHARACTER to avoid conflict with a service use of the character or to use the current character as data.

Examples If, for some reason, you need to change END_PARTIAL_CHARACTER, enter a CHANGE_TERMINAL_ATTRIBUTE command at your terminal.

```
%CHATA EPC=NUL
```

END_PARTIAL_POSITIONING (EPP)

Purpose Defines the character string the network sends to your terminal to perform cursor positioning after you enter the character defined by the `END_PARTIAL_CHARACTER` terminal attribute. The network sends this sequence after receiving an `END_PARTIAL_CHARACTER`. (See chapter 5 for more information.)

Format *END_PARTIAL_POSITIONING=CRS*
END_PARTIAL_POSITIONING=LFS
END_PARTIAL_POSITIONING=CRSLFS
END_PARTIAL_POSITIONING=NONE

CRS Uses the setting you specified with `CARRIAGE_RETURN_SEQUENCE`.

LFS Uses the setting you specified with `LINE_FEED_SEQUENCE`.

CRSLFS Uses the settings you specified with both `CARRIAGE_RETURN_SEQUENCE` and `LINE_FEED_SEQUENCE`.

NONE Does not use any character string.

The default is `CRS`.

- Remarks**
- If your terminal automatically repositions the cursor where you want it after an `END_PARTIAL_CHARACTER`, you may want `END_PARTIAL_POSITIONING` set to `NONE`.
 - If your terminal does not position the cursor where you want it after an `END_PARTIAL_CHARACTER`, reset `END_PARTIAL_POSITIONING`. Select the setting that describes what you want the network to do when it receives an `END_PARTIAL_CHARACTER` in your input.

END_PARTIAL_POSITIONING (EPP)

Examples If your terminal automatically performs both a line feed and return, you can set the END_PARTIAL_POSITIONING to NONE to avoid duplication. To do so, enter the following CHANGE_TERMINAL_ATTRIBUTE command.

```
%EPP=NONE
```

FOLD_LINE (FL)

Purpose Specifies whether the network folds output lines that exceed the PAGE_WIDTH setting.

When you set this attribute to ON, the portion of the line that exceeds PAGE_WIDTH is continued (displayed or printed) on the next line. (See the descriptions of the CARRIAGE_RETURN_SEQUENCE terminal attribute earlier in this chapter, and the LINE_FEED_SEQUENCE and the PAGE_WIDTH terminal attributes later in this chapter for information on related settings. Also see chapter 5.)

Format *FOLD_LINE=ON*
FOLD_LINE=OFF

ON Folds output lines.

OFF Does not fold output lines.

The default is ON.

Remarks

- If a line of output is too long for a screen or printer, some terminals automatically continue the output on the next physical line. However, others overprint on the same physical line. In these cases, changing FOLD_LINE to ON enables CDCNET to position the cursor for you.

In other words, the network performs a LINE_FEED_SEQUENCE followed by a CARRIAGE_RETURN_SEQUENCE to force remaining output to the left margin of the next line whenever PAGE_WIDTH is reached.

- Whether your terminal wraps output and how FOLD_LINE is set affects the formatting of your data.

Action	FL=ON	FL=OFF
Terminal wraps.	Produces extra blank line.	Produces satisfactory positioning.
Terminal does not wrap.	Produces satisfactory positioning.	Strikes over or discards characters.

FOLD_LINE (FL)

- For FOLD_LINE to work properly, you must set PAGE_WIDTH to your terminal's physical page width.

Examples You are preparing to print a file in which each set of 30 characters identifies a unique item on your microcomputer's printer. You want it printed with a single item on each line so that you can read the information easily. To format your data in this manner, change PAGE_WIDTH to 30 and FOLD_LINE to ON.

```
%CHATA PW=30 FL=ON
```

FORM_FEED_DELAY (FFD)

Purpose Increases or decreases the amount of idle time after a FORM_FEED_SEQUENCE. (During this time, the network sends your terminal NUL characters.)

If information is sent to your terminal faster than it can position the cursor (or paper), you can avoid losing data by increasing the idle time with FORM_FEED_DELAY. This additional time allows your terminal to completely erase the screen or move to the top of a new page (or form). (See chapter 5 and the description of the FORM_FEED_SEQUENCE terminal attribute later in this chapter for more information.)

NOTE

Form feed delays are typically used for older, nonbuffered devices that do not support X-ON/X-OFF flow control.

Format *FORM_FEED_DELAY = integer*

integer Specifies the idle time in number of milliseconds. You can use any integer from 0 through 3000.

The default is 0.

Remarks

- Whenever any of the following occur, CDCNET inserts enough NUL characters in the output to fill the milliseconds you specify with FORM_FEED_DELAY:
 - Output contains a FORM_FEED_SEQUENCE, as specified by END_PAGE_ACTION.
 - Output from your service contains a character (such as a format effector) that the network converts to the FORM_FEED_SEQUENCE.

FORM_FEED_DELAY (FFD)

- A combination of factors determines the delay you enter for FORM_FEED_DELAY. The amount of time needed depends on the page length, the speed at which your terminal processes a FORM_FEED_SEQUENCE, and line speed.

<u>Factor</u>	<u>Delay Time</u>
Device processes FFS faster.	Decreases.
Page length increases.	Increases.
Line speed increases.	Decreases.

- Certain terminals, such as the Lear Siegler ADM3A and ADM5, do not ignore NUL characters. In these cases, you should set FORM_FEED_DELAY to 0.

Examples

Slave printers that repeat information exchanged by CDCNET and a terminal are often attached to microcomputers. In this situation, you can avoid losing data on your printed listing by changing the FORM_FEED_DELAY.

```
%CHATA FFD=200
```

Specifying a delay of one-fifth second provides additional time for positioning paper. While the network inserts NUL characters after each FORM_FEED_SEQUENCE, your printer moves the paper to the top of the next page.

FORM_FEED_SEQUENCE (FFS)

- Purpose** Defines the sequence of characters that causes a page break. This sequence, often called a form feed, typically positions the cursor or paper at the top of the next page. (See the description of `END_PAGE_ACTION` terminal attribute earlier in this chapter for more information. Also see chapter 5.)
- Format** `FORM_FEED_SEQUENCE=sequence`
- `sequence` Defines a sequence of 0 through 7 characters. (See appendix B for detailed information about defining characters.)
- The default is `FF`.
- Remarks**
- CDCNET sends a `FORM_FEED_SEQUENCE` to your terminal whenever the connected service indicates it should do so.
 - If the service uses a format effector that requires a top-of-form operation, CDCNET substitutes the sequence defined by `FORM_FEED_SEQUENCE`.
 - If the sequence specified contains `CR` or `LF` (ASCII carriage-return or line-feed characters), the network replaces them with the `CARRIAGE_RETURN_SEQUENCE` or `LINE_FEED_SEQUENCE`, respectively.
 - CDCNET sends the `<OVER>` prompt to your terminal when it detects an end-of-page condition (a `FORM_FEED_SEQUENCE`), the printer or screen is not empty, and the terminal attribute `HOLD_PAGE_OVER=ON`.
- Examples** Suppose your terminal emulates a DEC VT100 terminal. You want this terminal to clear its screen each time the service requests a top-of-page operation. Enter the following command to change the `FORM_FEED_SEQUENCE`:

```
%CHATA FFS=(ESC,'[','H',ESC,'[','J')
```

FUNCTION_KEY_CLASS (FKC)

FUNCTION_KEY_CLASS (FKC)

Purpose Specifies the name of the function key class to be used with the current terminal device.

Format *FUNCTION_KEY_CLASS=DEC_VT100*
FUNCTION_KEY_CLASS=DEC_VT100_GOLD
FUNCTION_KEY_CLASS=DEC_VT220
FUNCTION_KEY_CLASS=SUN_160
FUNCTION_KEY_CLASS=NONE

The default is NONE.

Remarks

- The FUNCTION_KEY_CLASS name must match the name of a currently registered Control Data-defined function key class.
- The FUNCTION_KEY_CLASS can be used only when the INPUT_EDITING_MODE=TRANSPARENT and the TRANSPARENT_CHARACTER_MODE=FORWARD or FORWARD_TERMINATE.

Examples When you use the File Editor application with a VT-100 terminal, function keys have to be followed by a return for the application to act on that function. To avoid using the return key you can, before using the editor, change the FUNCTION_KEY_CLASS as shown below.

```
%CHATA FKC=DEC_VT100
```

HOLD_PAGE (HP)

Purpose Specifies whether data flow stops at the end of each page (or form).

If this attribute is set to ON, data flow stops when PAGE_LENGTH minus one line is reached. It also stops before a FORM_FEED_SEQUENCE. In both cases, you must then press the RETURN key or enter some data to proceed to the next and subsequent pages.

If HOLD_PAGE is set to OFF, output is displayed or printed without interruption. (See the descriptions of the END_PAGE_ACTION and HOLD_PAGE_OVER terminal attributes earlier in this chapter, and the PAGE_LENGTH terminal attribute later in this chapter for information on related settings. See also chapter 5.)

Format *HOLD_PAGE=ON*
HOLD_PAGE=OFF

ON Stops data flow and waits for an input response.

OFF Does not stop data flow.

The default is OFF.

- Remarks**
- The network waits for you to enter the END_LINE_CHARACTER (usually RETURN) when HOLD_PAGE is ON and PAGE_LENGTH is reached. The network also starts a new page when the following occur:
 1. Entering a network command causes the network to place output on a new page. Actually, it is the NETWORK_COMMAND_CHARACTER followed by an END_LINE_CHARACTER that causes your output to resume on the next page. (That is, entering the percent sign (%) and pressing the RETURN key.)
 2. Entering a line of input to the service causes the network to forward the data to the service and display subsequent output on a new page.

HOLD_PAGE (HP)

- If you have specified the following attribute settings, HOLD_PAGE occurs before END_PAGE_ACTION.
HOLD_PAGE=ON
END_PAGE_ACTION=FFS
- When these settings apply and the network sends the terminal a FORM_FEED_SEQUENCE before PAGE_LENGTH is reached, the network stops sending data and waits until you enter an END_LINE_CHARACTER (usually RETURN) before continuing output on the next page.
- Typically, you use HOLD_PAGE to display data, but you can also specify this attribute when printing forms to allow time for positioning the next form.
- CDCNET does not perform page holding when you are using the following setting:

PAGE_LENGTH=0.

- If PAGE_WIDTH is greater than zero, CDCNET determines when PAGE_LENGTH is reached by counting the number of physical lines it outputs.
- If PAGE_WIDTH is set to zero (PAGE_WIDTH=0), CDCNET determines when PAGE_LENGTH is reached by counting the number of logical lines sent by the service.

Examples

Suppose you are working at a terminal with the following attribute settings and want to display one page at a time:

```
HOLD_PAGE=OFF
PAGE_LENGTH=24
PAGE_WIDTH=80
```

You can enter a CHANGE_TERMINAL_ATTRIBUTE command to change the value of HOLD_PAGE:

```
%CHATA HP=ON
```

HOLD_PAGE_OVER (HPO)

Purpose Specifies whether an <OVER> prompt is displayed at your terminal when a HOLD_PAGE is encountered. This prompt reminds you that more information is available. (See the descriptions of the END_PAGE_ACTION and the HOLD_PAGE terminal attributes earlier in this chapter, and the PAGE_LENGTH terminal attribute later in this chapter for information on related settings. Also see chapter 5.)

Format *HOLD_PAGE_OVER=ON*
HOLD_PAGE_OVER=OFF

ON Displays <OVER> messages.

OFF Does not display <OVER> messages.

The default is ON.

Remarks

- CDCNET sends you prompting messages when PAGE_LENGTH is greater than zero and the following settings are specified:

HOLD_PAGE=ON
HOLD_PAGE_OVER=ON

- CDCNET sends the following prompting message to your terminal at the end of a page.

<OVER>

- CDCNET sends you the prompting message if it detects a FORM_FEED_SEQUENCE even though the printer or screen is not yet empty. See the description of the terminal attribute FORM_FEED_SEQUENCE earlier in this chapter for more information.

<OVER>

HOLD_PAGE_OVER (HPO)

Examples If you are working at a terminal with the following attribute settings, you may want CDCNET to prompt you at the end of a page.

```
HOLD_PAGE=ON  
HOLD_PAGE_OVER=OFF  
PAGE_LENGTH=24
```

Changing the value of HOLD_PAGE_OVER to ON produces an <OVER> prompt on line 24 of every page.

```
%CHATA HPO=ON
```

LINE_FEED_DELAY (LFD)

Purpose Increases or decreases the idle time after a `LINE_FEED_SEQUENCE`. (During this time, the network sends your terminal NUL characters.)

If information is sent to your terminal faster than it can position the paper (or cursor), you can avoid losing data by increasing the idle time with `LINE_FEED_DELAY`. This additional idle time prevents data from being lost while your terminal is moving the paper (or cursor) to the next line. (See chapter 5 and the description of the `LINE_FEED_SEQUENCE` terminal attribute later in this chapter for more information.)

NOTE

Line feed delays are typically used for older, nonbuffered devices that do not support X-ON/X-OFF flow control.

Format `LINE_FEED_DELAY = integer`

`integer` Specifies the idle time in number of milliseconds. You can use any integer from 0 through 1000.

The default is 0.

Remarks

- Whenever any of the following occurs, CDCNET inserts enough NUL characters in the output to fill the milliseconds you specify with `LINE_FEED_DELAY`.
 - Output from your service contains a character (such as a format effector or LF) that the network converts to the `LINE_FEED_SEQUENCE`.
 - `PAGE_WIDTH` is reached; either CDCNET or your terminal folds the line (depending upon the setting of `FOLD_LINE`); and CDCNET inserts a `LINE_FEED_SEQUENCE` and `CARRIAGE_RETURN_SEQUENCE` to reposition your cursor.

LINE_FEED_DELAY (LFD)

- The network performs END_LINE_POSITIONING or END_PARTIAL_POSITIONING and, as a result, sends your terminal a LINE_FEED_SEQUENCE.
- A combination of factors determines the delay you enter for LINE_FEED_DELAY. The amount of time needed to move the paper (or cursor) depends on the terminal's page width, the speed at which the device moves, and line speed.

<u>Factor</u>	<u>Delay</u>
Page width increases.	Amount of time increases.
Device performs cursor positioning faster.	Amount of time decreases.
Line speed increases.	Amount of time decreases.

- Since line feeds usually occur in conjunction with returns, the time specified for CARRIAGE_RETURN_DELAY often suffices to position the paper (or cursor).
- Using both the LINE_FEED_DELAY and CARRIAGE_RETURN_DELAY provides a combined maximum delay of two seconds for positioning, if needed.
- Certain terminals, such as the Lear Siegler ADM3A and ADM5, do not ignore NUL characters. In these cases, you should set LINE_FEED_DELAY to 0.

Examples Slave printers that repeat information exchanged by CDCNET and a terminal are often attached to microcomputers. To avoid losing data on your printed listing, change the LINE_FEED_DELAY.

```
%CHATA LFD=200
```

Specifying a delay of one-fifth second provides additional time for positioning the paper. While CDCNET inserts NUL characters after each LINE_FEED_SEQUENCE, your printer moves the paper to the next line.

LINE_FEED_SEQUENCE (LFS)

- Purpose** Defines the sequence of characters that indicates a line-feed action. This action moves the cursor down one line, or rolls the printer paper up one line in preparation of the next line of data. (See the descriptions of the `END_LINE_POSITIONING` and `END_PARTIAL_POSITIONING` terminal attributes earlier in this chapter for more information. Also see chapter 5.)
- Format** `LINE_FEED_SEQUENCE = sequence`
- `sequence` Defines a sequence of 0 through 2 characters. (See appendix B for detailed information about defining characters.)
- The default is LF.
- Remarks**
- CDCNET sends the `LINE_FEED_SEQUENCE` to your terminal whenever a LF (ASCII character) appears in your data.
 - When the service uses a format effector that requires a line-feed action, CDCNET substitutes the sequence defined by `LINE_FEED_SEQUENCE`.
 - If `FOLD_LINE` is ON, CDCNET inserts a `LINE_FEED_SEQUENCE` when `PAGE_WIDTH` is reached.
- Examples** If your terminal automatically performs both a line feed and carriage return, you can set the `LINE_FEED_SEQUENCE` to NUL to avoid duplication. To do so, enter the following `CHANGE_TERMINAL_ATTRIBUTE` command.
- ```
%CHATA LFS=''
```

## NETWORK\_COMMAND\_CHARACTER (NCC)

**Purpose** Defines the key that precedes CDCNET commands. This manual uses % to represent the NETWORK\_COMMAND\_CHARACTER.

**Format** NETWORK\_COMMAND\_CHARACTER = *character*

**character** Specifies an ASCII character. (See appendix B for detailed information about defining characters.)

The default is %.

- Remarks**
- When this character occurs at the beginning of an input line, CDCNET interprets the data as one of the following:
    1. A CDCNET terminal user command. (See chapter 2.)
    2. A user interrupt. (See chapter 6.)
    3. Page turn in input. (When the NETWORK\_COMMAND\_CHARACTER is followed by an END\_LINE\_CHARACTER, the network repositions the cursor [carriage] at the top of your screen [page]. See the description of the HOLD\_PAGE terminal attribute in chapter 5.)
  - Using the ACTIVATE\_AUTO\_RECOGNITION command or changing CODE\_SET may change the graphic representation (not the value) of your NETWORK\_COMMAND\_CHARACTER and ATTENTION\_CHARACTER.

**Examples**

Suppose you have a Bubble APL terminal that you normally use with the coded character set switch on ASCII. To use the NOS APL interpreter, you need to change the NETWORK\_COMMAND\_CHARACTER and ATTENTION\_CHARACTER, as well as the switch setting and CODE\_SET.

1. Enter the following CHANGE\_TERMINAL\_ATTRIBUTE command:

```
%CHATA NCC=ESC AC=DC4 CS=TPAPL
```

You change the NETWORK\_COMMAND\_CHARACTER to avoid having the division sign become your NETWORK\_COMMAND\_CHARACTER when you change to TPAPL.

2. Set your terminal's switch on APL to select the typewriter-pairing ASCII coded character set with APL print.

When you have completed your APL work and want to use ASCII again, repeat the steps.

1. Enter the command:

```
ESC CHATA NCC=% AC=NUL CS=ASCII
```

2. Set your terminal's switch on ASCII.



## PAGE\_LENGTH (PL)

**Purpose** Specifies how the network divides output into pages. In conjunction with other attributes, it enables you to work with shorter or longer pages of information. (See the descriptions of the END\_PAGE\_ACTION, FORM\_FEED\_SEQUENCE, and HOLD\_PAGE terminal attributes earlier in this chapter for information on related settings. Also see chapter 5.)

**Format** *PAGE\_LENGTH=integer*

**integer** Specifies the number of lines per page. You can use any integer from 2 through 255. If you enter 0, the network does not divide your output into pages.

The default is 24.

- Remarks**
- The network informs your service of any change in PAGE\_LENGTH.
  - PAGE\_LENGTH establishes the vertical boundary for your output. To ensure proper paging, you should set PAGE\_LENGTH to the actual physical length of your screen or page.
  - When PAGE\_LENGTH is set to infinite (PAGE\_LENGTH=0), the network does not increment a line counter or perform any functions dependent on PAGE\_LENGTH, END\_PAGE\_ACTION, or HOLD\_PAGE because you do not have a specified page length. Instead, your output is continuously displayed or printed, regardless of length.
  - If a service uses the current page length value to calculate transmission block size or otherwise format output, setting PAGE\_LENGTH to infinite (PAGE\_LENGTH=0) may produce undesirable results.
  - Setting PAGE\_LENGTH to a value larger than your terminal's actual screen length can cause the first lines of some displays to scroll off the page during output.

**Examples**

Some terminals support both 24-line and 30-line lengths. When you are working at one of these terminals, you can avoid any confusion by specifying PAGE\_LENGTH after you connect to CDCNET.

```
%CHATA PL=24
```

Issuing this command ensures that PAGE\_LENGTH is 24, regardless of which option was previously selected.

## PAGE\_WIDTH (PW)

**Purpose** Determines the page width for your screen or page. (See chapter 5 and the description of the FOLD\_LINE terminal attribute earlier in this chapter.)

**Format** *PAGE\_WIDTH = integer*

*integer* Specifies the number of characters per line. You can use any integer from 10 through 255. If you enter 0, the network does not divide your output into lines.

The default is 80.

**Remarks**

- The network informs your service of any change in PAGE\_WIDTH.
- If PAGE\_WIDTH is greater than your terminal's page width, characters may be truncated, overstruck on the right margin, replaced on the left margin of the same line, or continued on the next line depending upon your terminal.  
In addition, insertion of any NUL characters required by CARRIAGE\_RETURN\_DELAY or LINE\_FEED\_DELAY does not necessarily coincide with carriage (or cursor) movement.

**Examples** If you are using a CDC 721 terminal and have a file containing records greater than 80 characters in length, you can extend the terminal's page width to 132 characters. First, change the terminal's physical setting.

1. Select SETUP to begin the change.
2. Press F10 to specify MORE SELECT.
3. When the new function selections appear on your screen, press SHIFT F7 to increase your terminal's width to 132 characters.
4. Press F1 to return to CYBER mode.

Then, enter the following `CHANGE_TERMINAL_ATTRIBUTE` command to inform the network of the change by setting `PAGE_WIDTH` to 132.

```
%CHATA PW=132
```

## PARITY (P)

**Purpose** Tells the network what your terminal's parity is.

If you receive garbled (unreadable) messages when accessing the network, the communication line that connects your terminal to the computer site probably requires a different parity setting (or coded character set). At this point, you have two choices:

1. Call your site administrator to determine your terminal's proper setting. Then enter a `CHANGE_TERMINAL_ATTRIBUTE` command with your terminal's setting for `PARITY` (or `CODE_SET`).
2. Turn off your terminal and consult your terminal documentation to verify the setting.

If necessary, reset your terminal's switch to match the characteristics of your communication line.

**Format** *PARITY=EVEN*  
*PARITY=ODD*  
*PARITY=MARK*  
*PARITY=ZERO*  
*PARITY=NONE*

|             |                                                                                       |
|-------------|---------------------------------------------------------------------------------------|
| <b>EVEN</b> | Specifies that the sum of all bits in a character is an even number.                  |
| <b>ODD</b>  | Specifies that the sum of all bits in a character is an odd number.                   |
| <b>MARK</b> | Sets parity bit to 1. (Certain terminals and software packages require this setting.) |
| <b>ZERO</b> | Sets parity bit to 0. (Certain terminals and software packages require this setting.) |
| <b>NONE</b> | Passes parity bit through unchanged.                                                  |

The default is **EVEN**.

Remarks

- If your site administrator has configured your communication line for automatic recognition, the two line feed characters the network sends to your terminal in response to the initial returns you use to connect to CDCNET have their parity bits set to zero.
- The following chart shows how CDCNET handles input and output for the various PARITY settings. (The INPUT\_EDITING\_MODE setting is only relevant when PARITY is NONE.) It describes how CDCNET handles data.

| PARITY | Input                                                                                                          | Output                                                                                          |
|--------|----------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| EVEN   | Checks and clears 8th bit.                                                                                     | Sets 8th bit to EVEN.                                                                           |
| ODD    | Checks and clears 8th bit.                                                                                     | Sets 8th bit to ODD.                                                                            |
| MARK   | Checks and clears 8th bit.                                                                                     | Sets 8th bit.                                                                                   |
| ZERO   | Checks and clears 8th bit.                                                                                     | Clears 8th bit.                                                                                 |
| NONE   | Clears 8th bit if input editing mode is normal. Passes through unchanged if input editing mode is transparent. | Clears 8th bit if output is not transparent. Passes through unchanged if output is transparent. |

- If CDCNET detects parity errors in your input data, the network forwards the data with an error indication. It is up to your service to process this indication.
- The following attribute settings are often used during file transfers.

PARITY=NONE  
 INPUT\_EDITING\_MODE=TRANSPARENT

Instead of checking the 8th bit, file transfer packages use other methods such as CRC.

## PARITY (P)

- You normally change PARITY due to one of the following:
  - The initial value is incorrect for your terminal.
  - The 8th bit in the code must be treated as part of your data.
- You may need to set PARITY to NONE if a local area network is between your terminal and CDCNET. Consult your site administrator for specific information.

### Examples

A local area network that links your personal computer to CDCNET requires a connected terminal to have parity set to none. Your site administrator has configured your communication line with PARITY set to EVEN (the default). To avoid problems, you should change the PARITY setting so that CDCNET matches the local area network, which should match your terminal's setting.

```
%CHATA P=NONE
```

With this setting, CDCNET ignores your terminal's parity setting.

**RESPONSE\_ACTION (RA)**

- Purpose** Indicates whether the network displays successful network command responses, network banners, and other unsolicited, network-generated output at your terminal.
- Format** *RESPONSE\_ACTION=SEND*  
*RESPONSE\_ACTION=DISCARD*
- SEND** Displays all network responses at terminal.
- DISCARD** Discards all network responses.
- The default is SEND.
- Remarks**
- Specifying DISCARD for the RESPONSE\_ACTION setting results in discarding network command responses, network banners, and other unsolicited, network-generated output, instead of displaying it at your terminal. This setting is typically used for passthrough connections to non-Control Data hosts or non-Control Data host front end computers.
  - Typically, the type of user receiving the information determines the RESPONSE\_ACTION setting.
- | Setting | Type of User |
|---------|--------------|
| DISCARD | Nonhuman     |
| SEND    | Human        |
- Examples** When an asynchronous printer is connected to the NOS Printer Support Utility (PSU), the terminal user procedure establishes attribute settings for the printer. This procedure contains a CHANGE\_TERMINAL\_ATTRIBUTE command to suppress the CDCNET banner and other unsolicited output.
- ```
CHANGE_TERMINAL_ATTRIBUTE RA=DISCARD
```
- If for some reason you do need to change RESPONSE_ACTION at your terminal, enter a CHANGE_TERMINAL_ATTRIBUTE command.
- ```
%CHATA RA=DISCARD
```



## STATUS\_ACTION (SA)

**Purpose** Specifies how your terminal handles messages from the network operator.

**Format** *STATUS\_ACTION=DISCARD*  
*STATUS\_ACTION=HOLD*  
*STATUS\_ACTION=SEND*

**DISCARD (D)** Does not display messages. CDCNET discards the messages.

**HOLD (H)** Saves the last four messages until you change STATUS\_ACTION to SEND or DISCARD. If you disconnect from CDCNET, the network discards the messages.

**SEND (S)** Displays each message when received.

The default is SEND.

**Remarks** Unless you specify one of the following options, messages from the network operator may appear in the midst of your output.

*STATUS\_ACTION=HOLD*  
*STATUS\_ACTION=DISCARD*

**Examples** You are preparing to print some financial forms at your terminal. Because you do not want unsolicited messages on the forms, change STATUS\_ACTION to HOLD.

*%CHATA SA=HOLD*

This **CHANGE\_TERMINAL\_ATTRIBUTE** command instructs CDCNET to suppress any messages from the network operator.

## TERMINAL\_MODEL (TM)

**Purpose** Identifies your terminal's characteristics for the service you are accessing. If your computer site uses this feature, your site administrator gives you a terminal model name. (See appendix E for detailed information on using TERMINAL\_MODEL.)

**Format** *TERMINAL\_MODEL=name*

**name** Specifies the name assigned to your terminal model. (See appendix E for a list of valid NOS/VE and NOS names.)

The default is NONE.

**Remarks**

- The network informs your service of any change in TERMINAL\_MODEL.
- If you or your site administrator does not specify TERMINAL\_MODEL, it defaults to NONE.

**Examples** To change your terminal model name from NONE to DEC\_VT100, enter the following command:

```
%CHATA TM=DEC_VT100
```



# Connection Attributes

---

|                                                     |      |
|-----------------------------------------------------|------|
| Displaying and Changing Connection Attributes ..... | 4-1  |
| Connection Attributes and Protocols .....           | 4-2  |
| Connection Attributes and Input Editing Modes ..... | 4-4  |
| Connection Attribute Descriptions .....             | 4-5  |
| ATTENTION_CHARACTER_ACTION (ACA) .....              | 4-6  |
| ATTENTION_CHARACTER_ENABLE (ACE) .....              | 4-7  |
| BREAK_KEY_ACTION (BKA) .....                        | 4-8  |
| ECHO_ENABLE (EE) .....                              | 4-9  |
| INPUT_BLOCK_SIZE (IBS) .....                        | 4-10 |
| INPUT_EDITING_MODE (IEM) .....                      | 4-11 |
| INPUT_FLOW_CONTROL_ENABLE (IFCE) .....              | 4-12 |
| INPUT_OUTPUT_MODE (IOM) .....                       | 4-13 |
| OUTPUT_FLOW_CONTROL_ENABLE (OFCE) .....             | 4-15 |
| PARITY_ENABLE (PE) .....                            | 4-16 |
| PARTIAL_CHARACTER_FORWARDING (PCF) .....            | 4-17 |
| STORE_BACKSPACE_CHARACTER (SBC) .....               | 4-18 |
| STORE_NULS_DELS (SND) .....                         | 4-19 |
| TRANSPARENT_CHARACTER_MODE (TCM) .....              | 4-20 |
| TRANSPARENT_FORWARD_CHARACTER (TFC) .....           | 4-22 |
| TRANSPARENT_LENGTH_MODE (TLM) .....                 | 4-23 |
| TRANSPARENT_MESSAGE_LENGTH (TML) .....              | 4-24 |
| TRANSPARENT_PROTOCOL_MODE (TPM) .....               | 4-25 |
| TRANSPARENT_TERMINATE_CHARACTER (TTC) .....         | 4-26 |
| TRANSPARENT_TIMEOUT_INTERVAL (TTI) .....            | 4-27 |
| TRANSPARENT_TIMEOUT_MODE (TTM) .....                | 4-29 |



Connection attributes enable you to control the connection between your terminal and a service. As mentioned earlier, you can create and use more than one connection to link your terminal with a service. Each connection you create has one set of connection attributes.

Connection attributes generally describe how an application wants to use the terminal. Connection attributes are changed mostly by applications although there may be exceptions where it is meaningful for you to select certain values for connection attributes. Any time you change a connection attribute, CDCNET notifies the connected service of the change.

Connection attributes share the following qualities:

- The proper connection attribute value is set by the application, so you should normally not have to set the value.
- The connection attribute value is changed using commands available to your application through your service.

## Displaying and Changing Connection Attributes

Two commands allow you to display and change the connection attributes associated with your terminal. That is, you can display and change the ones supported by the protocol you are using. The network maintains a separate set of connection attributes for each connection you create.

`DISPLAY_CONNECTION_ATTRIBUTE`

`CHANGE_CONNECTION_ATTRIBUTE`

Because applications generally set these attributes, most users can begin processing on their connected service without changing any connection attributes. However, you may want to change the settings of `ATTENTION_CHARACTER_ACTION` or `BREAK_KEY_ACTION`, depending on your service.

## Connection Attributes and Protocols

Figure 4-1 shows the default connection attribute values for the Asynchronous protocol. Default connection attributes for the 3270 Binary Synchronous Communications, X.PC, Mode 4, and 3270 SNA Communications protocols are described in appendixes F, H, I, and J respectively.

|                                 |               |
|---------------------------------|---------------|
| Attention_Character_Action      | : 2           |
| Attention_Character_Enable      | : ON          |
| Break_Key_Action                | : 0           |
| Echo_Enable                     | : ON          |
| Input_Block_Size                | : 160         |
| Input_Editing_Mode              | : NORMAL      |
| Input_Flow_Control_Enable       | : ON          |
| Input_Output_Mode               | : UNSOLICITED |
| Output_Flow_Control_Enable      | : ON          |
| Parity_Enable                   | : ON          |
| Partial_Character_Forwarding    | : OFF         |
| Store_Backspace_Character       | : OFF         |
| Store_Nuls_Dels                 | : OFF         |
| Transparent_Character_Mode      | : TERMINATE   |
| Transparent_Forward_Character   | : CR 8D(16)   |
| Transparent_Length_Mode         | : NONE        |
| Transparent_Message_Length      | : 255         |
| Transparent_Protocol_Mode       | : NONE        |
| Transparent_Terminate_Character | : CR 8D(16)   |
| Transparent_Timeout_Interval    | : 0           |
| Transparent_Timeout_Mode        | : NONE        |

**Figure 4-1. Asynchronous Protocol Connection Attribute Defaults**

CDCNET recognizes the following connection attributes only when INPUT\_EDITING\_MODE=TRANSPARENT:

- Transparent\_Character\_Mode
- Transparent\_Forward\_Character
- Transparent\_Length\_Mode
- Transparent\_Message\_Length
- Transparent\_Protocol\_Mode
- Transparent\_Terminate\_Character
- Transparent\_Timeout\_Interval
- Transparent\_Timeout\_Mode



## Connection Attributes and Input Editing Modes

Which attributes apply to your input and output processing depends upon whether the INPUT\_EDITING\_MODE connection attribute is set to NORMAL or TRANSPARENT, as shown in table 4-1. Chapter 5 describes normal and transparent modes in more detail.

**Table 4-1. Connection Attributes and Input Editing Modes**

| Connection Attribute            | Normal | Transparent |
|---------------------------------|--------|-------------|
| Attention_Character_Action      | I      | I           |
| Attention_Character_Enable      |        | I           |
| Break_Key_Action                | I      | I           |
| Echo_Enable                     |        | I           |
| Input_Block_Size                | I      | I           |
| Input_Editing_Mode <sup>1</sup> |        |             |
| Input_Flow_Control_Enable       |        | O           |
| Input_Output_Mode               | I/O    | I/O         |
| Output_Flow_Control_Enable      |        | I           |
| Parity_Enable                   |        | I           |
| Partial_Character_Forwarding    | I      |             |
| Store_Backspace_Character       | I      |             |
| Store_Nuls_Dels                 | I      |             |
| Transparent_Character_Mode      |        | I           |
| Transparent_Forward_Character   |        | I           |
| Transparent_Length_Mode         |        | I           |
| Transparent_Message_Length      |        | I           |
| Transparent_Protocol_Mode       |        | I           |
| Transparent_Terminate_Character |        | I           |
| Transparent_Timeout_Interval    |        | I           |
| Transparent_Timeout_Mode        |        | I           |

Attributes marked I apply to input. Those marked O apply to output.

1. Table 4-1 is based on the value of this attribute.

## Connection Attribute Descriptions

The following pages describe the connection attributes used by the network to control Asynchronous protocol connections. Refer to appendixes F through I for connection attribute support for other protocols.

These attribute descriptions contain purpose, format, remarks, and examples, when applicable. Each description begins with an attribute name followed by its abbreviation, in parentheses. The format description lists the values that you can assign a specified connection attribute. It also gives an explanation of each value and its abbreviation.

## ATTENTION\_CHARACTER\_ACTION (ACA)

**Purpose** Specifies how the network responds when it recognizes the ATTENTION\_CHARACTER in data from your terminal. (Chapter 3 describes the ATTENTION\_CHARACTER terminal attribute.)

**Format** *ATTENTION\_CHARACTER\_ACTION=integer*

**integer** Specifies a service-defined action. You can use any integer from 0 through 9. On NOS/VE and NOS, 0 cancels input, 1 cancels input and output (usually a pause condition on most services), and 2 through 9 cancels input and output (usually a terminate condition on most services).

Default is 2.

**Remarks**

- ATTENTION\_CHARACTER\_ACTION and BREAK\_KEY\_ACTION apply to both normal and transparent modes.
- Whenever you press CONTROL T, the key that you specified for ATTENTION\_CHARACTER, CDCNET performs these actions:
  - Sends the service expedited data (the value that you specified for ATTENTION\_CHARACTER\_ACTION).
  - Discards both input and output.
  - In addition, the service gives control to the program if your program is able to invoke reprieve processing.

**Examples** If you are writing a program, you can use ATTENTION\_CHARACTER\_ACTION to provide users with specialized interrupts. For instance, using the following commands allows users to interrupt your program.

```
%CHACA ACA=7
%CHATA AC=20
```

**ATTENTION\_CHARACTER\_ENABLE (ACE)**

|                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b> | Specifies whether or not the terminal interface program (TIP) is to treat the attention character as data. The parameter is only in effect when the connection attribute <code>INPUT_EDITING_MODE=TRANSPARENT</code> .                                                                                                                                                                                                                                            |
| <b>Format</b>  | <i>ATTENTION_CHARACTER_ENABLE=YES</i><br><i>ATTENTION_CHARACTER_ENABLE=NO</i>                                                                                                                                                                                                                                                                                                                                                                                     |
|                | <p><b>YES</b>      The TIP does attention character processing as specified by the terminal attribute <code>ATTENTION_CHARACTER</code>. If <code>AC=some character</code>, the specified character is processed as the attention character. If <code>AC=NUL</code>, all characters are processed as data, regardless of the value of this (ACE) parameter.</p> <p><b>NO</b>        The TIP treats the attention character as data.</p> <p>The default is YES.</p> |
| <b>Remarks</b> | <code>ATTENTION_CHARACTER_ENABLE</code> applies only when <code>INPUT_EDITING_MODE=TRANSPARENT</code> .                                                                                                                                                                                                                                                                                                                                                           |

## BREAK\_KEY\_ACTION (BKA)

**Purpose** Specifies how the network responds when it recognizes a BREAK signal from your terminal. Because the ability to transmit this signal is terminal-dependent and is not defined by a terminal attribute, you should check your terminal documentation for more information.

**Format** *BREAK\_KEY\_ACTION=integer*

**integer** Specifies a service-defined action. You can use any integer from 0 through 9. On NOS/VE and NOS, 0 cancels input, 1 cancels input and output (usually a pause condition on most services), and 2 through 9 cancels input and output (usually a terminate condition on most services).

The default is 0.

- Remarks**
- ATTENTION\_CHARACTER\_ACTION and BREAK\_KEY\_ACTION apply to both NORMAL and TRANSPARENT modes.
  - You can have interrupt and terminate keys on most terminals by using your ATTENTION\_CHARACTER and BREAK key and by setting the appropriate connection attributes: ATTENTION\_CHARACTER\_ACTION and BREAK\_KEY\_ACTION.
  - The BREAK signal also acts as an X-ON when connection attribute OUTPUT\_FLOW\_CONTROL\_ENABLE=YES. (See the attribute description later in this chapter.)

**Examples** You can use your BREAK key to terminate a program. To do this, change the value of BREAK\_KEY\_ACTION by entering the following command:

```
%CHACA BKA=2
```

The next time you use the BREAK key while output is in process, the service reacts as if you entered a terminal user interrupt (such as %2). That is, the network discards any input and output, and then the service terminates the program.

**ECHO\_ENABLE (EE)**

**Purpose** Specifies whether the network echoes characters you enter when the terminal attribute ECHOPLEX=TRUE. (See the description of the ECHOPLEX terminal attribute in chapter 3 for more information.)

**Format** *ECHO\_ENABLE=YES*  
*ECHO\_ENABLE=NO*

**YES** Specifies that the network echoes all characters you enter if terminal attribute ECHOPLEX=TRUE.

**NO** Specifies that the network does not echo characters you enter if terminal attribute ECHOPLEX=TRUE.

The default is YES.

**NOTE**


---

When terminal attribute ECHOPLEX=FALSE, ECHO\_ENABLE is ignored and no echoing occurs.

---

**Remarks** None.

## INPUT\_BLOCK\_SIZE (IBS)

**Purpose** Specifies the maximum number of characters the network forwards to your service in a transmission. Whenever your terminal sends the specified number of characters to the network, it can send the service a partial transmission without an `END_LINE_CHARACTER` or `END_PARTIAL_CHARACTER`.

**Format** `INPUT_BLOCK_SIZE = integer`

`integer` Specifies the number of characters. You can use any integer from 80 through 2000.

The default is 160.

- Remarks**
- When a service cannot store transmissions larger than a certain size, you can reduce the size of the network transmissions with `INPUT_BLOCK_SIZE`.
  - The settings of the following attributes determine when the network sends a service transmission. (See chapter 5 for details.)

| Type of Data     | Attribute                                                                                                                |
|------------------|--------------------------------------------------------------------------------------------------------------------------|
| Normal mode      | <code>END_LINE_CHARACTER</code><br><code>END_PARTIAL_CHARACTER</code>                                                    |
| Transparent mode | <code>TRANSPARENT_CHARACTER_MODE</code><br><code>TRANSPARENT_LENGTH_MODE</code><br><code>TRANSPARENT_TIMEOUT_MODE</code> |

Upon recognizing a condition specified by one of these attributes, the network sends the service the characters that it has received from the terminal.

If the number of characters the network is storing reaches the `INPUT_BLOCK_SIZE` before one of the above conditions occur, the network forwards the data as a special type of partial transmission.

**INPUT\_EDITING\_MODE (IEM)**

**Purpose** Specifies how the network edits data you enter at your terminal. When you set this attribute to **NORMAL**, the network edits information and responds to all CDCNET commands. When set to **TRANSPARENT**, the network forwards information with only limited editing. In transparent mode, the network only responds to the **ATTENTION\_CHARACTER**, **BREAK** key, and **X-ON/X-OFF** characters. (See chapter 5 for additional information. Chapter 3 describes the **ATTENTION\_CHARACTER** terminal attribute.)

**Format** *INPUT\_EDITING\_MODE=NORMAL*  
*INPUT\_EDITING\_MODE=TRANSPARENT*

|                        |                                                                                                                               |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| <b>NORMAL (N)</b>      | Edits your input before forwarding it to the service. This editing removes special codes or characters used by your terminal. |
| <b>TRANSPARENT (T)</b> | Forwards your input to the service. The network does not remove special codes or characters.                                  |

The default is **NORMAL**.

**Remarks**

- Normal mode is used for line-oriented, interactive, command/response processing.
- Transparent mode is frequently used in file transfers, full-screen formatting, and full-screen editing.
- Normally, your service controls the IEM attribute.
- The \$NET connection is always in normal mode.



## INPUT\_FLOW\_CONTROL\_ENABLE (IFCE)

**Purpose** Specifies whether or not input character flow control is to be used on the terminal. (See the description of the CHARACTER\_FLOW\_CONTROL terminal attribute in chapter 3 for more information.)

**Format** *INPUT\_FLOW\_CONTROL\_ENABLE=YES*  
*INPUT\_FLOW\_CONTROL\_ENABLE=NO*

**YES** Specifies that the terminal controls the flow of input characters when connection attribute INPUT\_EDITING\_MODE=TRANSPARENT and terminal attribute CHARACTER\_FLOW\_CONTROL=INPUT or ON.

**NO** Specifies that the terminal does not control the flow of input characters when connection attribute INPUT\_EDITING\_MODE=TRANSPARENT and terminal attribute CHARACTER\_FLOW\_CONTROL=INPUT or ON.

The default is YES.

**Remarks** None.

**INPUT\_OUTPUT\_MODE (IOM)**

**Purpose** Specifies how terminal input and service output are handled by the network before delivery.

**Format** *INPUT\_OUTPUT\_MODE=FULLDUPLEX*  
*INPUT\_OUTPUT\_MODE=SOLICITED*  
*INPUT\_OUTPUT\_MODE=UNSOLICITED*

**FULLDUPLEX (F)** Indicates that the network edits and forwards input even if you are receiving output.

**SOLICITED (S)** Indicates that the service must request input. The network does not edit or forward input until requested by the service (that is, the network allows you to enter data, but does not perform cursor positioning until the service accepts it).

**UNSOLICITED (U)** Indicates that input has priority over output. The network edits input, forwards input, and delays any output that may be in progress (that is, the network allows you to type ahead).

The default is UNSOLICITED.

- Remarks**
- In fullduplex mode, the network processes input and output independently of each other. It edits input upon receipt, and when it receives a forwarding character, such as an `END_LINE_CHARACTER`, the network forwards any edited input to the service.  
 As soon as the network receives output, it delivers the output to your terminal.
  - In solicited mode, the network edits and forwards input only when the service solicits input. The service does this by sending a complete output transmission to the terminal.

## INPUT\_OUTPUT\_MODE (IOM)

If the service does not solicit input, the network accepts input, but does not edit this input. (That is, the network does not echo, backspace, or perform cursor positioning.) While you can enter interrupts, they are not processed until the service solicits input.

The network transmits output upon receipt. Input does not interrupt output in progress.

- In unsolicited mode, the network edits input upon receipt. Edited input is forwarded to the service when a forwarding character, such as an `END_LINE_CHARACTER` is received.

When editing input, the network does not send any output received until it encounters a forwarding character. Upon receipt of input, the network suspends any output in progress until it receives a forwarding character.

If you are using the X.25 Asynchronous protocol, input does not interrupt output. To do so, you can press the BREAK key or issue an X-OFF character if `CHARACTER_FLOW_CONTROL` is ON.

**OUTPUT\_FLOW\_CONTROL\_ENABLE (OFCE)**

|                |                                                                                                                                                                                                                                       |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b> | Specifies whether or not the output character flow is to be accepted from the terminal when INPUT_EDITING_MODE=TRANSPARENT. (See the description of the CHARACTER_FLOW_CONTROL terminal attribute in chapter 3 for more information.) |
| <b>Format</b>  | <i>OUTPUT_FLOW_CONTROL_ENABLE=YES</i><br><i>OUTPUT_FLOW_CONTROL_ENABLE=NO</i>                                                                                                                                                         |
| <b>YES</b>     | Controls the output flow of data when terminal attribute CHARACTER_FLOW_CONTROL=OUTPUT or ON, and INPUT_EDITING_MODE=TRANSPARENT.                                                                                                     |
| <b>NO</b>      | Does not take any action with the output flow of data from the terminal when CHARACTER_FLOW_CONTROL=OUTPUT and INPUT_EDITING_MODE=TRANSPARENT.                                                                                        |
|                | The default is YES.                                                                                                                                                                                                                   |
| <b>Remarks</b> | None.                                                                                                                                                                                                                                 |

## PARITY\_ENABLE (PE)

**Purpose** Specifies whether or not the network processes data according to the setting of the terminal attribute PARITY. (See the description of the terminal attribute PARITY in chapter 3 for more information.)

**Format** *PARITY\_ENABLE=YES*  
*PARITY\_ENABLE=NO*

**YES** Specifies that input and output data are processed according to the setting of the terminal attribute PARITY.

**NO** Specifies that input and output data are processed as if the terminal attribute PARITY=NONE.

The default is YES.

**Remarks** The attribute affects only transparent output data. The attribute is in effect for input only when INPUT\_EDITING\_MODE=TRANSPARENT.

**PARTIAL\_CHARACTER\_FORWARDING (PCF)**

|                |                                                                                                                                                                                                                                                                                 |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b> | Specifies whether the network forwards a partial transmission when an <code>END_PARTIAL_CHARACTER</code> occurs. (Chapter 3 describes the <code>END_PARTIAL_CHARACTER</code> terminal attribute.)                                                                               |
| <b>Format</b>  | <i>PARTIAL_CHARACTER_FORWARDING=ON</i><br><i>PARTIAL_CHARACTER_FORWARDING=OFF</i>                                                                                                                                                                                               |
|                | <p><b>ON</b>        Forwards partial transmission to the service when an <code>END_PARTIAL_CHARACTER</code> occurs in input.</p> <p><b>OFF</b>       Does not take any action when an <code>END_PARTIAL_CHARACTER</code> occurs in input.</p> <p>The default is <b>OFF</b>.</p> |
| <b>Remarks</b> | None.                                                                                                                                                                                                                                                                           |

STORE\_BACKSPACE\_CHARACTER (SBC)

**STORE\_BACKSPACE\_CHARACTER (SBC)**

**Purpose** Specifies how the network handles the BACKSPACE\_CHARACTER in your input data. (Chapter 3 describes the BACKSPACE\_CHARACTER terminal attribute.)

**Format** *STORE\_BACKSPACE\_CHARACTER=ON*  
*STORE\_BACKSPACE\_CHARACTER=OFF*

**ON** Forwards the BACKSPACE\_CHARACTER and the character you backspaced over to the service as part of NORMAL data.

**OFF** Discards BACKSPACE\_CHARACTER and the character you backspaced over from NORMAL data.

The default is OFF.

**Remarks** None.

**STORE\_NULS\_DELS (SND)**

- Purpose** Specifies how the network handles NUL (null) and DEL (delete) characters.
- Format** STORE\_NULS\_DELS=ON  
STORE\_NULS\_DELS=OFF
- ON Forwards NUL (null) and DEL (delete) characters to the service as part of NORMAL data.
- OFF Discards NUL and DEL characters from NORMAL data.
- The default is OFF.
- Remarks** Services usually do not consider NUL or DEL characters to be data. Both are normally nonprinting characters that are used by your terminal or the network; most services require NUL or DEL characters to be discarded.



## TRANSPARENT\_CHARACTER\_MODE (TCM)

**Purpose** Forwards input data and/or terminates TRANSPARENT mode when data entered from your terminal contains a character specified by TRANSPARENT\_FORWARD\_CHARACTER and/or TRANSPARENT\_TERMINATE\_CHARACTER. (See the descriptions of TRANSPARENT\_FORWARD\_CHARACTER and TRANSPARENT\_TERMINATE\_CHARACTER later in this chapter for more information. Also see chapter 5.)

**Format** *TRANSPARENT\_CHARACTER\_MODE=FORWARD*  
*TRANSPARENT\_CHARACTER\_MODE=TERMINATE*  
*TRANSPARENT\_CHARACTER\_MODE=FORWARD\_*  
*TERMINATE*  
*TRANSPARENT\_CHARACTER\_MODE=NONE*

**FORWARD (F)** Sends your data to the service when a TRANSPARENT\_FORWARD\_CHARACTER occurs in input. Transparent mode remains in effect.

**TERMINATE (T)** Sends your data to the service and terminates transparent mode when a TRANSPARENT\_TERMINATE\_CHARACTER occurs in input.

**FORWARD\_**  
**TERMINATE**  
**(FT)** Sends your data to the service when a TRANSPARENT\_FORWARD\_CHARACTER occurs in input; ends transparent mode when a TRANSPARENT\_TERMINATE\_CHARACTER occurs after a TRANSPARENT\_FORWARD\_CHARACTER in input.

**NONE (N)** Causes no action when these characters occur.

The default is TERMINATE.

## Remarks

- CDCNET forwards input data when one of the following settings applies to your connection and CDCNET recognizes a TRANSPARENT\_FORWARD\_CHARACTER.

TRANSPARENT\_CHARACTER\_MODE=  
FORWARD

TRANSPARENT\_CHARACTER\_MODE=  
FORWARD\_TERMINATE

- CDCNET forwards input data and terminates transparent input mode when one of the following settings applies to your connection.

TRANSPARENT\_CHARACTER\_MODE=  
TERMINATE

TRANSPARENT\_CHARACTER\_MODE=  
FORWARD\_TERMINATE

## TRANSPARENT\_FORWARD\_CHARACTER (TFC)

**Purpose** Identifies the key you press to forward transparent input. The network only recognizes this attribute if `INPUT_EDITING_MODE=TRANSPARENT` and `TRANSPARENT_CHARACTER_MODE=FORWARD` or `FORWARD_TERMINATE`, or `TRANSPARENT_PROTOCOL_MODE=FORWARD`. (See the descriptions of the `TRANSPARENT_CHARACTER_MODE` and `TRANSPARENT_PROTOCOL_MODE` attributes in this chapter for more information.)

**Format** `TRANSPARENT_FORWARD_CHARACTER=list or NUL`

**list** Defines a list of 1 through 4 characters. You can then use any of the keys defined by these characters to forward information. (See appendix B for detailed information about defining characters.)

**NUL** Specifies no character is used for transparent forwarding.

The default is CR 8D(16).

**Remarks**

- If either of the following settings applies to your connection, CDCNET acts on the `TRANSPARENT_FORWARD_CHARACTER`.

`TRANSPARENT_CHARACTER_MODE=FORWARD`

`TRANSPARENT_CHARACTER_MODE=FORWARD_TERMINATE`

- If you set `TRANSPARENT_FORWARD_CHARACTER` to DC1 or DC3 with the following settings, CDCNET recognizes the character as a flow control character.

`INPUT_EDITING_MODE=TRANSPARENT`  
`CHARACTER_FLOW_CONTROL=ON`

Accordingly, DC1 or DC3 does not function as a `TRANSPARENT_FORWARD_CHARACTER` and does not reach the service as data.

**TRANSPARENT\_LENGTH\_MODE (TLM)**

|                           |                                                                                                                                                                                                                                                                                                      |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Forwards input data and/or ends transparent mode when it has received the number of characters specified by <code>TRANSPARENT_MESSAGE_LENGTH</code> . (See the description of the <code>TRANSPARENT_MESSAGE_LENGTH</code> attribute later in this chapter for more information. Also see chapter 5.) |
| <b>Format</b>             | <pre>TRANSPARENT_LENGTH_MODE=FORWARD TRANSPARENT_LENGTH_MODE=FORWARD_EXACT TRANSPARENT_LENGTH_MODE=TERMINATE TRANSPARENT_LENGTH_MODE=NONE</pre>                                                                                                                                                      |
| <b>FORWARD (F)</b>        | Sends your data to the service when <code>TRANSPARENT_MESSAGE_LENGTH</code> is reached in input. The message may exceed the specified length. Transparent mode remains in effect.                                                                                                                    |
| <b>FORWARD_EXACT (FE)</b> | Sends the exact number of characters specified by <code>TRANSPARENT_MESSAGE_LENGTH</code> when the network receives that number from your terminal. Transparent mode remains in effect.                                                                                                              |
| <b>TERMINATE (T)</b>      | Sends your data to the service and terminates transparent mode when the <code>TRANSPARENT_MESSAGE_LENGTH</code> is reached in input.                                                                                                                                                                 |
| <b>NONE (N)</b>           | Takes no action when the <code>TRANSPARENT_MESSAGE_LENGTH</code> is reached.                                                                                                                                                                                                                         |
|                           | The default is NONE.                                                                                                                                                                                                                                                                                 |
| <b>Remarks</b>            | None.                                                                                                                                                                                                                                                                                                |

## TRANSPARENT\_MESSAGE\_LENGTH (TML)

**Purpose** Specifies the maximum number of characters in data that the network forwards to your service. The network only recognizes this attribute when INPUT\_EDITING\_MODE is set to TRANSPARENT, and TRANSPARENT\_LENGTH\_MODE is other than NONE. (See the description of the TRANSPARENT\_LENGTH\_MODE attribute earlier in this chapter for more information.)

**Format** *TRANSPARENT\_MESSAGE\_LENGTH = integer*

*integer* Specifies the number of characters. You can use any integer from 1 through 32767 (07FFF(16)).

The default is 255.

- Remarks**
- CDCNET recognizes TRANSPARENT\_MESSAGE\_LENGTH when TRANSPARENT\_LENGTH\_MODE is set to FORWARD, FORWARD\_EXACT, or TERMINATE.
  - CDCNET forwards transmissions and can terminate transparent mode based upon the number of characters received.

**TRANSPARENT\_PROTOCOL\_MODE (TPM)**

|                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b> | Specifies whether or not transparent data is to be forwarded, based upon a TIP-specific protocol event. The network recognizes this attribute only if INPUT_EDITING_MODE=TRANSPARENT. (See the description of the INPUT_EDITING_MODE earlier in this chapter for more information.)                                                                                                                                                                                                                                                                           |
| <b>Format</b>  | <p><i>TRANSPARENT_PROTOCOL_MODE=FORWARD</i><br/> <i>TRANSPARENT_PROTOCOL_MODE=TERMINATE</i><br/> <i>TRANSPARENT_PROTOCOL_MODE=NONE</i></p> <p><b>FORWARD (F)</b> Sends your data to the service when a TIP-specific protocol event occurs.</p> <p><b>TERMINATE (T)</b> Sends your data to the service when a TIP-specific protocol event occurs, and terminates transparent mode (setting the connection attribute INPUT_EDITING_MODE=NORMAL).</p> <p><b>NONE (N)</b> Takes no action based on a TIP-specific protocol event.</p> <p>The default is NONE.</p> |
| <b>Remarks</b> | None.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

## TRANSPARENT\_TERMINATE\_CHARACTER (TTC)

**Purpose** Identifies the key you press to terminate and forward input. The network only recognizes this attribute when INPUT\_EDITING\_MODE is set to TRANSPARENT. (See the description of the TRANSPARENT\_CHARACTER\_MODE attribute earlier in this chapter for more information.)

**Format** *TRANSPARENT\_TERMINATE\_CHARACTER = list*

**list** Defines a list of 1 through 4 characters. You can then use any of the keys defined by these characters to terminate and forward information. (See appendix B for detailed information about defining characters.)

The default is CR 8D(16).

- Remarks**
- If either of the following settings applies to your connection, CDCNET acts on the TRANSPARENT\_TERMINATE\_CHARACTER.  
TRANSPARENT\_CHARACTER\_MODE=TERMINATE  
TRANSPARENT\_CHARACTER\_MODE=FORWARD\_TERMINATE
  - If you set TRANSPARENT\_TERMINATE\_CHARACTER to DC1 or DC3 with the following settings, CDCNET recognizes the character as a flow control character.  
CHARACTER\_FLOW\_CONTROL=ON  
INPUT\_EDITING\_MODE=TRANSPARENT  
Accordingly, neither DC1 nor DC3 function as a TRANSPARENT\_TERMINATE\_CHARACTER and do not reach the service as data.
  - When writing application programs, you must change connection attributes by using commands available to your applications via the service.

**TRANSPARENT\_TIMEOUT\_INTERVAL (TTI)**

**Purpose** Specifies the number of character times which are allowed to elapse between input characters before the network forwards your data to the service. The network only recognizes this attribute if INPUT\_EDITING\_MODE is set to TRANSPARENT and TRANSPARENT\_TIMEOUT\_MODE is other than NONE. (See the description of the TRANSPARENT\_TIMEOUT\_MODE attribute later in this chapter for more information.)

**Format** *TRANSPARENT\_TIMEOUT\_INTERVAL = integer*

**integer** Specifies the number of character times. You can use the default value of 0 or any integer from 2 through 255 (OFF(16)). If you use 0, use the following chart, which is based on line speed, to determine the allowed elapsed time. To find out the time allotted to your line speed, select the speed less than or equal to your line speed.

| <b>Time Limits<br/>(Milliseconds)</b> | <b>Line Speed (<math>\leq</math>)<br/>(Bits per Second)</b> |
|---------------------------------------|-------------------------------------------------------------|
| 400                                   | 110                                                         |
| 300                                   | 600                                                         |
| 200                                   | 1200                                                        |
| 150                                   | 3600                                                        |
| 80                                    | 9600                                                        |
| 60                                    | 19200                                                       |
| 40                                    | 38400                                                       |

The default is 0.

If you enter values 2 through 255, the Terminal Interface Program (TIP) calculates the elapsed time (accurate to 10 milliseconds) based on line speed. If the calculated elapsed time is greater than 1 second, the TIP uses 1 second as the value for the elapsed time.

See chapter 5 for more information.



TRANSPARENT\_TIMEOUT\_INTERVAL (TTI)

- Remarks
- CDCNET recognizes TRANSPARENT\_TIMEOUT\_INTERVAL when TRANSPARENT\_TIMEOUT\_MODE is set to FORWARD or TERMINATE.
  - CDCNET forwards transmissions and can terminate transparent mode based upon the elapsed time between characters.
  - CDCNET uses an equation similar to the following equation to calculate the value of the TTI. For this equation, assume the terminal is running at a line speed of 19200 bps and the elapsed timeout value is to be changed from the default value of 60 milliseconds to approximately 120 milliseconds, for a calculated value of 230.

$$\text{characters} = 120 \text{ msec} \times \frac{1 \text{ sec}}{1000 \text{ msec}} \times \frac{19200 \text{ bits}}{1 \text{ sec}} \times \frac{1 \text{ character}}{10 \text{ bits}}$$

M03117

**TRANSPARENT\_TIMEOUT\_MODE (TTM)**

**Purpose** Forwards input data and ends transparent mode when the allotted time elapses between characters. The amount of time allotted depends upon your `TRANSPARENT_TIMEOUT_INTERVAL` attribute and your line speed.

**Format** *TRANSPARENT\_TIMEOUT\_MODE=FORWARD*  
*TRANSPARENT\_TIMEOUT\_MODE=TERMINATE*  
*TRANSPARENT\_TIMEOUT\_MODE=NONE*

**FORWARD (F)** Sends your data to the service when the allotted time elapses without the network receiving a character.

**TERMINATE (T)** Terminates transparent mode when the allotted time elapses without the network receiving a character.

**NONE (N)** Takes no action based on time between characters.

The default is NONE.

**Remarks** You can use flow control with `TRANSPARENT_TIMEOUT_MODE`. If `CHARACTER_FLOW_CONTROL=ON`, CDCNET stops counting milliseconds when DC3 encountered in input data, and resumes counting when DC1 appears in your data.



---

|                                                        |      |
|--------------------------------------------------------|------|
| Data Modes and Data Types .....                        | 5-1  |
| Role of Attribute Settings .....                       | 5-3  |
| Virtual Line Mode: Data Placement .....                | 5-5  |
| Using Cursor Positioning Sequences .....               | 5-6  |
| Delaying Data Transmission .....                       | 5-7  |
| Virtual Line Mode: Normal Input .....                  | 5-8  |
| Forwarding Complete Transmissions .....                | 5-9  |
| Forwarding Partial Transmissions .....                 | 5-11 |
| Editing Normal Data .....                              | 5-14 |
| Virtual Line Mode: Output .....                        | 5-16 |
| Formatting Virtual Line Output .....                   | 5-17 |
| Using Certain ASCII Characters .....                   | 5-18 |
| Omitting Format Effectors .....                        | 5-18 |
| Using Format Effectors .....                           | 5-18 |
| Format Effectors .....                                 | 5-19 |
| Example .....                                          | 5-20 |
| End-of-Line Positioning .....                          | 5-21 |
| Determining PAGE_WIDTH .....                           | 5-22 |
| Using FOLD_LINE .....                                  | 5-22 |
| End-of-Page Positioning .....                          | 5-24 |
| Determining PAGE_LENGTH .....                          | 5-25 |
| Changing Pages .....                                   | 5-26 |
| Transparent Mode: Transparent Input .....              | 5-28 |
| Editing Transparent Data .....                         | 5-28 |
| Forwarding Transparent Data .....                      | 5-29 |
| Transparent Mode: Output .....                         | 5-30 |
| Virtual Line and Transparent Modes: Flow Control ..... | 5-30 |
| X-ON/X-OFF Flow Control .....                          | 5-31 |
| Automatic Control .....                                | 5-31 |
| Manual Control .....                                   | 5-32 |
| EIA Flow Control .....                                 | 5-32 |



This chapter discusses the CDCNET terminal concepts of data mode and data type and how they, together with connection and terminal attributes, affect the appearance of different types of data at your terminal.

## Data Modes and Data Types

This subsection provides an overview of the data modes and types and the role of attribute settings in each mode.

Data mode specifies how the network processes input and output data. CDCNET recognizes two data modes: virtual line mode and transparent mode. The data mode depends upon the type of data input to the network.

Data type specifies the type of data to be input to the network. CDCNET recognizes two types of data: normal data and transparent data. Normal data is data which is to be edited for input or formatted for output. Normal data is processed in virtual line mode. Transparent data is input data on which little or no editing is to be done. Transparent data is processed in transparent mode. The following table provides more information about data mode and data type.

| Type of Data      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Virtual line mode | <p>This mode is also referred to as <i>edited</i> for input or <i>formatted</i> for output. The INPUT_EDITING_MODE connection attribute designates input in this mode as normal.</p> <p>In virtual line mode, the network and the service send each other 7-bit data with the parity bit set to zero or 8-bit data.</p> <p>The network recognizes CDCNET commands when you are processing in this mode. (See chapter 2 for information on commands. To determine which attributes apply when you are entering normal data, see tables 3-1 and 4-1.)</p>                                                                                                                                                                                                                                                                                                                                                                                      |
| Transparent mode  | <p>This mode is called transparent because the network performs little or no editing on input. The INPUT_EDITING_MODE connection attribute designates input in this mode as transparent.</p> <p>In transparent mode, the network and the service can send each other 7-bit data with the parity bit set to zero or 8-bit data.</p> <p>This mode is used by full-screen applications and by file transfer applications to or from microcomputers. For some uses, it is referred to as binary mode.</p> <p>The network does not recognize CDCNET commands when you are processing in transparent mode. In an emergency, you can use the transparent input editing mode escape sequence, the escape to \$NET connection sequence, or the secure access sequence to escape from transparent mode. (For more information, see chapter 6. To determine which attributes apply when you are entering transparent data, see tables 3-1 and 4-1.)</p> |

## Role of Attribute Settings

The role attributes play in determining appearance of data on your terminal varies according to the type of data and protocol you are using. Because you can generally set and change attributes independently of each other, understanding which attributes are involved in certain activities allow you to change or nullify attribute settings more effectively.

Basically, you have full control over the setting of individual attributes, including changing the TIP-defined and site-defined defaults. Any change you make in the subset of attributes that a TIP supports applies for the duration of a connection, or until changed again. In addition, some services may override attribute settings without you knowing about it. (For example, see NOS/VE System Usage for information on how NOS/VE handles connection attributes.)

The rest of this chapter discusses how certain attribute settings affect specific tasks you do at your terminal depending upon the data mode in which you are operating. Depending upon the task, the chapter enumerates your choices or outlines the order in which the network applies attribute settings. (See chapters 3 and 4 for displays showing the attribute defaults for the asynchronous protocol; refer to appendixes F, G, H, I, and J for information on the terminal and connection attributes of other protocols.) This chapter contains the following subsections discussing the attribute settings in virtual line mode and transparent mode:

| Subsection                             | Description                                                                                                                             |
|----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Virtual Line Mode:<br>Data Placement   | Identifies the sequences and delays (terminal-attribute settings) that affect the placement of input and output on your screen or page. |
| Virtual Line Mode:<br>Normal Input     | Discusses the use of complete and partial transmissions, related cursor positioning, and data editing.                                  |
| Virtual Line Mode:<br>Output           | Describes formatting virtual line output, end-of-line positioning, and end-of-page positioning.                                         |
| Transparent Mode:<br>Transparent Input | Discusses editing and forwarding of data.                                                                                               |



| <b>Subsection</b>                                      | <b>Description</b>                                                           |
|--------------------------------------------------------|------------------------------------------------------------------------------|
| Transparent Mode:<br>Output                            | Summarizes how the network sends output to your terminal.                    |
| Virtual Line and<br>Transparent Modes:<br>Flow Control | Discusses the use of X-ON/X-OFF flow control and EIA flow control.           |
| Virtual Line and<br>Transparent Modes:<br>Interrupts   | Describes the use of the BREAK key, ATTENTION_CHARACTER, and user interrupt. |

## Virtual Line Mode: Data Placement

The network sends your terminal certain sequences, defined by terminal attribute-settings, that affect the appearance of your input and output. What your terminal does with these depends upon how your terminal interprets the characters used in the sequences. As required, you can change these settings to meet your programming aims or to match your terminal's operations.

Some terminology used in these settings, as well as other attributes, originally applied to printers and hardcopy terminals. Now this terminology also applies to video-display terminals. In other words, you use the same terms to describe positioning of a cursor on a screen as paper in a printer. For example in this manual, pressing the RETURN key means you perform a carriage return (send an `END_LINE_CHARACTER` to the network). On the display terminal, the cursor moves; on the printer, the carriage moves to the left margin.

## Using Cursor Positioning Sequences

The following terminal attributes are associated with sequences that affect the placement of the cursor on your screen or printed page. The network sends your terminal a sequence whenever a particular event occurs. It does this by monitoring data that is being transmitted to and from your terminal.

| <b>Terminal Attribute</b> | <b>Abbreviation</b> |
|---------------------------|---------------------|
| CARRIAGE_RETURN_SEQUENCE  | CRS                 |
| END_PAGE_ACTION           | EPA                 |
| FORM_FEED_SEQUENCE        | FFS                 |
| LINE_FEED_SEQUENCE        | LFS                 |
| END_OUTPUT_SEQUENCE       | EOS                 |

The network uses the first four sequences to position virtual line data on your screen or printed page. How they affect the appearance of data is described later in this chapter under the following topics.

- Editing NORMAL data (input)
- End-of-line positioning (output)
- End-of-page positioning (output)

END\_OUTPUT\_SEQUENCE performs end-of-message processing in both virtual line and transparent modes. (Chapter 3 describes this terminal attribute.)

## Delaying Data Transmission

If your terminal needs additional time to reposition, the network uses delays established by three terminal attributes to stop the transmission of output so that your terminal or printer can position itself without losing any data. These delays are associated with the following terminal attributes.

| <b>Terminal Attribute</b> | <b>Associated Delay (Abbreviation)</b> |
|---------------------------|----------------------------------------|
| CARRIAGE_RETURN_SEQUENCE  | CARRIAGE_RETURN_DELAY (CRD)            |
| FORM_FEED_SEQUENCE        | FORM_FEED_DELAY (FFD)                  |
| LINE_FEED_SEQUENCE        | LINE_FEED_DELAY (LFD)                  |

The delays stop transmission of output for a specified number of milliseconds. During this time, the network sends your terminal NUL characters instead of output. What your terminal or printer does with NUL characters during this time depends upon the operation of the individual device. Most terminals discard these characters. If your terminal does not, you should avoid using delays with it. In most cases, terminals operate without requiring any delays.

### **NOTE**

It is usually older, nonbuffered devices that require carriage return, form feed, and line feed delays.

## Virtual Line Mode: Normal Input

When the network receives normal input in virtual line mode, the network performs cursor positioning and forwards the data to your service. The following terminal attributes determine how it is forwarded and what the network does to position the cursor. The abbreviations are shown in parentheses.

| <b>Terminal Attribute</b>        | <b>Associated Character</b>    |
|----------------------------------|--------------------------------|
| END_LINE_POSITIONING<br>(ELP)    | END_LINE_CHARACTER<br>(ELC)    |
| END_PARTIAL_POSITIONING<br>(EPP) | END_PARTIAL_CHARACTER<br>(EPC) |

Your terminal sends the network each character when you enter it. The network stores these characters until it receives an END\_LINE\_CHARACTER or END\_PARTIAL\_CHARACTER as specified by the associated terminal attribute. It then forwards the characters to the service as a complete or partial transmission.

Whether you end a line of input with an END\_LINE\_CHARACTER or END\_PARTIAL\_CHARACTER (if the PARTIAL\_CHARACTER\_FORWARDING connection attribute is set to ON) determines if the service receives a complete or partial transmission. In both cases, the network does the following:

- Edits the data before forwarding it.
- Marks a field at the beginning of the transmission indicating whether it is complete or partial.
- Performs some type of cursor positioning.


## Forwarding Complete Transmissions

Typically, services expect complete transmissions and the network performing `END_LINE_POSITIONING`. Forwarding a complete transmission begins when you press the `RETURN` key (or equivalent) and your terminal sends the network an `END_LINE_CHARACTER`, which is usually defined as `CR` (ASCII carriage-return character).

Upon receipt of this character, the network does the following:

- Finds the `END_LINE_CHARACTER` in your data.
- Labels the transmission as complete and forwards it to the service.
- Performs `END_LINE_POSITIONING` by sending the terminal the sequence specified for this terminal attribute.

How the service handles the complete transmission depends upon the service.




When the network encounters an `END_LINE_CHARACTER` in your input, it performs `END_LINE_POSITIONING`.

Virtual Line Mode: Normal Input

For example, your cursor is typically repositioned on the left margin of the next line. When you use the Asynchronous protocol, the following defaults are used in `END_LINE_POSITIONING`.

```
END_LINE_CHARACTER=CR
END_LINE_POSITIONING=LFS
LINE_FEED_SEQUENCE=LF
LINE_FEED_DELAY=0
```

When you press the RETURN key, the terminal moves the cursor (or carriage) to the left margin and sends CR (ASCII carriage-return character) to the network as the `END_LINE_CHARACTER`. In response to this character, the network does `END_LINE_POSITIONING` by sending the terminal the `LINE_FEED_SEQUENCE` and a `LINE_FEED_DELAY` if specified. When the terminal receives LF, it moves the cursor (or carriage) to the next line.



The network also finds the `END_LINE_CHARACTER` in the data, labels the transmission complete, and forwards the transmission to the service.

## Forwarding Partial Transmissions

If your service is able to handle segments of data, it might use the `PARTIAL_CHARACTER_FORWARDING` connection attribute. Depending upon the service, there can be some overlapping of time in which entering and processing of data can occur. As a result, the service may operate more efficiently.

When you are using the following setting, the network forwards data whenever it receives an `END_PARTIAL_CHARACTER` in your input.

```
PARTIAL_CHARACTER_FORWARDING=ON
```

If `PARTIAL_CHARACTER_FORWARDING` is OFF, the network does not forward partial transmissions. However, the network forwards a complete transmission whenever an `END_LINE_CHARACTER` appears in the input, regardless of the `PARTIAL_CHARACTER_FORWARDING` setting.

Regardless of the `PARTIAL_CHARACTER_FORWARDING` setting, the network performs `END_PARTIAL_POSITIONING` when the `END_PARTIAL_CHARACTER` occurs.

By labeling a transmission partial, the network is telling the service that more data is needed before the transmission is complete. Whether the service waits for the rest of the transmission, goes ahead and processes the partial transmission, or performs some other action, depends upon the service.


Your cursor is generally repositioned in the same place regardless of whether the network performs `END_LINE_POSITIONING` or `END_PARTIAL_POSITIONING`. (Differences could be produced by changing terminal-attribute settings.)



The network uses different terminal attributes when performing `END_PARTIAL_POSITIONING` than it does when performing `END_LINE_POSITIONING`. With the Asynchronous protocol, the network uses the following defaults.


```
END_PARTIAL_CHARACTER=LF
END_PARTIAL_POSITIONING=CRS
CARRIAGE_RETURN_SEQUENCE=CR
CARRIAGE_RETURN_DELAY=0
```

For example, when you press the key your terminal designates for sending a partial transmission, the terminal moves the cursor (or carriage) down a line and sends LF (ASCII line-feed character) to the network as the `END_PARTIAL_CHARACTER`. In response, the network does `END_PARTIAL_POSITIONING` by sending the terminal the `CARRIAGE_RETURN_SEQUENCE` (and a `CARRIAGE_RETURN_DELAY` if specified). When the terminal receives CR, it moves the cursor (or carriage) to the left margin.



The network also finds the `END_PARTIAL_CHARACTER` in the data, labels the transmission partial, and forwards the transmission to the service.

When the network forwards transmissions to a service, it identifies them as either partial or complete. How the service processes them depends upon the individual service.



**EPC** When the network sees an **END\_PARTIAL\_CHARACTER** on each of these lines, it forwards the partial transmission to the service.

When the network detects the **END\_LINE\_CHARACTER**, it indicates to the service that the transmission (which includes previously forwarded partials) is complete .

**ELC**

## Editing Normal Data

While editing normal data in virtual line mode, the network looks for the characters listed in the following table. When the network encounters one of these characters, it performs a special action, as summarized in the table and described in detail in chapters 3 and 4.

| <b>Character</b> | <b>Action</b>                                                                                                                                                                          |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AC               | CDCNET performs the attention character action, as defined by the ATTENTION_CHARACTER_ACTION connection attribute if the connection attribute ATTENTION_CHARACTER_ENABLE is set to ON. |
| BC               | CDCNET backspaces one character over the current input line, but only if the STORE_BACKSPACE_CHARACTER connection attribute is set to OFF.                                             |
| BLC              | CDCNET discards the BLC and recognizes the beginning of a new line of input when this character follows an END_LINE_CHARACTER.                                                         |
| CLC              | CDCNET cancels the line being edited when this character is followed by an END_LINE_CHARACTER.                                                                                         |
| DC1 & DC3        | CDCNET recognizes these flow control characters if the terminal attribute CHARACTER_FLOW_CONTROL is set to ON or OUTPUT and OUTPUT_FLOW_CONTROL_ENABLE is set to ON.                   |
| ELC              | CDCNET recognizes the end of a line of input data when it receives this character.                                                                                                     |
| EPC              | CDCNET recognizes the end of a partial line of input data if the PARTIAL_CHARACTER_FORWARDING connection attribute is set to ON and it receives this character.                        |

| <b>Character</b> | <b>Action</b>                                                                                                                                                                                   |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| NCC              | When an input line begins with this character and ends with an <code>END_LINE_CHARACTER</code> , CDCNET attempts to execute the input line as a user interrupt or CDCNET terminal user command. |
| NUL & DEL        | CDCNET forwards NULs and DELs to the connected service if the <code>STORE_NULS_AND_DELS</code> connection attribute is set to ON.                                                               |

## Virtual Line Mode: Output

When the network receives virtual line mode output from a service, it formats and translates it as needed. The translating includes converting data to the specified coded character set and changing the formatting characters the service uses to the appropriate network sequences. The following topics in this section describe how terminal attributes affect the appearance of virtual line output on your screen or printed page.

| <b>Topic</b>                   | <b>Description</b>                                                                                      |
|--------------------------------|---------------------------------------------------------------------------------------------------------|
| Formatting virtual line output | Describes the formatting characters and the corresponding network sequences.                            |
| End-of-line positioning        | Outlines the terminal attributes that may affect the placement of a single line on your screen or page. |
| End-of-page positioning        | Enumerates the terminal attributes that may affect the formatting of an entire screen or page of data.  |

## Formatting Virtual Line Output

When a service sends output to your terminal in virtual line mode, the network expects it to contain certain characters that indicate how the output should be formatted on your screen or page.

| <b>Characters</b> | <b>Description</b>                                                                                                                                                                                                            |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ASCII characters  | Virtual line output is composed of 7-bit ASCII characters. These characters are grouped into transmissions of zero or more data characters.                                                                                   |
| Unit separator    | The network expects each transmission displayed or printed at your terminal to end with an ASCII unit-separator character (US).                                                                                               |
| Format effectors  | A service can send virtual line output to the network with format effectors or without format effectors. These characters, which occur in the first position of a line, control the positioning of printed or displayed data. |

How output appears on your screen or printed page depends upon the service's use of format effectors and certain ASCII characters. A service can control the appearance of output by doing any of the following:

- Using certain ASCII characters (CR, LF, FF)
- Omitting format effectors
- Using format effectors

## Using Certain ASCII Characters

The network translates most characters in virtual line output to the specified coded character set before transmitting them to the terminal. The following three ASCII characters that the network uses to position output are the only exceptions.

| <u>ASCII Character</u> | <u>Terminal-Attribute Setting Sent by Network</u> |
|------------------------|---------------------------------------------------|
| CR                     | CARRIAGE_RETURN_SEQUENCE                          |
| FF                     | FORM_FEED_SEQUENCE                                |
| LF                     | LINE_FEED_SEQUENCE                                |

When the network receives one of these characters, it sends your terminal the sequence for the appropriate terminal attribute. As a result, the service is able to control end-of-line and end-of-page positioning through its use of these three characters.

## Omitting Format Effectors

If the service does not use format effectors, the network treats each transmission as if it began with a space format effector. In other words, the network sends your terminal a CARRIAGE\_RETURN\_SEQUENCE and LINE\_FEED\_SEQUENCE before each line. When the output is displayed or printed, it is single spaced.

## Using Format Effectors

In virtual line mode, a service can use format effectors to control the appearance of output on your screen or printed page. In such cases, the network processes the first character of each transmission and the first character after each ASCII unit-separator (US) as a format effector.

*Format Effectors*

The network converts the format effectors into terminal attribute-defined sequences and sends them to your terminal for line and page positioning.

Table 5-1 lists the format effectors that affect positioning before a line is displayed, and table 5-2 lists those that affect positioning afterwards.

**Table 5-1. Positioning Before Output**

| <b>Format Effector</b>                         | <b>Terminal Attribute(s) Sent by the Network</b>                                                      |
|------------------------------------------------|-------------------------------------------------------------------------------------------------------|
| +                                              | CARRIAGE_RETURN_SEQUENCE                                                                              |
| 0                                              | CARRIAGE_RETURN_SEQUENCE, LINE_FEED_SEQUENCE, and LINE_FEED_SEQUENCE <sup>1</sup>                     |
| -                                              | CARRIAGE_RETURN_SEQUENCE, LINE_FEED_SEQUENCE, LINE_FEED_SEQUENCE, and LINE_FEED_SEQUENCE <sup>1</sup> |
| ,                                              | None                                                                                                  |
| *                                              | FORM_FEED_SEQUENCE                                                                                    |
| space                                          | CARRIAGE_RETURN_SEQUENCE and LINE_FEED_SEQUENCE <sup>1</sup>                                          |
| ASCII character not listed in table 5-1 or 5-2 | CARRIAGE_RETURN_SEQUENCE and LINE_FEED_SEQUENCE <sup>1</sup>                                          |

1. If an input line precedes the output line, the network sends one less LINE\_FEED\_SEQUENCE to compensate for the positioning performed in response to the preceding input.



**Table 5-2. Positioning After Output**

| <b>Format Effector</b> | <b>Terminal Attribute(s) Sent by the Network</b>   |
|------------------------|----------------------------------------------------|
| . (period)             | CARRIAGE_RETURN_SEQUENCE and<br>LINE_FEED_SEQUENCE |
| / (slant)              | CARRIAGE_RETURN_SEQUENCE                           |

*Example*

This example is based on two assumptions:

- The service controls output appearance with format effectors.
- Your terminal is using the following default settings for the Asynchronous protocol:

```
CARRIAGE_RETURN_SEQUENCE=CR
LINE_FEED_SEQUENCE=LF
```

If the network detects a zero (0) in the first position of a line, it sends the CARRIAGE\_RETURN\_SEQUENCE and LINE\_FEED\_SEQUENCE as specified in table 5-1. In other words, it sends your terminal the following ASCII characters to double space the output.

```
CR
LF
LF
```

Your terminal interprets these characters and normally positions the cursor at the left margin and performs two line feeds.


## End-of-Line Positioning

The following terminal attributes control how lines of virtual line output appear on your screen or printed page. Abbreviations for these attributes are shown in parentheses.

| <b>Terminal Attribute</b>      | <b>Description</b>                                                                                                                             |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| PAGE_WIDTH (PW)                | Determines the maximum number of characters on a line.                                                                                         |
| FOLD_LINE (FL)                 | Indicates whether the network performs line folding.                                                                                           |
| CARRIAGE_RETURN_SEQUENCE (CRS) | Is used in line folding.                                                                                                                       |
| CARRIAGE_RETURN_DELAY (CRD)    | Is available when CARRIAGE_RETURN_SEQUENCE is sent to your terminal or when the terminal is folding lines that exceed its physical page width. |
| LINE_FEED_SEQUENCE (LFS)       | Is used in line folding.                                                                                                                       |
| LINE_FEED_DELAY (LFD)          | Is available when LINE_FEED_SEQUENCE is sent to your terminal or when the terminal is folding lines that exceed its physical page width.       |

## Determining PAGE\_WIDTH

The setting of PAGE\_WIDTH determines the width of an output line. If the virtual lines sent by your service exceed the PAGE\_WIDTH setting, the line can be folded so that subsequent output is displayed on the next line.



PAGE\_WIDTH is the number of characters per line.


## Using FOLD\_LINE

Your terminal may automatically fold lines, in which case FOLD\_LINE is usually set to OFF. If it does not, you may want to change the setting. If FOLD\_LINE is ON, the network performs line folding as follows:

1. The network folds a line if placing a character on a line would exceed the PAGE\_WIDTH setting.
2. The network folds the line after placing up to the number of characters specified by PAGE\_WIDTH on that line and then performs screen or paper positioning to output the remainder on the next line. The network does this by sending the terminal a LINE\_FEED\_SEQUENCE followed by a CARRIAGE\_RETURN\_SEQUENCE.
3. If a CARRIAGE\_RETURN\_DELAY or LINE\_FEED\_DELAY is specified to provide additional time for carriage or cursor positioning, the network sends NUL characters after the CARRIAGE\_RETURN\_SEQUENCE or LINE\_FEED\_SEQUENCE.

1. Finally, the network displays or prints more output on the next line.

For example, if you use the default settings of the Asynchronous TIP, `CARRIAGE_RETURN_SEQUENCE` is CR (ASCII carriage-return character) and `LINE_FEED_SEQUENCE` is LF (ASCII line-feed character). Typically, these settings move your cursor (or carriage) across the page to the beginning of the next line and down a line.



## End-of-Page Positioning

The following terminal attributes control how virtual line output appears on your screen or printed page. Abbreviations for these attributes are shown in parentheses.

| <b>Terminal Attribute</b> | <b>Description</b>                                                                                                |
|---------------------------|-------------------------------------------------------------------------------------------------------------------|
| PAGE_LENGTH (PL)          | Determines the maximum number of lines on a page.                                                                 |
| HOLD_PAGE (HP)            | Indicates whether or not the network stops output at the end of a page and waits for you to press the RETURN key. |
| HOLD_PAGE_OVER (HPO)      | Indicates whether or not the network places an <OVER> message at the end of a page.                               |
| END_PAGE_ACTION (EPA)     | Indicates whether or not the network uses the FORM_FEED_SEQUENCE to divide your output into pages.                |
| FORM_FEED_SEQUENCE (FFS)  | May be specified by END_PAGE_ACTION.                                                                              |
| FORM_FEED_DELAY (FFD)     | Is available when FORM_FEED_SEQUENCE is sent to your terminal.                                                    |


## Determining PAGE\_LENGTH

While the PAGE\_LENGTH setting determines the number of lines on your screen or printed page, the actual number you see is one less than the setting if either of the following conditions exist:

- HOLD\_PAGE is set to ON.
- END\_PAGE\_ACTION is set to FFS and FORM\_FEED\_SEQUENCE is specified (not blank).

Then the last line of PAGE\_LENGTH is reserved for network communications (such as the <OVER> prompt).

PAGE\_LENGTH is the number of lines per page.




## Changing Pages

When the `PAGE_LENGTH` setting is reached, what happens next depends upon the settings of other terminal attributes.


1. If `HOLD_PAGE` is ON, the network stops sending output until you indicate you are ready for more. You usually do this by pressing the RETURN key.

When `HOLD_PAGE` is ON, the network expects you to press the RETURN key to restart output on the next screen.



2. If `HOLD_PAGE` is ON, you can decide whether to receive `<OVER>` prompts. When `HOLD_PAGE_OVER` is ON, the network automatically sends a prompt at the end of every page.


When `HOLD_PAGE_OVER` is ON, the prompt appears on the last line of `PAGE_LENGTH`.



3. If `END_PAGE_ACTION` is set to FFS, the network sends the `FORM_FEED_SEQUENCE` to your terminal. The network sends this sequence regardless of whether `HOLD_PAGE` is ON or OFF.

4. If a `FORM_FEED_DELAY` is specified, the network sends it after the `FORM_FEED_SEQUENCE` to provide additional time for your terminal to reposition its cursor (or carriage).

For example, if you use the Asynchronous TIP default setting, `FORM_FEED_SEQUENCE` is FF (ASCII form-feed character). As a result of this setting, your terminal typically positions the cursor at the top of the screen or rolls a new page of paper into place.



The `FORM_FEED_SEQUENCE` tells your terminal how to position itself for subsequent output.

If a `FORM_FEED_DELAY` is specified, the network sends it after the `FORM_FEED_SEQUENCE` to provide additional time for repositioning.



## Transparent Mode: Transparent Input

When you enter input data in transparent mode, you use the following connection attribute setting, and the network forwards input data in transparent mode.

```
INPUT_EDITING_MODE=TRANSPARENT
```

### Editing Transparent Data

In contrast to normal input, the network performs limited editing on transparent data. It only uses the following terminal attributes:

```
ATTENTION_CHARACTER
CHARACTER_FLOW_CONTROL
ECHOPLEX
END_OUTPUT_SEQUENCE
PARITY
STATUS_ACTION
FUNCTION_KEY_CLASS
```

The network does not respond to network commands when handling TRANSPARENT input. However, it does recognize the following:

- ATTENTION\_CHARACTER
- BREAK key
- DC1 and DC3 characters (if CHARACTER\_FLOW\_CONTROL is set to ON)

## Forwarding Transparent Data

The service usually begins, controls, and ends transparent mode (both input and output) without your intervention. (See chapter 6 for a description of the transparent input editing mode escape sequence.)

Three connection attributes govern the forwarding and terminating of transparent data (input). Each of these depends upon a specific condition being fulfilled. (See chapter 4 for a description of these connection attributes.)

| <b>Condition</b> | <b>Connection Attribute</b>                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Timeout          | <p><b>TRANSPARENT_TIMEOUT_MODE</b></p> <p>Identifies the action the network takes after a specified input inter-character time out. The length of this period depends upon your line speed.</p>                                                                                                                                                                                                                                                                     |
| Length           | <p><b>TRANSPARENT_LENGTH_MODE</b></p> <p>Identifies the action the network takes when it has received the number of characters specified by the <b>TRANSPARENT_MESSAGE_LENGTH</b> connection attribute.</p>                                                                                                                                                                                                                                                         |
| Character        | <p><b>TRANSPARENT_CHARACTER_MODE</b></p> <p>Identifies the action the network takes under the following conditions:</p> <ul style="list-style-type: none"> <li>● When data entered from your terminal contains a character specified by either the <b>TRANSPARENT_FORWARD_CHARACTER</b> or <b>TRANSPARENT_TERMINATE_CHARACTER</b> connection attribute.</li> <li>● As a result of what is specified in the <b>FUNCTION_KEY_CLASS</b> terminal attribute.</li> </ul> |

You can use one or a combination of these connection attributes to forward and terminate your data.

## Transparent Mode: Output

The network sends transparent output in transparent mode to your terminal unformatted and untranslated. Since it does not perform any end-of-line or end-of-page positioning, the terminal displays data exactly as the service sends it.

If, however, PARITY is EVEN, ODD, MARK, or ZERO, the network ensures that transparent output conforms to the setting. When PARITY is NONE, output is delivered as 8-bit data.

## Virtual Line and Transparent Modes: Flow Control

Sometimes your terminal or the network sends virtual line or transparent data faster than the receiver can handle it. To prevent loss of input and output data, the network supports two kinds of automatic flow control:

| Type of Flow Control                     | Description                                                                                                                                                                                                                                                                                                                             |
|------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| X-ON/X-OFF                               | You can control the sending of X-ON/X-OFF characters with the CHARACTER_FLOW_CONTROL terminal attribute. The setting affects the flow of data between the terminal and the network. (See Inadvertent Flow Control in chapter 9 and the description of the CHARACTER_FLOW_CONTROL terminal attribute in chapter 3 for more information.) |
| EIA (Electronics Industries Association) | The site administrator can set a DEFINE_LINE parameter to control the use of EIA flow control. Setting this parameter to ON or OFF only affects the flow of input data. However, EIA flow control always applies to output. (See Understanding Configuration Options in chapter 1.)                                                     |

## X-ON/X-OFF Flow Control

When `CHARACTER_FLOW_CONTROL` is set to ON, the X-ON/X-OFF protocol regulates transmission of both input and output data by using ASCII characters. In other words, the terminal and the network control data flow by sending each other DC1 and DC3 characters:

- X-OFF (DC3) turns off transmission.
- X-ON (DC1) turns on transmission.

### Automatic Control

The terminal sends DC1 and DC3 characters to control the flow of output being sent by the network. Many terminals automatically send a DC3 character when they cannot handle any more data and then send a DC1 character when they are ready for additional data. The latter means that the terminal has moved most of the data previously received to its screen, a flexible disk, or other destination, and can handle more data.

Similarly, the network sends DC1 and DC3 characters to control the flow of input from the terminal. The network sends a DC3 character when the connection to the service becomes congested, and sends a DC1 character when the connection becomes uncongested.

If either your input or output contains DC1 or DC3 characters that you do want handled as data, you can use EIA flow control instead of `CHARACTER_FLOW_CONTROL`. If you need to do so, contact your site administrator.

## Manual Control

If necessary, you can manually send X-ON/X-OFF characters to control data flow. This manual option is advantageous when you are either using a terminal that does not support automatic flow control, are experiencing communications difficulties, or are scanning a large output file.

- To stop output, press the CONTROL key and hold it down while you press S. This control sequence forces the terminal to send the network an X-OFF character (DC3).
- To restart output, press the CONTROL key and hold it down while you press Q. This control sequence forces the terminal to send the network an X-ON character (DC1).

## EIA Flow Control

The `EIA_FLOW_CONTROL` parameter on the `DEFINE_LINE` network configuration command determines whether Clear to Send (CTS) and Request to Send (RTS) flow control signals are used by the TDI to stop and resume the flow of the terminal's input data.

When EIA flow control is enabled and the TDI cannot accept terminal input data due to temporary network congestion, the TDI drops its RTS signal, causing the terminal to see its CTS signal drop. A drop of the CTS signal is an indication to the terminal that it should temporarily suspend input transmission. When the TDI can accept input data again it raises its RTS signal, causing the terminal to see its CTS signal raise. This indicates that it is clear to resume transmission of input data.

The terminal can use its RTS signal in the same manner to control the flow of the TDI's output data. Use of EIA flow control by the terminal is always available and is not subject to the `EIA_FLOW_CONTROL` parameter on the `DEFINE_LINE` network configuration command.

When both EIA flow control and character flow control are enabled, the TDI uses EIA flow control to control the terminal's input and the TDI recognizes both types of signals as output flow control requests from the terminal.

Although EIA flow control can be used at the same time as `CHARACTER_FLOW_CONTROL`, there are times when you should only use the former. For example, you should select the EIA option

when transferring data using the full 256-character set, and when transmitting data containing DC1 and DC3 characters. If you want to avoid using `CHARACTER_FLOW_CONTROL` and do not know whether your site controls input with EIA flow control, contact your site administrator.



# **Terminal User Exception Processing 6**

---

- User Interrupts ..... 6-1
  - Entering User Interrupts with the Network Command Character..... 6-3
  - Entering User Interrupts with the BREAK Key or Attention Character..... 6-4
  
- Special Sequences ..... 6-5
  - Delete All Existing Connections ..... 6-5
  - Terminate Transparent Editing Mode ..... 6-7
  - Escape to the \$NET Connection While in Transparent Mode .... 6-8





Terminal user exception processing allows you to send special signals to your connected service and to CDCNET. CDCNET supports two types of signals, as follows:

- User interrupts (signals to your connected service)
- Special sequences (signals to CDCNET)

User interrupts allow you to send a single character to your connected service.

Special sequences allow you to send specific key/character sequences to CDCNET. CDCNET takes specific actions after recognizing one of these specific sequences.

## User Interrupts

Interrupts are control signals sent to your connected service that request the service to temporarily or permanently stop its current activity and begin a new or different activity. This new activity is determined by the value of the character or numeric following the network control character used by your site to identify a user interrupt to the service.

CDCNET processes single-character user interrupts that are either numeric, in the range 0 through 9, or alphabetic. When you enter a user interrupt on a working connection, CDCNET synchronizes the connection and supplies the associated numeric or alphabetic character to the application as the reason code. This reason code is sent to the application as expedited data, and is therefore not subject to the flow control constraints of normal data (in other words, it is not queued behind other data in the input data buffers). It is the responsibility of the application to respond to the user interrupt.

If the interrupt character is a numeric in the range 1 through 9, CDCNET synchronizes the connection and discards any input and output that might currently be held in network queues for the connection. If the interrupt character is 0, CDCNET discards only the input. If the interrupt character is alphabetic, CDCNET does not discard input or output. These actions are summarized in the following table:

| <b>Interrupt Character</b> | <b>Action</b>                                                                                                                                                                  |
|----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 through 9                | The connection is synchronized and both input and output are discarded. The interrupt character is forwarded to the application as the reason code for the synchronization.    |
| 0                          | The connection is synchronized and only input is discarded. A reason code of 0 is forwarded to the application.                                                                |
| Alphabetic                 | The connection is synchronized, but neither input nor output is discarded. The interrupt character is forwarded to the application as the reason code for the synchronization. |

If an additional user interrupt is entered before the network receives a response from the application to a user interrupt already being processed, the additional interrupt is ignored. User interrupts entered on the \$NET connection are also ignored. In either case, CDCNET displays the following message:

User interrupt ignored.

You can enter user interrupts while in normal or transparent input editing mode. However, CDCNET recognizes a different type of user interrupt for each mode. You can enter a user interrupt by:

- Using the network command character
- Using the BREAK key or an attention character

In some cases, you can enter a numeric user interrupt *either* by using the network command character *or* by using the BREAK key or attention character. However, in situations when the network command character is not recognized by the network, you can *only* enter user interrupts with the BREAK key or attention character. The following sections describe how to enter user interrupts in each situation.

## Entering User Interrupts with the Network Command Character

In normal input editing mode, a user interrupt can be entered using the network command character followed by a single alphabetic or numeric character. For example, the following entry causes the connection to be synchronized and a user interrupt 2 to be sent to the application:

```
%2
```

If you enter the network command character followed by a single character that is neither alphabetic nor numeric (for example, %\$), CDCNET interprets the entry as an invalid user interrupt and issues the following message:

```
Invalid user interrupt.
```

User interrupts can also be entered using the attention character or BREAK key, as described next. These alternative methods might be necessary under some conditions, such as when your service connection is operating in transparent input editing mode.

## Entering User Interrupts with the BREAK Key or Attention Character

In transparent input editing mode, you can only enter a user interrupt with the BREAK key or attention character. This is because during transparent mode the network does not sample your input for the network command character.

The `BREAK_KEY_ACTION` connection attribute defines the numeric interrupt that is processed when the BREAK key is used, if your terminal has a BREAK key.

If your terminal does not have a BREAK key, a user interrupt can be entered with the attention character. The character that acts as the attention character is defined by the `ATTENTION_CHARACTER` *terminal* attribute, described in chapter 3. The interrupt that is processed when you enter the attention character is a numeric in the range 0 through 9 defined by the `ATTENTION_CHARACTER_ACTION` *connection* attribute, described in chapter 4.

For example, suppose you have used the following command to set your `BREAK_KEY_ACTION` connection attribute to 2:

```
%CHACA BKA=2
```

Thereafter, if you press the BREAK key you execute the equivalent of a level 2 user interrupt. That is, the following two actions have the same effect:

- Entering %2 (in nontransparent input editing mode)
- Pressing the BREAK key (in transparent input editing mode)

## Special Sequences

As described previously, when you press the BREAK key or enter the attention character, CDCNET synchronizes your working connection and sends the corresponding reason code to the connected service for it to act upon. At this point, CDCNET is poised to accept one of three special character sequences from the terminal. That is, the asynchronous TIP always tests the characters following a BREAK key or attention character for one of the following three special sequences:

- Secure access sequence
- Transparent input editing mode escape sequence
- Escape to \$NET connection sequence

These special character sequences, which cannot be altered, alert CDCNET that you want to do one of the following special tasks, as described in the following sections.

- Delete all existing connections.
- Terminate transparent mode.
- Escape to the \$NET connection while in transparent mode.

### Delete All Existing Connections

When you want to delete all existing service connections, use the secure access sequence. The secure access sequence provides a trusted path to the \$NET connection. At a site where network security is a concern, this sequence can be used to guarantee that your connection is to CDCNET, avoiding the scenario in which you provide your username and password to an application that merely imitates CDCNET and/or the host validation interface.

Delete all existing connections as follows:

1. Press the BREAK key or enter the attention character.
2. While holding down the control key (CTRL) press A, and then T.
3. Press NEXT (or return).

## Special Sequences

CDCNET deletes all existing service connections, resets all terminal and connection attributes to the CDCNET defaults, and issues its banner to your terminal, including the prompt:

You may enter CDCNET commands.

At this point, you are using the \$NET connection and can enter any CDCNET commands that are valid on this connection.

## Terminate Transparent Editing Mode

When your connection is in transparent input editing mode, CDCNET does not sample your input for the network command character. If you need to suspend your session with an application that is running in transparent mode in order to enter a CDCNET command, you can terminate transparent editing mode with the transparent mode escape sequence. Besides forwarding the break condition to the connected application, this sequence causes CDCNET to change your INPUT\_EDITING\_MODE connection attribute from TRANSPARENT to NORMAL. It is then possible to execute a CDCNET command that is prefixed with the network command character.

Terminate the transparent editing mode as follows:

1. Press the BREAK key or enter the attention character.
2. Hold down the control key (CTRL) and press X.
3. Press NEXT (or return).

Following this sequence, you could then enter a CDCNET command, which CDCNET would recognize. For example, if you are engaged in a session with an application that is running in transparent mode and you need to change a connection attribute, you could take the following steps:

1. Enter the transparent mode escape sequence.
2. Enter the CHANGE\_CONNECTION\_ATTRIBUTE command. For example,

```
%CHACA TML=135
```

3. Return to transparent input editing mode with the following CHANGE\_CONNECTION\_ATTRIBUTE command:

```
%CHACA IEM=T
```



## Escape to the \$NET Connection While in Transparent Mode

If you are using the Asynchronous or X.25 protocol and need to escape to the \$NET connection, you can do so with the escape to \$NET connection sequence. Besides forwarding the break condition to the connected application, this sequence causes CDCNET to change your working connection to the \$NET connection without deleting your current working connection or any other existing connections.

If this sequence is used while the `BREAK_KEY_ACTION` connection attribute is set to 0, it is functionally equivalent to executing a `%CHAWC` command without parameters.

Escape to the \$NET connection with the following special break sequence:

1. Press the BREAK key or enter the attention character.
2. Hold down the control key (CTRL) and press C.

CDCNET responds by issuing its banner message, and the prompt:

You may enter CDCNET commands

You can return to the suspended connection with a `CHANGE_WORKING_CONNECTION` command.

# Interactive Terminal Passthrough

---

7

|                                                        |      |
|--------------------------------------------------------|------|
| Becoming a Passthrough Server .....                    | 7-2  |
| Creating a Connection to the Passthrough Service ..... | 7-2  |
| Defining a Passthrough Title .....                     | 7-3  |
| Becoming a Passthrough Client .....                    | 7-4  |
| Managing Passthrough Connections .....                 | 7-4  |
| Putting a Passthrough Connection On Hold .....         | 7-5  |
| Entering Normal Input Editing Mode .....               | 7-5  |
| Letting a Passthrough Connection Time Out .....        | 7-7  |
| Deleting a Passthrough Connection .....                | 7-7  |
| Using the Attention Character or BREAK Key .....       | 7-8  |
| Controlling Passthrough Service Messages .....         | 7-8  |
| Passthrough Attributes .....                           | 7-9  |
| Connection Attributes .....                            | 7-9  |
| Terminal Attributes .....                              | 7-10 |
| Using Flow Control .....                               | 7-10 |
| DEFINE_PASSTHROUGH_TITLE (DEFPT) .....                 | 7-11 |



Interactive terminal passthrough connects two asynchronous users for the purpose of exchanging transparent data. The feature is provided by CDCNET's passthrough service.

Passthrough permits connections between asynchronous end-users, including the following:

- Interactive terminals and hosts foreign to CDCNET
- Interactive terminals and smart dial-out modems
- Two interactive terminals in a conversational mode
- Two microcomputers engaged in a file transfer

The term *passthrough user* refers to any of the types mentioned above. However, the text in this chapter is written for the interactive terminal user and microcomputer user.

All passthrough users fall into one of two categories:

| <b>User Type</b>   | <b>Role Description</b>                                                                   |
|--------------------|-------------------------------------------------------------------------------------------|
| Passthrough Server | Offers services by defining a passthrough title to which passthrough clients can connect. |
| Passthrough Client | Connects to the services offered by a passthrough server.                                 |

This chapter describes how to become a passthrough server or passthrough client, and how to manage a passthrough connection. It also identifies the connection and terminal attributes that are important to passthrough connections, and describes the `DEFINE_PASSTHROUGH_TITLE` command.

Refer to chapter 9 for notes and cautions about using the interactive terminal passthrough service.

## Becoming a Passthrough Server

To become a passthrough server, you must register a title with the passthrough service. This is a two-step process:

1. Create a connection to the passthrough service.
2. Define a passthrough title.

### Creating a Connection to the Passthrough Service

Use the `CREATE_CONNECTION (CREC)` command described in this manual to establish a connection to the passthrough service. The service name of the passthrough service is site-configurable, with a default value of `PASSTHROUGH`.

For example, the following command creates a connection to the passthrough service if the site uses the default passthrough service name.

```
CREC PASSTHROUGH
```

The following message indicates that a connection to the passthrough service was made successfully:

```
Connection to Passthrough Service complete.
```

#### **NOTE**

---

The site must configure the passthrough service into the DI to which the intended server is connected. If the passthrough service is *not* installed when the server attempts to connect to the passthrough service, the `CREATE_CONNECTION` command fails and issues the "Cannot locate service" message.

---

## Defining a Passthrough Title

After connecting to passthrough with CREC, the intended server must next register a server title with the passthrough service. This is done with the `DEFINE_PASSTHROUGH_TITLE` (`DEFPT`) command, described later in this chapter.

If the connection to CDCNET passthrough was made by a terminal user command (that is, `CREC PASSTHROUGH_SERVICE` or `DO TUP_NAME`), the title that is registered is prefixed by the two-character string, `T_`. This signifies that the title was registered by an interactive terminal user, as opposed to site configuration.

If the connection to CDCNET passthrough was made by a TUP that executed automatically when the user connected to the network, the title is registered as it appears on the `DEFPT TITLE` parameter. The absence of the `T_` prefix indicates that the title was registered as the result of site configuration.

The first input after the passthrough connection is created must be a `DEFPT` command. If it is not, the intended server is prompted with the following message:

```
Passthrough input discarded.
Please register titles.
```

### **NOTE**

---

Multiple `DEFPT` commands with the same title are allowed on the same network. This allows passthrough users to access one of many services providing the same function; for example, dial-out modems.

---

## Becoming a Passthrough Client

After one passthrough user becomes a registered server, another user becomes a passthrough client by creating a connection to the server's registered title. This is done using the `CREATE_CONNECTION` (`CREC`) command. Specify a `SERVICE_NAME` value equal to the title registered by the passthrough server.

You are notified if the connection is successful. Message text differs between connections to servers that registered through site configuration and those that registered interactively. Successful connection to a site-defined service brings the following response:

```
Connection to Site Passthrough service service_name complete.
System = system_name, Line = line_name.
```

Successful connection to a user-defined service brings this response:

```
Connection to User Passthrough service service_name complete.
System = system_name, Line =line_name.
```

In either case, the system and line fields indicate the DI system and line names associated with the server.

## Managing Passthrough Connections

Each passthrough server or passthrough client has options for managing its passthrough connection(s). These options are listed below and described afterward:

- Putting a passthrough connection on hold
- Temporarily entering normal input editing mode
- Letting a passthrough connection time out
- Deleting a passthrough connection
- Using the attention character or `BREAK` key
- Controlling passthrough service messages

## Putting a Passthrough Connection On Hold

A working passthrough connection can be put on hold if the passthrough user (client or server) enters the escape to \$NET connection sequence, as described in chapter 6.

After entering this special break sequence, you can enter any CDCNET terminal user commands. For example, you can create another connection with the `CREATE_CONNECTION` (CREC) command, or return to existing connections (including the passthrough connection) using the `CHANGE_WORKING_CONNECTION` (CHAWC) command; all CDCNET terminal user commands are described in this manual.

## Entering Normal Input Editing Mode

The passthrough service only permits communication between passthrough client and server in the transparent input editing mode. In transparent mode you cannot execute CDCNET terminal user commands. However, if you enter the transparent mode escape sequence on this connection, you are temporarily placed in normal mode, from which you can enter terminal user commands.

The transparent mode escape sequence is as follows:

1. Press the `BREAK` key (or `ATTENTION_CHARACTER`).
2. Hold down the `CONTROL` (CTRL) key and press X.

You cannot communicate through passthrough using normal mode, but you *can* enter terminal user commands that are prefixed with the network control character. For example, `%DISPLAY_COMMAND_LIST`, `%DISPLAY_CONNECTION_ATTRIBUTES`, or `%CHANGE_WORKING_CONNECTION`.



The next time you enter something on this connection that is not prefixed with the network control character, the passthrough service resets the connection to transparent input editing mode and discards the input, issuing the following message:

```
Passthrough input discarded.
Passthrough connection attributes reset.
```

The preferred method of resuming transparent mode communication on the passthrough connection is to enter a single end-of-line character. The following message is issued:

```
Passthrough connection attributes reset.
```

This message indicates that the passthrough service has reset your input editing mode to transparent, and that passthrough communication can resume.

## Letting a Passthrough Connection Time Out

A passthrough connection is considered idle if there is no data being passed in either direction. Some passthrough servers use an inactivity timer to disconnect idle connections (refer to the `DEFINE_PASSTHROUGH_TITLE` command described later in this chapter). When this timer approaches a full count, the following message, followed by the ASCII BEL character, is issued to the passthrough user:

```
Passthrough connection connection_name timeout in 30 seconds.
```

If the passthrough connection remains idle for an additional 30 seconds, the following message is issued to the terminal user, and the passthrough connection is disconnected:

```
Passthrough connection connection_name timeout.
```

## Deleting a Passthrough Connection

Passthrough users (either servers or clients) can delete a passthrough connection in one of the following ways:

- By entering a service command to delete the connection, or
- By entering a `$NET` escape sequence (refer to the prior discussion about putting a passthrough connection on hold). The passthrough connection is then deleted using the `DELETE_CONNECTION` (`DELC`) command, described in this manual.

When a *client* deletes the connection, the following message is issued to the *server*:

```
Passthrough client connection disconnected.
```

When a *server* deletes the connection, the following message is issued to the *client*, and the client's connection is disconnected:

```
Passthrough server connection disconnected.
```

These messages are also issued to clients and servers when the network operator discontinues the passthrough service.

## Using the Attention Character or BREAK Key

When you enter the attention character or press the BREAK key, the passthrough service receives a break indication with the BREAK\_KEY\_ACTION value equal to 0. To send a break across the passthrough connection to the other passthrough user, you must issue the equivalent of two break indications (press the BREAK key twice or enter two attention characters). A break indication that is not immediately followed by another break indication is discarded.

### NOTE

---

Because the BREAK key and ATTENTION\_CHARACTER actions use level zero user interrupts, some terminal user input may be lost.

---

## Controlling Passthrough Service Messages

Passthrough service messages are conditionally issued to users based on the value of the RESPONSE\_ACTION (RA) terminal attribute. When you first connect to the passthrough service, the service checks the value of the RA attribute. If RA=SEND, then all passthrough-generated messages are issued directly to your connection. If RA=DISCARD, then these messages are not issued.

### NOTE

---

Passthrough only checks the RA attribute value when the connection is first made. Changing the value of RA after the connection is made has no affect on whether passthrough service messages are forwarded to you. Thus, the appropriate RA value should be selected before you connect to passthrough.

---

## Passthrough Attributes

Both the client and server connections are put in transparent input editing mode when a passthrough client connects to a passthrough server. This gives the server and/or client complete control of the input editing and output formatting.

### Connection Attributes

The following passthrough connection attribute values are set in a passthrough connection, and *cannot* be changed.

```

INPUT_EDITING_MODE = TRANSPARENT
INPUT_OUTPUT_MODE = FULLDUPLEX
BREAK_KEY_ACTION = 0
ATTENTION_KEY_ACTION = 0

```

INPUT\_OUTPUT\_MODE is set to full duplex so that the client and server can emulate the input/output mode of their choice.

Both the BREAK\_KEY\_ACTION and ATTENTION\_CHARACTER\_ACTION are set to zero so that only input is synchronized when passing the break condition through the network. If you try to change either of these values they are reset immediately to zero by the passthrough service.

The default values for passthrough's data-forwarding connection attributes are as follows:

```

INPUT_BLOCK_SIZE = 2000
TRANSPARENT_CHARACTER_MODE = NONE
TRANSPARENT_FORWARDING_CHARACTERS = CR LF 8A(16) 8D(16)
TRANSPARENT_LENGTH_MODE = FORWARD
TRANSPARENT_MESSAGE_LENGTH = line_speed divided by 40
TRANSPARENT_TIMEOUT_INTERVAL = 2
TRANSPARENT_TIMEOUT_MODE = FORWARD

```

---

### NOTE

These connection attribute settings are appropriate for most passthrough connections, and result in the best network performance. Although you may change connection attributes, Control Data does not recommend it.

---

## Terminal Attributes

The `ATTENTION_CHARACTER` terminal attribute should be set to `NUL` for passthrough connections. Otherwise, you cannot transmit the attention character to the destination because it is processed the same as the `BREAK` key.

## Using Flow Control

Flow control on passthrough connections is highly recommended. Use the `CHANGE_TERMINAL_ATTRIBUTES` (`CHATA`) command to change character flow control. The following are guidelines for helping you choose the correct flow control:

- For dedicated lines, use EIA flow control with `RTS/CTS` signals, if your cabling and your device support it. Use of EIA flow control must be coordinated with your site administrator.
- Configurations that do not support EIA flow control (certain direct connections to hosts and microcomputers, for example), should use character flow control.
- Character flow control should also be used for connections involving a dial-out modem.
- For binary file transfers, use character flow control, but only if the binary data does not include embedded `X-ON/X-OFF` characters; these characters in binary data can cause the file transfer to suspend indefinitely. (For example, because `XMODEM` allows `X-ON/X-OFF` characters to be part of data, do not use character flow control.)

It may be possible to do without flow control for low-speed, low-volume data transfers, but only if the file transfer protocol can recover from lost or partially lost file transfer data units.

**DEFINE\_PASSTHROUGH\_TITLE (DEFPT)**

**Purpose** Registers the title(s) for a passthrough server, enabling another person or service to connect to your server for the exchange of data.

The DEFINE\_PASSTHROUGH\_TITLE command should not be prefixed with the network command character. DEFPT is a command that is acted upon by the passthrough service, not by \$NET.

**Format** DEFINE\_PASSTHROUGH\_TITLE  
 TITLE = name  
 INACTIVITY\_TIMER = integer or keyword

**Parameters** TITLE (T)

Specifies the title(s) to be registered with the passthrough service. These are the names that a passthrough client uses on the CREATE\_CONNECTION command. If you specify more than one name, enclose the names in parentheses and separate them with spaces.

*INACTIVITY\_TIMER (IT)*

Specifies the maximum time, in seconds, that a passthrough connection can remain idle. If no data is transferred in either direction on the connection for the specified length of time, the passthrough connection is disconnected. Allowed values are any integer from 120 through 14400, or the keyword INFINITE. If you specify INFINITE, the network does not disconnect the connection because of inactivity.

If you do not specify a value for this parameter, the network uses the value the site administrator specified when the passthrough service was defined.

**Remarks** If the connection to CDCNET passthrough was made by a terminal user command (that is, CREC passthrough\_ service or DO tup\_name), the title that is registered is prefixed by the two-character string, T\_. This signifies that the title was registered by an interactive terminal user, as opposed to site configuration.

If the connection to CDCNET passthrough was made by a TUP that executed automatically when the user connected to the network, the title is registered as it appears on the DEFPT TITLE parameter. The absence of the T\_ prefix indicates that the title was registered as the result of site configuration.

Multiple DEFPT commands with the same title are allowed on the same network. This allows passthrough users to access one of many services providing the same function; for example, dial-out modems.

**Examples** Suppose you connect a microcomputer to the network that is able to provide services to other microcomputers (such as electronic mail management). You make these services available on the network in the following steps:

1. Create a connection to the passthrough service (assuming your site uses the default passthrough service name, PASSTHROUGH):

```
CREC PASSTHROUGH
```

2. Register as a passthrough server with the following command:

```
DEFPT T=MAILPC IT=INFINITE
```

Subsequently, other microcomputers on the network can connect to your service with the following command:

```
%CREC T_MAILPC
```

**Responses** If the DEFPT command is successful, the following response is returned:

```
Passthrough service titles registered.
```

You can now receive connections from passthrough clients.

If, for any reason, the titles cannot be registered in the CDCNET directory, the following message is returned:

```
Passthrough service titles not registered.
```

In this case, you should enter the DEFPT command again.

## **X.25 Interactive Terminal Gateway**

**8**

|                                                                    |      |
|--------------------------------------------------------------------|------|
| X.25 Interactive Terminal Gateway Modes .....                      | 8-1  |
| Gateway Command Mode .....                                         | 8-2  |
| Gateway Command Mode Connection Attributes .....                   | 8-2  |
| Data Transfer Mode .....                                           | 8-3  |
| Data Transfer Mode Connection Attributes .....                     | 8-3  |
| X.3 Packet Assembler/Disassembler (PAD) Parameters .....           | 8-5  |
| Connecting to the X.25 Interactive Terminal Gateway .....          | 8-6  |
| Connecting to the X.25 Service .....                               | 8-7  |
| Connecting to the X.25 Service in Two Steps .....                  | 8-8  |
| Connecting to the X.25 Service in One Step .....                   | 8-8  |
| Managing the X.25 Service Connection .....                         | 8-9  |
| Changing Gateway Connection Attributes .....                       | 8-9  |
| Switching Between Gateway Modes .....                              | 8-9  |
| Switching to Gateway Command Mode from Data Transfer<br>Mode ..... | 8-10 |
| Switching to Data Transfer Mode from Gateway Command<br>Mode ..... | 8-10 |
| Deleting a Gateway Connection .....                                | 8-11 |
| X.25 Interactive Terminal Gateway Commands .....                   | 8-11 |
| Terminal Gateway Commands .....                                    | 8-11 |
| CREATE_X25_CONNECTION (CREXC) .....                                | 8-13 |
| DISPLAY_COMMAND_INFORMATION (DISCI) .....                          | 8-16 |
| DISPLAY_COMMAND_LIST_ENTRY (DISCLE) .....                          | 8-18 |
| DISPLAY_X25_SERVICES (DISXS) .....                                 | 8-19 |
| QUIT (QUI) .....                                                   | 8-20 |
| X.28 Commands .....                                                | 8-21 |
| CLR .....                                                          | 8-22 |
| INT .....                                                          | 8-23 |
| PAR? .....                                                         | 8-24 |
| SET .....                                                          | 8-25 |
| STAT .....                                                         | 8-26 |





The X.25 interactive terminal gateway allows asynchronous users to access an X.25 service or a remote DTE on an X.25 public data network (PDN) with CDCNET. As seen in figure 8-1, users can be physically connected anywhere on the network and have access to the gateway via CDCNET.




Figure 8-1. X.25 Interactive Gateway Environment

## X.25 Interactive Terminal Gateway Modes

The gateway has two operating modes; both are discussed in this chapter:

- Gateway command mode
- Data transfer mode

## Gateway Command Mode

Gateway command mode allows you to communicate with the X.25 terminal gateway. Once you have created a connection to the X.25 terminal gateway, you can direct it to perform one of several terminal gateway commands, to modify one of several parameters affecting X.25 communications or to connect to the remote DTE. You communicate with the gateway via several commands, which you enter following a gateway command prompt. The commands available to you in gateway command mode are discussed later in this chapter. The gateway command prompt is:

```
x25/
```

### Gateway Command Mode Connection Attributes

Once you have created a connection to the X.25 terminal gateway, your connection attributes are set by CDCNET as shown in figure 8-2.

|                                 |               |
|---------------------------------|---------------|
| Attention_Character_Action      | : 2           |
| Attention_Character_Enable      | : ON          |
| Break_Key_Action                | : 0           |
| Echo_Enable                     | : ON          |
| Input_Block_Size                | : 160         |
| Input_Editing_Mode              | : NORMAL      |
| Input_Flow_Control_Enable       | : ON          |
| Input_Output_Mode               | : UNSOLICITED |
| Output_Flow_Control_Enable      | : ON          |
| Parity_Enable                   | : ON          |
| Partial_Character_Forwarding    | : OFF         |
| Store_Backspace_Character       | : OFF         |
| Store_NuIs_Dels                 | : OFF         |
| Transparent_Character_Mode      | : TERMINATE   |
| Transparent_Forward_Character   | : CR 8D(16)   |
| Transparent_Length_Mode         | : NONE        |
| Transparent_Message_Length      | : 255         |
| Transparent_Protocol_Mode       | : NONE        |
| Transparent_Terminate_Character | : CR 8D(16)   |
| Transparent_Timeout_Interval    | : 0           |
| Transparent_Timeout_Mode        | : NONE        |

**Figure 8-2. Gateway Command Mode Connection Attribute Defaults**

**NOTE**

---

These connection attributes are appropriate for most X.25 gateway connections, and result in the best network performance. Although you may change connection attributes, Control Data does not recommend it.

---

Once you are connected to the gateway in command mode, you may change any connection attribute using the CHACA terminal interface command as described in chapter 4. CDCNET recognizes the changed attribute value when the X.25 session is established with the X.25 service.

## Data Transfer Mode

Data transfer mode allows you to communicate interactively with a remote DTE. The prompt you receive once your terminal is in data transfer mode depends upon the output from your remote DTE.

### Data Transfer Mode Connection Attributes

Once the remote DTE accepts the incoming call from your terminal (sent while your terminal is in gateway command mode), the gateway enters data transfer mode. The gateway then sets the connection attributes for the remote DTE connection. If you activated a TUP when you created the connection to the gateway, your connection attributes may differ from the default connection attributes (figure 8-3) recognized by CDCNET after establishment of data transfer mode:

|                                 |                               |
|---------------------------------|-------------------------------|
| Attention_Character_Action      | : 0                           |
| Attention_Character_Enable      | : OFF                         |
| Break_Key_Action                | : 0                           |
| Echo_Enable                     | : ON                          |
| Input_Block_Size                | : set to the X.25 packet size |
| Input_Editing_Mode              | : TRANSPARENT                 |
| Input_Flow_Control_Enable       | : ON                          |
| Input_Output_Mode               | : FULLDUPLEX                  |
| Output_Flow_Control_Enable      | : ON                          |
| Parity_Enable                   | : ON                          |
| Partial_Character_Forwarding    | : ON                          |
| Store_Backspace_Character       | : ON                          |
| Store_Nuls_Dels                 | : ON                          |
| Transparent_Character_Mode      | : FORWARD                     |
| Transparent_Forward_Character   | : CR 8D(16) DLE 90(16)        |
| Transparent_Length_Mode         | : FORWARD_EXACT               |
| Transparent_Message_Length      | : set to the X.25 packet size |
| Transparent_Protocol_Mode       | : NONE                        |
| Transparent_Terminate_Character | : NUL                         |
| Transparent_Timeout_Interval    | : 2                           |
| Transparent_Timeout_Mode        | : FORWARD                     |

**Figure 8-3. Data Transfer Mode Connection Attribute Defaults**

#### **NOTE**

These connection attribute settings are appropriate for most X.25 connections. If changes to these default settings are required, they can be made using the %CHACA command.

Once you are operating in data transfer mode, you may change connection attributes, but only to correct a well-defined problem. This is discussed in Changing Gateway Connection Attributes later in this chapter.

## X.3 Packet Assembler/Disassembler (PAD) Parameters

When connected to the X.25 service, certain X.3 packet assembler/disassembler (PAD) parameter values set by the remote X.25 service are mapped to a corresponding connection or terminal attributes supporting your terminal connection. If your terminal supports the X.25 asynchronous protocol, the X.3 PAD parameters are mapped to certain attributes as shown in table 8-1. If your terminal does not support the X.25 asynchronous protocol, the X.3 PAD parameters are mapped to certain terminal attributes as shown in table 8-2.

**Table 8-1. Pad Parameter Mapping Supporting the X.25 Asynchronous Protocol**

| PAD              |                          |                                                          |
|------------------|--------------------------|----------------------------------------------------------|
| Parameter Number | PAD Parameter Name       | Maps to Attribute                                        |
| 2                | Echo                     | Echo_Enable                                              |
| 3                | Forwarding Characters    | Transparent_Forward Character                            |
| 4                | Idle Timer Delay         | Transparent_Timeout_Interval<br>Transparent_Timeout_Mode |
| 5                | Ancillary Device Control | Input_Flow_Control_Enable                                |
| 12               | Flow Control             | Output_Flow_Control_Enable                               |
| 21               | Parity Treatment         | Parity_Enable                                            |

**Table 8-2. PAD Parameter Mapping Supporting Non-X.25 Asynchronous Protocols**

| PAD              |                          |                                                          |
|------------------|--------------------------|----------------------------------------------------------|
| Parameter Number | PAD Parameter Name       | Maps to Attribute                                        |
| 2                | Echo                     | Echoplex                                                 |
| 3                | Forwarding Characters    | No attribute changes                                     |
| 4                | Idle Timer Delay         | Transparent_Timeout_Interval<br>Transparent_Timeout_Mode |
| 5                | Ancillary Device Control | Character_Flow_Control                                   |
| 12               | Flow Control             | Character_Flow_Control                                   |

## Connecting to the X.25 Interactive Terminal Gateway

After accessing CDCNET via an asynchronous terminal interface program (TIP), you can connect to an X.25 interactive terminal gateway with the `CREATE_CONNECTION` terminal user command. The `SERVICE_NAME` parameter of the command must specify the title of the gateway to which you want to connect. Your site administrator knows the gateway titles to which you have access.

Following successful connection to the specified gateway, you receive the CDCNET connection message and the gateway command prompt:

```
Connection connection_name created
x25/
```

You can now create an X.25 connection (with the `CREATE_X25_CONNECTION` terminal gateway command) to the X.25 service to which you want to communicate, or enter any of the supported X.28 commands. These commands are all described later in this chapter.

Refer to figure 8-4 when reading the next paragraphs describing how you connect to an X.25 service and a specific DTE address on that service.




Figure 8-4. Connecting to a DTE on an X.25 Network.

## Connecting to the X.25 Service

You can connect to the X.25 service in one of two ways:

- Create the connection in two steps with the `CREATE_CONNECTION` terminal user command and the `CREATE_X25_CONNECTION` gateway command.
- Create the connection in one step with the `CREATE_CONNECTION` terminal user command.



## Connecting to the X.25 Service in Two Steps

You can connect to the X.25 service in two steps as follows:

1. Create a connection to the X.25 interactive terminal gateway available to you using the `CREATE_CONNECTION` terminal user command. Specify the title of the gateway to which you want to connect on the `SERVICE_NAME` parameter.

```
CREC SN=TELENET
```

CDCNET returns the CDCNET connection message and the gateway command mode prompt:

```
Connection $A created
x25/
```

2. Create a connection to the remote DTE with which you want to communicate using the `CREATE_X25_CONNECTION` gateway command mode command. Specify the destination as either a valid remote DTE address or a valid X.25 service name. The following command requests a connection to a specific service name.

```
CREXC SN=4823337
```

Following the successful execution of the `CREXC` command, CDCNET returns the banner and login prompt of the X.25 service to which you are now connected.

Refer to the description of the `CREATE_X25_CONNECTION` command later in this chapter for more information.

## Connecting to the X.25 Service in One Step

You can connect to the X.25 service in a single step using the `CREATE_CONNECTION` terminal user command to connect to the X.25 gateway and to establish the X.25 connection with the remote DTE.

Enter the `CREATE_CONNECTION` command, specifying values for the `SERVICE_NAME` parameter and the `SERVICE_DATA` parameter.

```
CREC SN=TELENET SD=4823337
```

Following the successful execution of the `CREC` command, CDCNET returns the banner and login prompt of the remote DTE to which you are now connected.

## Managing the X.25 Service Connection

Once established, you can manage the X.25 connection from your terminal in the following ways:

- Changing gateway connection attributes
- Switching between gateway modes
- Deleting a gateway connection

### Changing Gateway Connection Attributes

You can change gateway connection attributes when you are in either gateway command mode or in data transfer mode. Changing connection attributes from either mode involves some risk.

#### **CAUTION**

---

Changing attributes before or during an X.25 session may prevent your terminal from transmitting to the remote DTE, or prevent the remote DTE from responding to your terminal.

---

Should you need to change a connection attribute while in gateway command mode, you can change a connection attribute via the `CHANGE_CONNECTION_ATTRIBUTES` terminal user command. CDCNET recognizes the new value specified by the `CHACA` command when you establish the X.25 session with the remote DTE. This occurs when the gateway enters data transfer mode.

Refer to chapter 2 for a description of the `CHACA` command.

### Switching Between Gateway Modes

Once you are in data transfer mode, you may need to interrupt the remote session, either temporarily or permanently switching to gateway command mode.

## Switching to Gateway Command Mode from Data Transfer Mode

You can switch to gateway command mode from data transfer mode using one of two PAD escape sequences or a CDCNET interrupt sequence via the BREAK key.

- If CCITT X.3 parameter number 1 (Pad Recall Character) value is 1 (Pad Recall With DLE), enter CTRL (P), and press RETURN. Your screen displays the following gateway command prompt:

```
x25/
```

- If CCITT X.3 parameter number 7 (Break Action) value is 8 (Escape from Data Transfer), press the BREAK key twice. This restores the connection to the gateway command mode. This double BREAK key processing depends entirely on the value of the X.3 parameter 7. You cannot pass a BREAK signal to the remote DTE when the specified action is to escape from the data transfer mode. Your screen displays the following gateway command prompt:

```
x25/
```

- If you want to interrupt data transfer mode temporarily by resetting the input editing mode attribute to NORMAL, enter the escape sequence: BREAK CTRL (X). Input editing mode attribute is reset to NORMAL, but the terminal remains in data transfer mode. However, as soon as the gateway receives character input in normal mode, the gateway interprets it as a command and the gateway switches from data transfer mode to gateway command mode. Your screen then displays the following gateway command prompt:

```
x25/
```

To determine the value of CCITT X.3 parameter numbers 1 (Pad Recall Character) and 7 (Break Action) use the gateway command mode command X.28 command PAR?. This command is discussed later in this chapter.

## Switching to Data Transfer Mode from Gateway Command Mode

You can switch back to data transfer mode from gateway command mode by entering a carriage return in response to the X25/ prompt.

```
x25/<carriage return>
```

## Deleting a Gateway Connection

You can delete an X.25 gateway connection from either gateway command mode or data transfer mode, as follows:

- To delete a gateway connection while in gateway command mode, enter the QUIT gateway command following the gateway command mode prompt:

```
x25/QUIT
```

- To delete a gateway connection while in data transfer mode, you must first interrupt data transfer mode using either an X.3 PAD escape sequence described in the preceding section. Enter the CLR X.28 command following the gateway command mode prompt.

```
x25/CLR
CLR CONF
```

The connection to the remote DTE is now deleted. You can now delete the connection in gateway command mode with the QUIT command.

## X.25 Interactive Terminal Gateway Commands

There are two kinds of X.25 interactive terminal gateway commands. Terminal gateway commands allow you to control several aspects of gateway operation, and X.28 commands affect certain X.28 parameters affecting X.25 communication.

X.25 terminal gateway commands are discussed in the following paragraphs. X.28 commands are discussed later in this chapter.

### Terminal Gateway Commands

Terminal gateway commands allow you to create the connection with the remote DTE on an X.25 PDN, to display command and service information available to you within the gateway, and to terminate the connection with the gateway.

The terminal gateway commands include the following commands that follow the SCL syntax conventions:

```
CREATE_X25_CONNECTION
```

```
DISPLAY_COMMAND_INFORMATION
```

X.25 Interactive Terminal Gateway Commands

DISPLAY\_COMMAND\_LIST\_ENTRY

DISPLAY\_X25\_SERVICES

QUIT

**CREATE\_X25\_CONNECTION (CREXC)**

**Purpose** Creates a connection to a remote DTE on a public data network. You can specify either a site-defined name or the decimal DTE address of the remote DTE to which you want to connect. Before specifying the remote DTE to which you want to connect, you may want to check with your site administrator to learn which of the following addressing options are available to you:

- Specify a DTE address that falls within a specified range of DTE addresses. For example, if a range of 3110408\* is configured, only DTE addresses beginning with 3110408 are accepted.
- Specify a service name, which is associated with one or more specific remote DTEs. For example, a particular service name is mapped to one or more specific remote DTEs, depending upon your configuration.
- Specify a complete remote DTE address.

**Format** **CREATE\_X\_25\_CONNECTION**  
**SERVICE\_NAME = name, or string 1..15**

**Parameters** **SERVICE\_NAME (SN, REMOTE\_DTE\_ADDRESS, RDA)**

This parameter identifies the remote DTE to which you want to make the X.25 connection. The following parameter values are valid:

- SN – A parameter entered as a service name must match a site-configured title associated with a complete remote DTE address.
- REMOTE\_DTE\_ADDRESS or RDA – A parameter entered as a string can contain only the characters 0 through 9, and must satisfy the site-configured outcall blocks, if the gateway requires it.

**Responses** CDCNET issues the following responses after receiving an incorrect CREXC command:

--ERROR--Unauthorized remote DTE address specified.  
--ERROR-- A remote\_dte\_address may include only digits 0 through 9.  
--ERROR-- An X.25 connection currently exists.  
--ERROR-- Unable to locate service *service\_name*.  
--ERROR-- Unauthorized remote\_dte\_address specified.  
--ERROR-- Too many parameters given.  
--ERROR-- Parameter **SERVICE\_NAME** is required but was omitted.  
--ERROR-- Connection rejected. No memory is available.  
--ERROR-- Connection rejected. All X.25 logical channels are currently busy.  
--ERROR-- Connection rejected. The network is currently congested.  
--ERROR-- Connection rejected. The local dte address is currently inoperative.  
--ERROR-- Connection broken. The X.25 interface has been stopped by the network operator.  
--ERROR-- Connection broken. The X.25 link is now inoperative.  
--ERROR-- Connection broken. The X.25 link is currently experiencing problems.  
--ERROR-- Connection broken. The remote DTE has cleared the connection. Clearing cause code=XX and diagnostic code=YY.  
--ERROR-- Connection broken. The local DTE has cleared the connection. Clearing cause code=XX and diagnostic code=YY.  
--ERROR-- Connection broken. The X.25 link has temporarily gone down.  
--ERROR-- Connection to X.25 Terminal Gateway broken. The network operator has stopped the X.25 Terminal Gateway.

**Examples** The following examples assumes the following outcall blocks have been configured: name1=3110408\*, name2=1311061200123.

The following command creates a connection to a remote DTE specifying a service name.

```
x25/CREXC SN=name2
```

Your terminal displays the banner and login prompt from the remote DTE.

The following command creates a connection to a remote DTE by specifying the complete remote DTE address.

```
x25/CREXC RDA=311040800123
```

Your terminal displays the banner and login prompt from the remote DTE.

The following command attempts to create a connection to a remote DTE by specifying the complete remote DTE address.

```
x25/CREXC RDA=62600123
```

Your terminal displays the following message:

```
--ERROR--Unauthorized remote DTE address specified.
```



## DISPLAY\_COMMAND\_INFORMATION (DISCI)

**Purpose** Displays the parameters and parameter syntax information for a specified X.25 terminal gateway command and the associated X.28 commands. The specified command must be one of the available X.25 gateway or X.28 commands.

**Format** **DISPLAY\_COMMAND\_INFORMATION**  
**COMMAND = name of command**

**Parameters** **COMMAND (C)**

Specifies the command for which the parameters are to be displayed. You must provide either the full command name or the command abbreviation. The specified command must be one of the following X.25 terminal gateway or X.28 commands:

CREATE\_X25\_CONNECTION

DISPLAY\_COMMAND\_INFORMATION

DISPLAY\_COMMAND\_LIST\_ENTRY

DISPLAY\_X25\_SERVICES

QUIT

CLR

INT

PAR?

SET

STAT

**Responses** List of parameter names, parameter abbreviations, and parameter syntax for the specified command. (See example.)

--ERROR--xxxx is not a command.

--ERROR-- Parameter COMMAND is required but was omitted.

--ERROR-- Too many parameters given.

**Examples** The following command requests a display of the parameters and syntax of the CREXC command.

```
x25/DISCI CREXC
```

Your terminal displays the following information:

```
service_name,sn,remote_dte_address,rda: string 1..15
```

or

```
$name = $required
```

The following command requests a display of the parameters and syntax of the X.28 command SET:

```
x25/DISCI SET
```

Your terminal displays the following information:

```
CCITT syntax - number1:value,number2:value ..
number22:value
```

## DISPLAY\_COMMAND\_LIST\_ENTRY (DISCLE)

**Purpose** Displays the commands available after you have established a connection to the X.25 terminal gateway and the gateway is in gateway command mode. CDCNET issues the gateway command mode prompt (x25/) to your terminal when you enter gateway command mode.

**Format** DISPLAY\_COMMAND\_LIST\_ENTRY

**Parameters** None.

**Responses** List of commands available while you are in gateway command mode. (See example.)

--ERROR-- Too many parameters given.

**Examples** The following command requests a list of the commands available during the current X.25 terminal gateway session:

```
x25/DISCLE
```

Your terminal displays the following information:

```
X.25 Terminal Gateway Commands
```

```
create_x25_connection
display_command_information
display_command_list_entry
display_x25_services
quit
```

```
X.28 Commands
```

```
clr
int
par?
set
stat
```

**DISPLAY\_X25\_SERVICES (DISXS)**

**Purpose** Displays the list of site-configured service names with their associated remote DTE addresses. Note that the fully specified service names with no wildcard characters in their associated remote address can be used in place of the address on a CREC or CREXC command.

**Format** DISPLAY\_X25\_SERVICES

**Parameters** None.

**Responses** List of service names and their associated remote DTE addresses. (See example.)

--ERROR-- Too many parameters given.

**Examples** The following example lists the service names and associated remote DTE addresses:

x25/DISXS

| Service Name | Remote DTE Address |
|--------------|--------------------|
| NAME1        | 33333333           |
| NAME2        | 22222222           |
| NAME4        | 44444444           |
| NAME1        | 11111111           |
| n/a          | 3110612*           |
| n/a          | 3110408*           |
| n/a          | 3110*              |
| n/a          | *                  |

The following example shows the response when your site does not require gateway outcall blocks, and access is unlimited; that is, you can request that an X.25 connection be made to any remote DTE:

x25/DISXS

| Service Name     | Remote DTE Address |
|------------------|--------------------|
| Unlimited Access |                    |

## QUIT (QUI)

- Purpose** Terminates your connection with the X.25 terminal gateway. The command also breaks the corresponding connection with the remote DTE, if one exists.
- Format** QUIT
- Parameters** None.
- Responses** You receive the following response if the X.25 connection successfully terminates:
- You may enter CDCNET commands.
- ERROR-- Too many parameters given.
- Examples** The following example shows the use of the QUIT command.
- x25/QUIT
- CDCNET sends the following response to your terminal.
- You may enter CDCNET commands.

## X.28 Commands

X.28 commands allow you to change or request the status of X.3 PAD parameters affecting X.25 communications with a remote DTE.

The X.28 commands include the following commands that follow the CCITT Recommendation X.28 syntax conventions:

CLR

INT

PAR?

SET

STAT

## CLR

**Purpose** Terminates your X.25 connection with the remote DTE.

**Format** CLR

**Parameters** None.

**Responses** You receive the following response if the X.25 connection with the remote DTE successfully terminates.

CLR CONF

--ERROR-- Too many parameters given.

**Examples** The following example shows the use of the CLR command.

x25/CLR

CDCNET sends the following response to your terminal.

CLR CONF

## INT

**Purpose** Sends an interrupt packet to the remote DTE.

**Format** INT

**Parameters** None.

**Responses** You receive one of the following responses if the interrupt command was not successful.

INT ERR

--ERROR-- Too many parameters given.

**Examples** The following example shows the use of the INT command.

x25/INT



## PAR?

- Purpose** Displays the current values of the X.3 parameter reference numbers.
- Format** PAR?
- Parameters** None.
- Responses** You receive a display of the current values of the X.3 reference numbers.
- ERROR-- Too many parameters given.
- Examples** The following example shows the use of the PAR? command.

```
x25/PAR?
```

```
PAR1:0,2:0,3:2,4:0,5:0,6:0,7:21,8:0,9:0,10:0,11:0,
12:0,13:0,14:0,15:0,16:0,,17:0,18:0,19:0,20:0,
21:0,22:0
```

## SET

- Purpose** Changes the current values of the specified X.3 parameter reference numbers. You can only change the reference numbers supported by the X.25 interactive terminal gateway.
- Format** **SET**  
**NUMBER:VALUE,NUMBER:VALUE**  
**..NUMBER:VALUE**
- Parameters** **NUMBER**  
Specifies the X.3 reference number of the parameter to be changed.
- VALUE**  
Specifies the value to which the X.3 reference number parameter is to be changed.
- Responses** Your terminal displays the gateway command prompt x25/ when the SET command completes successfully. (See example.)
- PAR n:INV**
- PAR INV:N**
- SET ERR**
- Examples** The following example shows the use of the SET command. The X.3 reference number parameter 1 value is changed to 1, and the X.3 reference number parameter 7 value is changed to 8.
- ```
x25/SET 1:1,7:8
```
- ```
x25/
```

## STAT

**Purpose** Checks and displays the state of the X.25 connection to the remote DTE.

**Format** STAT

**Parameters** None.

**Responses** You receive the following response if no X.25 connection exists with a remote DTE.

FREE

You receive the following response if an X.25 connection currently exists with a remote DTE.

ENGAGED

You receive the following response if you have specified too many parameters.

--ERROR-- Too many parameters given.

**Examples** The following example shows the use of the STAT command.

x25/STAT

ENGAGED

**Resolving Communications Problems** **9**

---

Network Failures ..... 9-1

Automatic Recognition Difficulties ..... 9-2

Inadvertent Flow Control ..... 9-3

Accidental Transparent Input ..... 9-3

Passthrough Service Difficulties ..... 9-4

Service Failures ..... 9-6

Cursor Positioning Delays ..... 9-6



This chapter provides some notes and cautions regarding network communications problems. Understanding these concepts can help you to resolve these problems.

- Network failures
- Automatic recognition difficulties
- Inadvertent flow control
- Accidental transparent input
- Passthrough service difficulties
- Service failures
- Cursor positioning delays

## Network Failures

The network may not respond when you enter commands. This lack of response means the network equipment (device interface) you are using may not be functioning properly. Therefore, CDCNET cannot respond to your commands. Wait 5 to 10 minutes, and then try to access CDCNET again. If it still does not respond, call your site administrator.

If your line is defined to use automatic recognition and the network is not responding to your commands, you may be experiencing a problem with automatic recognition. See Automatic Recognition Difficulties, next in this chapter, for information on how to solve this problem.

If you are accessing CDCNET from a PDN, non-CDCNET LAN, or other multiplexing equipment, the problem may be in the other network or equipment rather than CDCNET. As part of your approach to solving the problem, consult the appropriate non-CDCNET documentation.

If you succeed in accessing the network after the failure, or you accessed your service via an alternate route (different device interface), you may discover that your service still lists your previous job as active. For example, you might check job status by entering a service command (such as `DISPLAY_JOB_STATUS` on `NOS/VE`).

You can try to recover this job. If you wait 5 to 10 minutes, the service should suspend the job due to inactivity and then you may be able to recover it.

## Automatic Recognition Difficulties

Your terminal may encounter network communications difficulties during the automatic recognition process:

- When you are initially accessing the network and press the RETURN key (or equivalent) twice.
- When you are using the `ACTIVATE_AUTO_RECOGNITION` command. (See chapter 2 for a description.)

If your terminal does not respond to your input, perform the following steps:

1. Press the BREAK key.
2. Then press the RETURN key twice.

In response, you should receive some output from the network. If you do not, take the following steps:

1. Turn off the power to your terminal.
2. If your terminal has a switch for coded character set (also called character set, code set, etc.), be sure it is set correctly. It is usually ASCII.
3. If you are using a switched line, turn on the power to your terminal and follow your local procedure for connecting a terminal through a modem or data set to the computer.

If your terminal is connected to a dedicated line, turn the power to your terminal on and wait 5 seconds.

4. Press the BREAK key again.
5. Then press the RETURN key twice.

## Inadvertent Flow Control

Sometimes output stops and your terminal does not respond to your input. In these instances, your terminal may have asked the network to stop sending output again.

This happens when you are using the following terminal-attribute setting and the terminal sends an X-OFF character (DC3) to CDCNET.

```
CHARACTER_FLOW_CONTROL=ON
```

To reactivate the flow of data, press the CONTROL key and hold it down while you press Q. This control sequence forces the terminal to send the network an X-ON character (DC1), which directs CDCNET to send your terminal output again.

## Accidental Transparent Input

If output stops and your terminal does not respond to your input, it might be because the INPUT\_EDITING\_MODE connection attribute is inadvertently set to TRANSPARENT. If you suspect this to be the case, enter the transparent input editing mode escape sequence, described in chapter 6.

If the communications difficulties persist, use the secure access sequence, also described in chapter 6, to delete all of your existing CDCNET connections. Then, create a new connection to the service and check to see if the job you exited is recoverable.



## Passthrough Service Difficulties

The following notes and cautions apply to the use of interactive terminal passthrough services:

- If you are using a passthrough service and need to interrupt data flow to enter a network command and work on some other task, you can use the escape to \$NET connection sequence, described in chapter 6. This sequence is effective at all times, even for nontransparent input.
- If you use remote echoing, (common with VAX<sup>1</sup> systems), you might notice longer echoing delays when using passthrough connections than you would if you were directly connected to the echoing systems.
- When you issue commands to remote systems to abort output, notice that output is not terminated until all of the data in the passthrough connection has been displayed at the terminal. The amount of data varies.
- In a non-passthrough configuration, commands such as TRMDEF (NOS) can be used to set parity, X-ON/X-OFF flow control, and other parameters for the communication line that connects the terminal to CDCNET. However, if such commands are used in a passthrough environment, they affect the parameters of the remote system port connected to the passthrough communication line, not the terminal's parameters. When troubleshooting passthrough communications, the possibility of such commands embedded in user startup procedures on the remote system should be investigated.

In limited circumstances it may be appropriate to initiate remote system communication line attribute changes in a passthrough configuration. However, you must fully understand the impact of doing this.

---

1. VAX is a registered trademark of the Digital Equipment Corporation.

- Before creating a passthrough connection for XMODEM transfers from a microcomputer, use the following command to disable parity and character flow control:

```
CHATA P=NONE CFC=NO
```

If you need to transfer files at speeds less than 9600 bits per second after you have connected to passthrough, take the following steps to set the `TRANSPARENT_MESSAGE_LENGTH` connection attribute to 135:

1. Press the `BREAK` key or attention character (do not press `RETURN`).
2. Hold down the `CTRL` key and press `X` (do not press `RETURN`).
3. Enter the following string, followed by `RETURN`:

```
CHACA TML=135 IEM=TRANSPARENT
```

## Service Failures

It sometimes takes CDCNET software several minutes to inform interactive terminal users about the loss of their connections to NOS or NOS/VE host applications. Similar delays can be expected when the network informs a user of its inability to create new connections to NOS or NOS/VE host applications, and the inability to execute terminal user procedures using the DO command.

If your service does fail, and your terminal is disconnected from it, the network connects you to \$NET and issues the following message:

You may enter CDCNET commands.

Try to access the service later using a CREATE\_CONNECTION command. Or, use the DISPLAY\_SERVICE command to display the latest status of your network's services.

## Cursor Positioning Delays

Cursor positioning delays implemented by the host suspending output transmission cannot be expected to reliably pass through a network. The more networks there are between source and destination, the more likely this problem is to occur.

This problem is likely to be seen on an asynchronous passthrough connection when the host tries to perform cursor positioning delays by suspending output. The only reliable delays in the network environment are those accomplished by sending NUL characters for the desired time-delay interval.





## Glossary

---

## A

### A

#### **Alphabetic Character**

One of the following letters:

- A through Z
- a through z

#### **American Standard Code for Information Interchange (ASCII)**

A standard code, using a coded character set consisting of 7-bit coded characters (8 bits including parity check), used for information interchange among data processing systems, data communication systems, and associated equipment. The ASCII set consists of control characters and graphic characters.

#### **ASCII**

Refer to American Standard Code for Information Interchange.

#### **Asynchronous Protocol**

The communications protocol enabling the transmission of data as characters individually synchronized by start/stop bits.

#### **Attribute**

Refer to Terminal Attribute.

#### **Auto Recognition**

Refer to Automatic Recognition.

#### **Automatic Recognition**

The process whereby the network identifies attributes (characteristics) of the terminal when the communication line, connected to the terminal, becomes active.

## B

### Batch Mode

A mode of execution where a job is submitted and processed as a unit without intervention from the user.

### Bit

Binary digit. A bit has the value of either 0 or 1.

### Bits Per Second

A data transmission rating that expresses the flow of the smallest units of information per unit of time.

## C

### Catenet

Refer to Concatenated Network.

### CCP

Refer to Communications Control Program.

### CDCNET

Refer to Control Data Distributed Communications Network.

### Character

(ISO) A member of a set of elements upon which agreement has been reached, and that is used for the organization, control, or representation of information. Characters may be letters, digits, punctuation marks, or other symbols. A character can be a graphic character or a control character.

### Client

In a passthrough connection, the passthrough user that creates a connection to another passthrough user (the Server). See also Server.

### Coded Character Set

(ISO) A set of unambiguous rules that establish a character set and the one-to-one relationships between the characters of the set and their coded representations.

## **Comment**

Any character or sequence of characters (except the quotation mark ["]) that is preceded by a quotation mark. It is terminated by another quotation mark or the end of the physical line. The network treats a comment the same as it does a space.

## **Communication Line**

A terminal line that establishes a complete communication circuit between a terminal and the network.

## **Communications Control Program (CCP)**

Software that provides terminal access and remote processing capability for NOS.

## **Complete Transmission**

Logical unit of data as processed by a service.

## **Concatenated Network (Catenet)**

A communications network composed of more than one type of communications medium (more than one network solution); often established when it is necessary to interconnect a local area network (LAN) with other resources (for example, another local area network, or geographically remote computer-related resources). Also called a catenet.

## **Connection**

1. (ISO) An association established between functional units for conveying information.
2. A data path between a terminal and a service through CDCNET. The default connection, \$NET, handles communications between the terminal and CDCNET.

## **Connection Attributes**

Characteristics unique to a particular connection, such as the type of editing to be done on input data. A terminal connected to CDCNET at any given time has as many sets of connection attributes as it has connections.

## **Control Character**

(ISO) A character that occurs in a particular context and initiates, modifies, or stops a control operation. A control character is not a graphic character, but may have graphic representation.



## **Control Data Distributed Communications/ Network (CDCNET)**

1. The collection of compatible hardware and software products offered by Control Data to interconnect computer resources into distributed communications networks.
2. A network that is interconnected by Control Data Network Architecture (CDNA)-compatible hardware and software products.

### **CRC**

Refer to Cyclic Redundancy Check.

### **Cursor**

1. (ISO) A movable, visible mark used to indicate the position on which the next operation takes place on a display surface.
2. The pointer used by a terminal to indicate where the user is positioned on the screen.

### **Cursor Positioning**

Placing the cursor to indicate where data should be entered or displayed.

### **Cyclic Redundancy Check (CRC)**

A technique designed for bit-oriented checking of errors on a transmission basis. It uses a unique mathematical polynomial that is known to both the sender and the receiver.

## **D**

### **Data Editing**

Process of preparing data for a later operation. Editing may include the rearrangement or the addition of data, the deletion of unwanted data, etc.

### **Dedicated Line**

A communication line that permanently connects a terminal to a device interface. Contrast with Switched Line.

### **Default**

The assumed value for a parameter when the parameter is not specified by the user.

**Device Interface (DI)**

The communications processor that Control Data offers as its CDCNET hardware product. Also called a CDCNET device interface.

**DI**

Refer to Device Interface.

**Digit**

One of the following characters:

0 1 2 3 4 5 6 7 8 9

**E****EBCDIC**

Refer to Extended Binary Coded Decimal Interchange Code.

**EIA Flow Control**

The procedure of controlling the rate of data transfer with an EIA hardware interface.

**Ellipsis**

Two (or more) consecutive periods at the end of a physical line to indicate the continuation of a command. The ellipsis can be optionally preceded or followed by a space.

**Escape to \$NET Connection Sequence**

The steps involved in switching from a connection in transparent mode to \$NET.

**Extended Binary Coded Decimal Interchange Code (EBCDIC)**

A set of 256 characters, each represented by eight bits, that is used with the 3270 Binary Synchronous Communications protocol.

**F****Field Attribute Character**

Character in the first position of each display field in a formatted display of a 3270 display station.

**Format Effectors**

Any character used to control the positioning of printed or displayed data.

**FSE**

Refer to Full Screen Editor.

**Full Screen Editor (FSE)**

A text editor on NOS (called FSE) or NOS/VE (called EDIT\_FILE) that allows you to edit files in either line mode or screen mode.

**G****Graphic Character**

A character that can be printed or displayed.

**H****HASP Protocol**

A job control protocol for transmitting data processing files and jobs between certain models of computers. It is also called the Houston Automatic Spooling Program.

**I****IAF**

Refer to Interactive Facility.

**Input**

Data flowing up-line from terminal to the service.

**Interactive Facility (IAF)**

An application used on NOS to provide a terminal user with interactive processing capability. The interactive facility makes terminal input/output and file input/output appear the same to an executing program.

**Interactive Mode**

A mode of execution where a user enters commands at a terminal and each command elicits a response from the computing service.

**Interface**

A mechanism that enables the exchange of data between two dissimilar resources in a communications network.

**L****LAN**

Refer to Local Area Network.

**LIM**

Refer to Line Interface Module.

**Line Folding**

The continuation of an output line that exceeds the terminal's width on the following line of the screen or paper.

**Line Interface Module (LIM)**

A smaller logic board within a CDCNET device interface that enables the device interface to be attached to terminal, workstation, and unit record equipment lines.

**Local Area Network (LAN)**

A privately owned communications network that interconnects computer-related resources. Typically, the resources interconnected by this network are confined to a relatively concise geographic area, such as a single building.

## **M**

### **M-Bit**

Refer to More Bit.

### **Microcomputer**

A computer system whose processing unit is a microprocessor. A basic microcomputer includes a microprocessor, storage, and input/output facility.

### **Microprocessor**

An integrated circuit that accepts and executes coded instructions, and delivers signals describing its status. The instructions may be entered, integrated, or stored internally.

### **Mode 4**

A data communications protocol, consisting of variants 4A, 4B, and 4C. The Mode 4 protocol supports two-way alternate communications (where messages may be sent in one direction or another, but not in both directions simultaneously) on switched or dedicated synchronous lines within a line speed range of 1200 to 19200 bits-per-second.

The CDCNET Mode 4 terminal interface program supports the 4A and 4C variants of the Mode 4 protocol.

### **More Bit (M-Bit)**

A data communications protocol flag that indicates whether there are more data packets in the message currently being delivered. If the M-Bit is set to TRUE, the message is incomplete.

## **N**

### **NAM**

Refer to Network Access Method.

### **NAM/VE**

Refer to Network Access Method/Virtual Environment.

### **\$NET**

The connection between a user's terminal and CDCNET. The network reserves this connection for CDCNET commands, network responses, and messages from the network operator.

**Network**

An interconnected set of host computers, terminals, workstations, and unit record equipment. Refer also to Local Area Network and Concatenated Network.

**Network Access Method (NAM)**

The access method that resides under NOS; allows host-based network applications programs to exchange information with communications networks.

**Network Access Method/Virtual Environment (NAM/VE)**

The access method that resides under NOS/VE; allows host-based network applications programs to exchange information with communications networks.

**Network Operating System (NOS)**

The operating system for CYBER 170 computer systems.

**Network Operating System/Virtual Environment (NOS/VE)**

The virtual operating system for CYBER 180 computer systems.

**Network Operator**

A person who monitors CDCNET activity, has the ability to control CDCNET hardware and software, makes occasional network configuration changes, and performs elementary troubleshooting.

**NOS**

Refer to Network Operating System.

**NOS/VE**

Refer to Network Operating System/Virtual Environment.

**O****Output**

Data flowing from the service to the terminal.

## P

### **Packet Assembly/Disassembly (PAD)**

Facility that allows nonpacket-mode asynchronous, start-stop mode terminals to communicate with hosts accessible through an X.25 network.

### **PAD ,**

Refer to Packet Assembly/Disassembly.

### **Parameter Name**

A name that uniquely identifies a parameter.

### **Partial Transmission**

Incomplete logical unit of data as processed by a service.

### **Passthrough.**

Refer to Terminal Passthrough.

### **PDN**

Refer to Public Data Network.

### **Personal Computer**

Refer to Microcomputer.

### **Protocol**

A set of conventions that must be followed to achieve complete communications between the computer-related resources in a network.

### **Public Data Network (PDN)**

A publicly-owned communications network that interconnects computer-related resources. Typically, the resources interconnected by this network are not confined to a relatively concise geographic area (such as an X.25 public data network).

## R

### **Reprive Processing**

The process a program performs after receiving an interrupt from the network.

## S

### SCL

Refer to System Command Language.

### Secure Access Sequence

A sequence of keystrokes that can be entered from an interactive terminal to delete all existing CDCNET service connections for that terminal. This sequence can be used to ensure there is a bona fide \$NET connection before the terminal user begins to enter service user validations or other guarded information.

### Server

In a passthrough connection, the passthrough user that defines a passthrough title for other passthrough users (clients) to connect to. See also Client.

### Service

An entity that is external to CDCNET but is registered within CDCNET as being capable of conducting input and output with a terminal or with another service.

### Site Administrator

A person who configures a site's network, supervises hardware and software changes, and ensures that the network operates efficiently.

### Slave Printer

Although terminals can have multiple input or output mechanisms on a connection at any time, CDCNET is aware of only one. Such mechanisms operate in series and are called slave devices.

### SNA

Refer to Systems Network Architecture.

### String

A value that represents a sequence of characters.

### Switched Line

A communication line connected with one device interface, but able to be connected to any one of several terminals via a switching mechanism, such as a dialed telephone line. Contrast with Dedicated Line.



## **System Command Language (SCL)**

User interface to the CDC Network Operating System/Virtual Environment (NOS/VE).

## **Systems Network Architecture (SNA)**

IBM standard defining the layers and layer protocols to be used within an IBM network.

# **T**

## **TDP**

Refer to Terminal Definition Procedure.

## **Terminal**

Any interactive device used to access a service through CDCNET. It may be a microcomputer, batch console, video-display terminal, hardcopy terminal, display station, or workstation that can be used to conduct a dialog with your service.

## **Terminal Attributes**

Characteristics that apply to all of a terminal's connections. A terminal connected to CDCNET has only one set of terminal attributes.

## **Terminal Definition Procedure (TDP)**

An optional configuration file that defines a terminal device or devices connected to a line whenever the line becomes active. A TDP can be used to define a terminal device that differs from the default terminal device type defined by the TIP that controls the line.

## **Terminal Interface Program (TIP)**

A program that provides an interface for terminals connected to a device interface supporting terminals. TIPs provide default line and terminal configurations. Optional terminal definition procedures (TDPs) and terminal user procedures (TUP) can be used to define terminals having attributes that differ from those provided by the TIP's defaults.

## **Terminal Passthrough**

A CDCNET feature that allows interactive asynchronous terminal traffic to pass through the network transparently. The hosts and terminals interface with each other as if they were directly connected. Terminal passthrough allows a CDCNET-connected terminal user to access non-CDCNET supported hosts, such as NOS/BE and VAX.

**Terminal Redefinition Command**

A command issued by a service or application that changes terminal or connection attributes.

**Terminal User Procedure (TUP)**

An optional configuration file that defines attributes of terminals and connections. A TUP can be used to define attributes for a particular terminal model or a group of terminals. A TUP for a terminal is executed when the communication line from the terminal to the supporting device interface becomes active.

**TIP**

Refer to Terminal Interface Program.

**Transparent Mode**

A way of handling data in which the network performs little or no input editing and does not format or translate output. The `INPUT_EDITING_MODE` terminal attribute designates input in this mode as transparent.

**Transparent Mode Escape Sequence**

The steps involved in switching from `NORMAL` input editing mode while engaged in a Transparent mode session.

**TUP**

Refer to Terminal User Procedure.

**Type-Ahead**

The ability of a terminal user to enter input even though the service has not finished processing the user's previous input(s).

**V****Virtual Line Mode**

A way of handling data in which the network edits input, and formats and translates output. The `INPUT_EDITING_MODE` terminal attribute designates input in this mode as normal.

## W

### Working Connection

The path a terminal uses to exchange information with a computing service or the network. It is one of the user's existing connections. If the user is communicating directly with the network, the connection is \$NET.

## X

### X.PC

An asynchronous data communications protocol that improves the networking capabilities of personal computers. It also allows users to have multiple active virtual circuits.

### X.25

The Consultative Committee of International Telephone and Telegraph (CCITT) standard for the interface between Data Terminal Equipment (DTE) and Data Circuit-Terminating Equipment (DCE) in an X.25 packet-switching network.

### X.29 PAD

A CDCNET feature that allows asynchronous terminals to access CDCNET either by a Public Data Network (PDN) that supports the X.3 Packet Assembly/Dissassembly (PAD) facility or by the terminals operating in X.25 mode.

## 3

### 3270 Bisynchronous TIP

A terminal interface program that provides support for the IBM 3270 Information Display System. The 3270 Bisynchronous TIP allows 3271, 3274, 3275, and 3276 control units to connect directly to CDCNET in order to communicate with a CDCNET terminal device interface (TDI) over dedicated or dial-up lines using the centralized multipoint Binary Synchronous Communication protocol. The 3270 TIP Bisynchronous supports up to 32 multi-dropped clusters of up to 32 devices on each line.

### 3270 SNA Communications TIP

A terminal interface program that provides IBM 3270 Information Display System users access to CDCNET through an SNA network.

# ASCII Coded Character Set

---

**B**

|                                 |     |
|---------------------------------|-----|
| Changing an Attribute .....     | B-2 |
| Using Examples .....            | B-3 |
| Entering ASCII Characters ..... | B-3 |
| Entering Sequences .....        | B-4 |
| Entering Lists .....            | B-5 |



This appendix contains the complete ASCII coded character set, in table B-1. This appendix also describes how you can change an attribute setting by assigning one or more ASCII characters to the attribute.

Three groups of attributes can be set using the methods described in this appendix. Within this guide, each attribute in the first two groups is described in terms of the key you press to perform an action. Your terminal or communications package determines how the action is performed.

- The first group consists of terminal attributes that you can change using a single ASCII character. The following terminal attributes belong to this group.

- ATTENTION\_CHARACTER (AC)
  - BACKSPACE\_CHARACTER (BC)
  - BEGIN\_LINE\_CHARACTER (BLC)
  - CANCEL\_LINE\_CHARACTER (CLC)
  - END\_LINE\_CHARACTER (ELC)
  - END\_PARTIAL\_CHARACTER (EPC)
  - NETWORK\_COMMAND\_CHARACTER (NCC)

- The second group contains connection attributes that you can change using a list of ASCII characters. The following connection attributes belong to this group.

- TRANSPARENT\_FORWARD\_CHARACTER (TFC)
  - TRANSPARENT\_TERMINATE\_CHARACTER (TTC)

- The third group consists of terminal attributes that you can change using a sequence of characters. The sequence defines the series of characters the network sends your terminal when the action occurs.

- CARRIAGE\_RETURN\_SEQUENCE (CRS)
  - END\_OUTPUT\_SEQUENCE (EOS)
  - FORM\_FEED\_SEQUENCE (FFS)
  - LINE\_FEED\_SEQUENCE (LFS)

## Changing an Attribute

If you need to change an attribute, the following procedure outlines the steps you take.

1. Decide which characters you can assign the attribute.

If you want to change an attribute in the second group (TFC, TTC) or one in the third group (CRS, EOS, FFS, LFS), you can use any ASCII character in the ASCII coded character set (see table B-1).

If you want to change an attribute in the first group (AC, BC, BLC, CLC, ELC, EPC, NCC), refer to the table specified in the following list.

| <u>Terminal Attribute</u> | <u>Available Characters</u> |
|---------------------------|-----------------------------|
| AC                        | See table B-2.              |
| BC                        | See table B-3.              |
| BLC                       | See table B-2.              |
| CLC                       | See table B-4.              |
| ELC                       | See table B-5.              |
| EPC                       | See table B-4.              |
| NCC                       | See table B-6.              |

2. Select an appropriate character (or characters).
3. Display your current terminal attributes by issuing this command:

```
%DISTA
```

If you are going to use TRANSPARENT mode, also display your connection attributes.

```
%DISCA
```

4. Review the attributes listed by `DISPLAY TERMINAL ATTRIBUTES` (and `DISPLAY_CONNECTION_ATTRIBUTES`). By verifying that the new character you have selected is not already assigned to another character attribute, you can avoid producing unexpected results. Repeat steps 2, 3, and 4 as necessary.

5. Refer to the appropriate table to find out how you can represent this character (as a graphic, mnemonic, character string, control character, or code radix).
6. Enter a `CHANGE_TERMINAL_ATTRIBUTE` or `CHANGE_CONNECTION_ATTRIBUTE` command to change the attribute.

## Using Examples

The following examples illustrate how you can enter ASCII characters, sequences, and lists.

### Entering ASCII Characters

If you change CLC from the cancel mnemonic (CAN) to the exclamation point (!), you can enter the attribute in the following ways.

| <b>Entry</b>                               | <b>Example</b>       |
|--------------------------------------------|----------------------|
| Character string (enclosed in apostrophes) | CLC='!'              |
| Decimal code                               | CLC=33 or CLC=33(10) |
| Hexadecimal code                           | CLC=21(16)           |

If you want to change CLC from an exclamation point (!) back to CAN, you can enter it in the following ways.

| <b>Entry</b>                                                                                     | <b>Example</b>       |
|--------------------------------------------------------------------------------------------------|----------------------|
| Mnemonic                                                                                         | CLC=CAN              |
| Control character (entered by simultaneously pressing the CONTROL key and specified graphic key) | CLC=^X               |
| Decimal code                                                                                     | CLC=24 or CLC=24(10) |
| Hexadecimal code                                                                                 | CLC=18(16)           |



Using NUL or an empty string (") deletes any character except the BACKSPACE\_CHARACTER, END\_LINE\_CHARACTER, and NETWORK\_COMMAND\_CHARACTER. For instance, if you do not want a CANCEL\_LINE\_CHARACTER, set the attribute to NUL or an empty string.

```
CLC=NUL
CLC=''
```

When you enter a DISPLAY\_TERMINAL\_ATTRIBUTE command to verify the setting, the network displays NUL regardless of whether you entered NUL or an empty string. The network uses NUL for these characters because NUL does not have any meaning for most terminals.

```
Cancel_Line_Character :NUL
```

## Entering Sequences

You can reset the third group of attributes by entering sequences as shown in the following EOS examples. To separate a sequence of more than one character, use spaces or commas, and enclose the sequence in parentheses.

```
EOS=(BEL '/')
EOS=(BEL, '/')
```

In addition to mnemonics and strings, you can also use decimal codes, hexadecimal codes, and control characters in sequences.

```
EOS=(^G '/')
EOS=(7 47)
EOS=(7(16) 2F(16))
```

When you specify a sequence of characters for an attribute, *all* the characters in the sequence are used by the network to perform the action.

You can use NUL or an empty string ('') to delete a sequence of characters.

```
EOS=NUL
EOS=''
```

When you display the setting, the network does not show a value.

```
END_OUTPUT_SEQUENCE :
```

However, if you enter a NUL character in a sequence of two or more characters, the network will accept it as a value.

## Entering Lists

You enter lists for the second group of attributes in the same way you do sequences. As shown in the following examples, a list is also separated by spaces or commas and enclosed in parentheses.

```
TTC=(CR ETX EOT RS)
TTC=(CR,ETX,EOT,RS)
```

This TTC list contains four characters. Unlike characters in a sequence, when you specify a list of characters for an attribute, the network recognizes any *one* of the characters listed.

Instead of using NUL or an empty string ("), you nullify a list of characters by specifying NONE for TRANSPARENT\_CHARACTER\_MODE.

```
TCM=NONE
```

**Table B-1. Complete ASCII Coded Character Set  
(Characters Available for CRS, EOS, FFS, LFS, TFC, and TTC)**

| Decimal Code | Hex Code | Graphic/<br>Mnemonic | Name or<br>Meaning           | Control<br>Character |
|--------------|----------|----------------------|------------------------------|----------------------|
| 000          | 00       | NUL                  | Null                         | ^@                   |
| 001          | 01       | SOH                  | Start of heading             | ^A or ^a             |
| 002          | 02       | STX                  | Start of text                | ^B or ^b             |
| 003          | 03       | ETX                  | End of text                  | ^C or ^c             |
| 004          | 04       | EOT                  | End of transmission          | ^D or ^d             |
| 005          | 05       | ENQ                  | Enquiry                      | ^E or ^e             |
| 006          | 06       | ACK                  | Acknowledge                  | ^F or ^f             |
| 007          | 07       | BEL                  | Bell                         | ^G or ^g             |
| 008          | 08       | BS                   | Backspace                    | ^H or ^h             |
| 009          | 09       | HT                   | Horizontal tabulation        | ^I or ^i             |
| 010          | 0A       | LF                   | Line feed                    | ^J or ^j             |
| 011          | 0B       | VT                   | Vertical tabulation          | ^K or ^k             |
| 012          | 0C       | FF                   | Form feed                    | ^L or ^l             |
| 013          | 0D       | CR                   | Carriage return              | ^M or ^m             |
| 014          | 0E       | SO                   | Shift out                    | ^N or ^n             |
| 015          | 0F       | SI                   | Shift in                     | ^O or ^o             |
| 016          | 10       | DLE                  | Data link escape             | ^P or ^p             |
| 017          | 11       | DC1                  | Device control 1<br>(X-ON)   | ^Q or ^q             |
| 018          | 12       | DC2                  | Device control 2             | ^R or ^r             |
| 019          | 13       | DC3                  | Device control 3<br>(X-OFF)  | ^S or ^s             |
| 020          | 14       | DC4                  | Device control 4             | ^T or ^t             |
| 021          | 15       | NAK                  | Negative acknowledge         | ^U or ^u             |
| 022          | 16       | SYN                  | Synchronous idle             | ^V or ^v             |
| 023          | 17       | ETB                  | End of transmission<br>block | ^W or ^w             |
| 024          | 18       | CAN                  | Cancel                       | ^X or ^x             |
| 025          | 19       | EM                   | End of medium                | ^Y or ^y             |
| 026          | 1A       | SUB                  | Substitute                   | ^Z or ^z             |
| 027          | 1B       | ESC                  | Escape                       | ^[                   |
| 028          | 1C       | FS                   | File separator               | ^\                   |
| 029          | 1D       | GS                   | Group separator              | ^]                   |
| 030          | 1E       | RS                   | Record separator             | ^^                   |
| 031          | 1F       | US                   | Unit separator               | ^_                   |

(Continued)

**Table B-1. Complete ASCII Coded Character Set**  
**(Characters Available for CRS, EOS, FFS, LFS, TFC, and TTC)**  
*(Continued)*

| <b>Decimal Code</b> | <b>Hex Code</b> | <b>Graphic/Mnemonic</b> | <b>Name or Meaning</b> | <b>Control Character</b> |
|---------------------|-----------------|-------------------------|------------------------|--------------------------|
| 032                 | 20              | SP                      | Space                  |                          |
| 033                 | 21              | !                       | Exclamation point      |                          |
| 034                 | 22              | "                       | Quotation marks        |                          |
| 035                 | 23              | #                       | Number sign            |                          |
| 036                 | 24              | \$                      | Dollar sign            |                          |
| 037                 | 25              | %                       | Percent sign           |                          |
| 038                 | 26              | &                       | Ampersand              |                          |
| 039                 | 27              | '                       | Apostrophe             |                          |
| 040                 | 28              | (                       | Opening parenthesis    |                          |
| 041                 | 29              | )                       | Closing parenthesis    |                          |
| 042                 | 2A              | *                       | Asterisk               |                          |
| 043                 | 2B              | +                       | Plus                   |                          |
| 044                 | 2C              | ,                       | Comma                  |                          |
| 045                 | 2D              | -                       | Hyphen                 |                          |
| 046                 | 2E              | .                       | Period                 |                          |
| 047                 | 2F              | /                       | Slant                  |                          |
| 048                 | 30              | 0                       | Zero                   |                          |
| 049                 | 31              | 1                       | One                    |                          |
| 050                 | 32              | 2                       | Two                    |                          |
| 051                 | 33              | 3                       | Three                  |                          |
| 052                 | 34              | 4                       | Four                   |                          |
| 053                 | 35              | 5                       | Five                   |                          |
| 054                 | 36              | 6                       | Six                    |                          |
| 055                 | 37              | 7                       | Seven                  |                          |
| 056                 | 38              | 8                       | Eight                  |                          |
| 057                 | 39              | 9                       | Nine                   |                          |
| 058                 | 3A              | :                       | Colon                  |                          |
| 059                 | 3B              | ;                       | Semicolon              |                          |
| 060                 | 3C              | <                       | Less than              |                          |
| 061                 | 3D              | =                       | Equals                 |                          |
| 062                 | 3E              | >                       | Greater than           |                          |
| 063                 | 3F              | ?                       | Question mark          |                          |
| 064                 | 40              | @                       | Commercial at          |                          |
| 065                 | 41              | A                       | Uppercase A            |                          |
| 066                 | 42              | B                       | Uppercase B            |                          |
| 067                 | 43              | C                       | Uppercase C            |                          |

*(Continued)*

**Table B-1. Complete ASCII Coded Character Set**  
 (Characters Available for CRS, EOS, FFS, LFS, TFC, and TTC)  
 (Continued)

| Decimal Code | Hex Code | Graphic/<br>Mnemonic | Name or<br>Meaning | Control<br>Character |
|--------------|----------|----------------------|--------------------|----------------------|
| 068          | 44       | D                    | Uppercase D        |                      |
| 069          | 45       | E                    | Uppercase E        |                      |
| 070          | 46       | F                    | Uppercase F        |                      |
| 071          | 47       | G                    | Uppercase G        |                      |
| 072          | 48       | H                    | Uppercase H        |                      |
| 073          | 49       | I                    | Uppercase I        |                      |
| 074          | 4A       | J                    | Uppercase J        |                      |
| 075          | 4B       | K                    | Uppercase K        |                      |
| 076          | 4C       | L                    | Uppercase L        |                      |
| 077          | 4D       | M                    | Uppercase M        |                      |
| 078          | 4E       | N                    | Uppercase N        |                      |
| 079          | 4F       | O                    | Uppercase O        |                      |
| 080          | 50       | P                    | Uppercase P        |                      |
| 081          | 51       | Q                    | Uppercase Q        |                      |
| 082          | 52       | R                    | Uppercase R        |                      |
| 083          | 53       | S                    | Uppercase S        |                      |
| 084          | 54       | T                    | Uppercase T        |                      |
| 085          | 55       | U                    | Uppercase U        |                      |
| 086          | 56       | V                    | Uppercase V        |                      |
| 087          | 57       | W                    | Uppercase W        |                      |
| 088          | 58       | X                    | Uppercase X        |                      |
| 089          | 59       | Y                    | Uppercase Y        |                      |
| 090          | 5A       | Z                    | Uppercase Z        |                      |
| 091          | 5B       | [                    | Opening bracket    |                      |
| 092          | 5C       | \                    | Reverse slant      |                      |
| 093          | 5D       | ]                    | Closing bracket    |                      |
| 094          | 5E       | ^                    | Circumflex         |                      |
| 095          | 5F       | _                    | Underline          |                      |
| 096          | 60       | `                    | Grave accent       |                      |
| 097          | 61       | a                    | Lowercase a        |                      |
| 098          | 62       | b                    | Lowercase b        |                      |
| 099          | 63       | c                    | Lowercase c        |                      |
| 100          | 64       | d                    | Lowercase d        |                      |
| 101          | 65       | e                    | Lowercase e        |                      |
| 102          | 66       | f                    | Lowercase f        |                      |
| 103          | 67       | g                    | Lowercase g        |                      |

(Continued)

**Table B-1. Complete ASCII Coded Character Set**  
**(Characters Available for CRS, EOS, FFS, LFS, TFC, and TTC)**  
*(Continued)*

| <b>Decimal Code</b> | <b>Hex Code</b> | <b>Graphic/<br/>Mnemonic</b> | <b>Name or<br/>Meaning</b> | <b>Control<br/>Character</b> |
|---------------------|-----------------|------------------------------|----------------------------|------------------------------|
| 104                 | 68              | h                            | Lowercase h                |                              |
| 105                 | 69              | i                            | Lowercase i                |                              |
| 106                 | 6A              | j                            | Lowercase j                |                              |
| 107                 | 6B              | k                            | Lowercase k                |                              |
| 108                 | 6C              | l                            | Lowercase l                |                              |
| 109                 | 6D              | m                            | Lowercase m                |                              |
| 110                 | 6E              | n                            | Lowercase n                |                              |
| 111                 | 6F              | o                            | Lowercase o                |                              |
| 112                 | 70              | p                            | Lowercase p                |                              |
| 113                 | 71              | q                            | Lowercase q                |                              |
| 114                 | 72              | r                            | Lowercase r                |                              |
| 115                 | 73              | s                            | Lowercase s                |                              |
| 116                 | 74              | t                            | Lowercase t                |                              |
| 117                 | 75              | u                            | Lowercase u                |                              |
| 118                 | 76              | v                            | Lowercase v                |                              |
| 119                 | 77              | w                            | Lowercase w                |                              |
| 120                 | 78              | x                            | Lowercase x                |                              |
| 121                 | 79              | y                            | Lowercase y                |                              |
| 122                 | 7A              | z                            | Lowercase z                |                              |
| 123                 | 7B              | {                            | Opening brace              |                              |
| 124                 | 7C              |                              | Vertical line              |                              |
| 125                 | 7D              | }                            | Closing brace              |                              |
| 126                 | 7E              | -                            | Tilde                      |                              |
| 127                 | 7F              | DEL                          | Delete                     |                              |

Table B-2. ASCII Characters Available for AC and BLC

| Decimal Code | Hex Code | Graphic/Mnemonic | Name or Meaning              | Control Character |
|--------------|----------|------------------|------------------------------|-------------------|
| 000          | 00       | NUL              | Null                         | ^@                |
| 001          | 01       | SOH              | Start of heading             | ^A or ^a          |
| 002          | 02       | STX              | Start of text                | ^B or ^b          |
| 003          | 03       | ETX              | End of text                  | ^C or ^c          |
| 004          | 04       | EOT              | End of transmission          | ^D or ^d          |
| 005          | 05       | ENQ              | Enquiry                      | ^E or ^e          |
| 006          | 06       | ACK              | Acknowledge                  | ^F or ^f          |
| 007          | 07       | BEL              | Bell                         | ^G or ^g          |
| 008          | 08       | BS               | Backspace                    | ^H or ^h          |
| 009          | 09       | HT               | Horizontal tabulation        | ^I or ^i          |
| 010          | 0A       | LF               | Line feed                    | ^J or ^j          |
| 011          | 0B       | VT               | Vertical tabulation          | ^K or ^k          |
| 012          | 0C       | FF               | Form feed                    | ^L or ^l          |
| 013          | 0D       | CR               | Carriage return              | ^M or ^m          |
| 014          | 0E       | SO               | Shift out                    | ^N or ^n          |
| 015          | 0F       | SI               | Shift in                     | ^O or ^o          |
| 016          | 10       | DLE              | Data link escape             | ^P or ^p          |
| 018          | 12       | DC2              | Device control 2             | ^R or ^r          |
| 020          | 14       | DC4              | Device control 4             | ^T or ^t          |
| 021          | 15       | NAK              | Negative acknowledge         | ^U or ^u          |
| 022          | 16       | SYN              | Synchronous idle             | ^V or ^v          |
| 023          | 17       | ETB              | End of transmission<br>block | ^W or ^w          |
| 024          | 18       | CAN              | Cancel                       | ^X or ^x          |
| 025          | 19       | EM               | End of medium                | ^Y or ^y          |
| 026          | 1A       | SUB              | Substitute                   | ^Z or ^z          |
| 027          | 1B       | ESC              | Escape                       | ^[                |
| 028          | 1C       | FS               | File separator               | ^\                |
| 029          | 1D       | GS               | Group separator              | ^]                |
| 030          | 1E       | RS               | Record separator             | ^^                |
| 031          | 1F       | US               | Unit separator               | ^_                |
| 033          | 21       | !                | Exclamation point            |                   |
| 035          | 23       | #                | Number sign                  |                   |
| 036          | 24       | \$               | Dollar sign                  |                   |
| 037          | 25       | %                | Percent sign                 |                   |
| 038          | 26       | &                | Ampersand                    |                   |
| 039          | 27       | '                | Apostrophe                   |                   |

(Continued)

**Table B-2. ASCII Characters Available for AC and BLC**  
(Continued)

| Decimal Code | Hex Code | Graphic/Mnemonic | Name or Meaning | Control Character |
|--------------|----------|------------------|-----------------|-------------------|
| 042          | 2A       | *                | Asterisk        |                   |
| 043          | 2B       | +                | Plus            |                   |
| 045          | 2D       | -                | Hyphen          |                   |
| 046          | 2E       | .                | Period          |                   |
| 047          | 2F       | /                | Slant           |                   |
| 058          | 3A       | :                | Colon           |                   |
| 059          | 3B       | ;                | Semicolon       |                   |
| 060          | 3C       | <                | Less than       |                   |
| 062          | 3E       | >                | Greater than    |                   |
| 063          | 3F       | ?                | Question mark   |                   |
| 064          | 40       | @                | Commercial at   |                   |
| 091          | 5B       | [                | Opening bracket |                   |
| 092          | 5C       | \                | Reverse slant   |                   |
| 093          | 5D       | ]                | Closing bracket |                   |
| 094          | 5E       | ^                | Circumflex      |                   |
| 095          | 5F       | _                | Underline       |                   |
| 096          | 60       | `                | Grave accent    |                   |
| 123          | 7B       | {                | Opening brace   |                   |
| 124          | 7C       |                  | Vertical line   |                   |
| 125          | 7D       | }                | Closing brace   |                   |
| 126          | 7E       | ~                | Tilde           |                   |



**Table B-3. ASCII Characters Available for BC**

| Decimal Code | Hex Code | Graphic/<br>Mnemonic | Name or<br>Meaning           | Control<br>Character |
|--------------|----------|----------------------|------------------------------|----------------------|
| 001          | 01       | SOH                  | Start of heading             | ^A or ^a             |
| 002          | 02       | STX                  | Start of text                | ^B or ^b             |
| 003          | 03       | ETX                  | End of text                  | ^C or ^c             |
| 004          | 04       | EOT                  | End of transmission          | ^D or ^d             |
| 005          | 05       | ENQ                  | Enquiry                      | ^E or ^e             |
| 006          | 06       | ACK                  | Acknowledge                  | ^F or ^f             |
| 007          | 07       | BEL                  | Bell                         | ^G or ^g             |
| 008          | 08       | BS                   | Backspace                    | ^H or ^h             |
| 009          | 09       | HT                   | Horizontal tabulation        | ^I or ^i             |
| 010          | 0A       | LF                   | Line feed                    | ^J or ^j             |
| 011          | 0B       | VT                   | Vertical tabulation          | ^K or ^k             |
| 012          | 0C       | FF                   | Form feed                    | ^L or ^l             |
| 013          | 0D       | CR                   | Carriage return              | ^M or ^m             |
| 014          | 0E       | SO                   | Shift out                    | ^N or ^n             |
| 015          | 0F       | SI                   | Shift in                     | ^O or ^o             |
| 016          | 10       | DLE                  | Data link escape             | ^P or ^p             |
| 018          | 12       | DC2                  | Device control 2             | ^R or ^r             |
| 020          | 14       | DC4                  | Device control 4             | ^T or ^t             |
| 021          | 15       | NAK                  | Negative acknowledge         | ^U or ^u             |
| 022          | 16       | SYN                  | Synchronous idle             | ^V or ^v             |
| 023          | 17       | ETB                  | End of transmission<br>block | ^W or ^w             |
| 024          | 18       | CAN                  | Cancel                       | ^X or ^x             |
| 025          | 19       | EM                   | End of medium                | ^Y or ^y             |
| 026          | 1A       | SUB                  | Substitute                   | ^Z or ^z             |
| 027          | 1B       | ESC                  | Escape                       | ^[                   |
| 028          | 1C       | FS                   | File separator               | ^\                   |
| 029          | 1D       | GS                   | Group separator              | ^]                   |
| 030          | 1E       | RS                   | Record separator             | ^^                   |
| 031          | 1F       | US                   | Unit separator               | ^_                   |
| 033          | 21       | !                    | Exclamation point            |                      |
| 035          | 23       | #                    | Number sign                  |                      |
| 036          | 24       | \$                   | Dollar sign                  |                      |
| 037          | 25       | %                    | Percent sign                 |                      |
| 038          | 26       | &                    | Ampersand                    |                      |
| 039          | 27       | '                    | Apostrophe                   |                      |
| 042          | 2A       | *                    | Asterisk                     |                      |

*(Continued)*

Table B-3. ASCII Characters Available for BC (Continued)

| Decimal Code | Hex Code | Graphic/<br>Mnemonic | Name or<br>Meaning | Control<br>Character |
|--------------|----------|----------------------|--------------------|----------------------|
| 043          | 2B       | +                    | Plus               |                      |
| 045          | 2D       | -                    | Hyphen             |                      |
| 046          | 2E       | .                    | Period             |                      |
| 047          | 2F       | /                    | Slant              |                      |
| 058          | 3A       | :                    | Colon              |                      |
| 059          | 3B       | ;                    | Semicolon          |                      |
| 060          | 3C       | <                    | Less than          |                      |
| 062          | 3E       | >                    | Greater than       |                      |
| 063          | 3F       | ?                    | Question mark      |                      |
| 064          | 40       | @                    | Commercial at      |                      |
| 091          | 5B       | [                    | Opening bracket    |                      |
| 092          | 5C       | \                    | Reverse slant      |                      |
| 093          | 5D       | ]                    | Closing bracket    |                      |
| 094          | 5E       | ^                    | Circumflex         |                      |
| 095          | 5F       | _                    | Underline          |                      |
| 096          | 60       | `                    | Grave accent       |                      |
| 123          | 7B       | {                    | Opening brace      |                      |
| 124          | 7C       |                      | Vertical line      |                      |
| 125          | 7D       | }                    | Closing brace      |                      |
| 126          | 7E       | ~                    | Tilde              |                      |
| 127          | 7F       | DEL                  | Delete             |                      |

Table B-4. ASCII Characters Available for CLC and EPC

| Decimal Code | Hex Code | Graphic/<br>Mnemonic | Name or<br>Meaning           | Control<br>Character |
|--------------|----------|----------------------|------------------------------|----------------------|
| 000          | 00       | NUL                  | Null                         | ^@                   |
| 001          | 01       | SOH                  | Start of heading             | ^A or ^a             |
| 002          | 02       | STX                  | Start of text                | ^B or ^b             |
| 003          | 03       | ETX                  | End of text                  | ^C or ^c             |
| 004          | 04       | EOT                  | End of transmission          | ^D or ^d             |
| 005          | 05       | ENQ                  | Enquiry                      | ^E or ^e             |
| 006          | 06       | ACK                  | Acknowledge                  | ^F or ^f             |
| 007          | 07       | BEL                  | Bell                         | ^G or ^g             |
| 008          | 08       | BS                   | Backspace                    | ^H or ^h             |
| 009          | 09       | HT                   | Horizontal tabulation        | ^I or ^i             |
| 010          | 0A       | LF                   | Line feed                    | ^J or ^j             |
| 011          | 0B       | VT                   | Vertical tabulation          | ^K or ^k             |
| 012          | 0C       | FF                   | Form feed                    | ^L or ^l             |
| 013          | 0D       | CR                   | Carriage return              | ^M or ^m             |
| 014          | 0E       | SO                   | Shift out                    | ^N or ^n             |
| 015          | 0F       | SI                   | Shift in                     | ^O or ^o             |
| 016          | 10       | DLE                  | Data link escape             | ^P or ^p             |
| 018          | 12       | DC2                  | Device control 2             | ^R or ^r             |
| 020          | 14       | DC4                  | Device control 4             | ^T or ^t             |
| 021          | 15       | NAK                  | Negative acknowledge         | ^U or ^u             |
| 022          | 16       | SYN                  | Synchronous idle             | ^V or ^v             |
| 023          | 17       | ETB                  | End of transmission<br>block | ^W or ^w             |
| 024          | 18       | CAN                  | Cancel                       | ^X or ^x             |
| 025          | 19       | EM                   | End of medium                | ^Y or ^y             |
| 026          | 1A       | SUB                  | Substitute                   | ^Z or ^z             |
| 027          | 1B       | ESC                  | Escape                       | ^[                   |
| 028          | 1C       | FS                   | File separator               | ^\                   |
| 029          | 1D       | GS                   | Group separator              | ] ]                  |
| 030          | 1E       | RS                   | Record separator             | ^^                   |
| 031          | 1F       | US                   | Unit separator               | ^_                   |
| 033          | 21       | !                    | Exclamation point            |                      |
| 034          | 22       | "                    | Quotation marks              |                      |
| 035          | 23       | #                    | Number sign                  |                      |
| 036          | 24       | \$                   | Dollar sign                  |                      |
| 037          | 25       | %                    | Percent sign                 |                      |
| 038          | 26       | &                    | Ampersand                    |                      |

(Continued)

**Table B-4. ASCII Characters Available for CLC and EPC**  
(Continued)

| Decimal Code | Hex Code | Graphic/Mnemonic | Name or Meaning     | Control Character |
|--------------|----------|------------------|---------------------|-------------------|
| 039          | 27       | '                | Apostrophe          |                   |
| 040          | 28       | (                | Opening parenthesis |                   |
| 041          | 29       | )                | Closing parenthesis |                   |
| 042          | 2A       | *                | Asterisk            |                   |
| 043          | 2B       | +                | Plus                |                   |
| 044          | 2C       | ,                | Comma               |                   |
| 045          | 2D       | -                | Hyphen              |                   |
| 046          | 2E       | .                | Period              |                   |
| 047          | 2F       | /                | Slant               |                   |
| 058          | 3A       | :                | Colon               |                   |
| 059          | 3B       | ;                | Semicolon           |                   |
| 060          | 3C       | <                | Less than           |                   |
| 061          | 3D       | =                | Equals              |                   |
| 062          | 3E       | >                | Greater than        |                   |
| 063          | 3F       | ?                | Question mark       |                   |
| 064          | 40       | @                | Commercial at       |                   |
| 091          | 5B       | [                | Opening bracket     |                   |
| 092          | 5C       | \                | Reverse slant       |                   |
| 093          | 5D       | ]                | Closing bracket     |                   |
| 094          | 5E       | ^                | Circumflex          |                   |
| 095          | 5F       | _                | Underline           |                   |
| 096          | 60       | `                | Grave accent        |                   |
| 123          | 7B       | {                | Opening brace       |                   |
| 124          | 7C       |                  | Vertical line       |                   |
| 125          | 7D       | }                | Closing brace       |                   |
| 126          | 7E       | ~                | Tilde               |                   |

Table B-5. ASCII Characters Available for ELC

| Decimal Code | Hex Code | Graphic/<br>Mnemonic | Name or<br>Meaning           | Control<br>Character |
|--------------|----------|----------------------|------------------------------|----------------------|
| 001          | 01       | SOH                  | Start of heading             | ^A or ^a             |
| 002          | 02       | STX                  | Start of text                | ^B or ^b             |
| 003          | 03       | ETX                  | End of text                  | ^C or ^c             |
| 004          | 04       | EOT                  | End of transmission          | ^D or ^d             |
| 005          | 05       | ENQ                  | Enquiry                      | ^E or ^e             |
| 006          | 06       | ACK                  | Acknowledge                  | ^F or ^f             |
| 007          | 07       | BEL                  | Bell                         | ^G or ^g             |
| 008          | 08       | BS                   | Backspace                    | ^H or ^h             |
| 009          | 09       | HT                   | Horizontal tabulation        | ^I or ^i             |
| 010          | 0A       | LF                   | Line feed                    | ^J or ^j             |
| 011          | 0B       | VT                   | Vertical tabulation          | ^K or ^k             |
| 012          | 0C       | FF                   | Form feed                    | ^L or ^l             |
| 013          | 0D       | CR                   | Carriage return              | ^M or ^m             |
| 014          | 0E       | SO                   | Shift out                    | ^N or ^n             |
| 015          | 0F       | SI                   | Shift in                     | ^O or ^o             |
| 016          | 10       | DLE                  | Data link escape             | ^P or ^p             |
| 018          | 12       | DC2                  | Device control 2             | ^R or ^r             |
| 020          | 14       | DC4                  | Device control 4             | ^T or ^t             |
| 021          | 15       | NAK                  | Negative acknowledge         | ^U or ^u             |
| 022          | 16       | SYN                  | Synchronous idle             | ^V or ^v             |
| 023          | 17       | ETB                  | End of transmission<br>block | ^W or ^w             |
| 024          | 18       | CAN                  | Cancel                       | ^X or ^x             |
| 025          | 19       | EM                   | End of medium                | ^Y or ^y             |
| 026          | 1A       | SUB                  | Substitute                   | ^Z or ^z             |
| 027          | 1B       | ESC                  | Escape                       | ^[                   |
| 028          | 1C       | FS                   | File separator               | ^\<br>^_             |
| 029          | 1D       | GS                   | Group separator              | ^]                   |
| 030          | 1E       | RS                   | Record separator             | ^^                   |
| 031          | 1F       | US                   | Unit separator               | ^_                   |
| 033          | 21       | !                    | Exclamation point            |                      |
| 035          | 23       | #                    | Number sign                  |                      |
| 036          | 24       | \$                   | Dollar sign                  |                      |
| 037          | 25       | %                    | Percent sign                 |                      |
| 038          | 26       | &                    | Ampersand                    |                      |
| 039          | 27       | '                    | Apostrophe                   |                      |
| 042          | 2A       | *                    | Asterisk                     |                      |

(Continued)

**Table B-5. ASCII Characters Available for ELC (Continued)**

| Decimal Code | Hex Code | Graphic/<br>Mnemonic | Name or<br>Meaning | Control<br>Character |
|--------------|----------|----------------------|--------------------|----------------------|
| 043          | 2B       | +                    | Plus               |                      |
| 045          | 2D       | -                    | Hyphen             |                      |
| 046          | 2E       | .                    | Period             |                      |
| 047          | 2F       | /                    | Slant              |                      |
| 058          | 3A       | :                    | Colon              |                      |
| 059          | 3B       | ;                    | Semicolon          |                      |
| 060          | 3C       | <                    | Less than          |                      |
| 062          | 3E       | >                    | Greater than       |                      |
| 063          | 3F       | ?                    | Question mark      |                      |
| 064          | 40       | @                    | Commercial at      |                      |
| 091          | 5B       | [                    | Opening bracket    |                      |
| 092          | 5C       | \                    | Reverse slant      |                      |
| 093          | 5D       | ]                    | Closing bracket    |                      |
| 094          | 5E       | ˆ                    | Circumflex         |                      |
| 095          | 5F       | _                    | Underline          |                      |
| 096          | 60       | `                    | Grave accent       |                      |
| 123          | 7B       | {                    | Opening brace      |                      |
| 124          | 7C       |                      | Vertical line      |                      |
| 125          | 7D       | }                    | Closing brace      |                      |
| 126          | 7E       | ~                    | Tilde              |                      |

Table B-6. ASCII Characters Available for NCC

| Decimal Code | Hex Code | Graphic/Mnemonic | Name or Meaning           | Control Character |
|--------------|----------|------------------|---------------------------|-------------------|
| 001          | 01       | SOH              | Start of heading          | ^A or ^a          |
| 002          | 02       | STX              | Start of text             | ^B or ^b          |
| 003          | 03       | ETX              | End of text               | ^C or ^c          |
| 004          | 04       | EOT              | End of transmission       | ^D or ^d          |
| 005          | 05       | ENQ              | Enquiry                   | ^E or ^e          |
| 006          | 06       | ACK              | Acknowledge               | ^F or ^f          |
| 007          | 07       | BEL              | Bell                      | ^G or ^g          |
| 008          | 08       | BS               | Backspace                 | ^H or ^h          |
| 009          | 09       | HT               | Horizontal tabulation     | ^I or ^i          |
| 010          | 0A       | LF               | Line feed                 | ^J or ^j          |
| 011          | 0B       | VT               | Vertical tabulation       | ^K or ^k          |
| 012          | 0C       | FF               | Form feed                 | ^L or ^l          |
| 013          | 0D       | CR               | Carriage return           | ^M or ^m          |
| 014          | 0E       | SO               | Shift out                 | ^N or ^n          |
| 015          | 0F       | SI               | Shift in                  | ^O or ^o          |
| 016          | 10       | DLE              | Data link escape          | ^P or ^p          |
| 018          | 12       | DC2              | Device control 2          | ^R or ^r          |
| 020          | 14       | DC4              | Device control 4          | ^T or ^t          |
| 021          | 15       | NAK              | Negative acknowledge      | ^U or ^u          |
| 022          | 16       | SYN              | Synchronous idle          | ^V or ^v          |
| 023          | 17       | ETB              | End of transmission block | ^W or ^w          |
| 024          | 18       | CAN              | Cancel                    | ^X or ^x          |
| 025          | 19       | EM               | End of medium             | ^Y or ^y          |
| 026          | 1A       | SUB              | Substitute                | ^Z or ^z          |
| 027          | 1B       | ESC              | Escape                    | ^[                |
| 028          | 1C       | FS               | File separator            | ^\<br>^_          |
| 029          | 1D       | GS               | Group separator           | ^]                |
| 030          | 1E       | RS               | Record separator          | ^^                |
| 031          | 1F       | US               | Unit separator            | ^_                |
| 033          | 21       | !                | Exclamation point         |                   |
| 034          | 22       | "                | Quotation marks           |                   |
| 035          | 23       | #                | Number sign               |                   |
| 036          | 24       | \$               | Dollar sign               |                   |
| 037          | 25       | %                | Percent sign              |                   |
| 038          | 26       | &                | Ampersand                 |                   |
| 039          | 27       | '                | Apostrophe                |                   |

(Continued)

**Table B-6. ASCII Characters Available for NCC (Continued)**

| Decimal Code | Hex Code | Graphic/<br>Mnemonic | Name or<br>Meaning  | Control<br>Character |
|--------------|----------|----------------------|---------------------|----------------------|
| 040          | 28       | (                    | Opening parenthesis |                      |
| 041          | 29       | )                    | Closing parenthesis |                      |
| 042          | 2A       | *                    | Asterisk            |                      |
| 043          | 2B       | +                    | Plus                |                      |
| 044          | 2C       | ,                    | Comma               |                      |
| 045          | 2D       | -                    | Hyphen              |                      |
| 046          | 2E       | .                    | Period              |                      |
| 047          | 2F       | /                    | Slant               |                      |
| 058          | 3A       | :                    | Colon               |                      |
| 059          | 3B       | ;                    | Semicolon           |                      |
| 060          | 3C       | <                    | Less than           |                      |
| 061          | 3D       | =                    | Equals              |                      |
| 062          | 3E       | >                    | Greater than        |                      |
| 063          | 3F       | ?                    | Question mark       |                      |
| 064          | 40       | @                    | Commercial at       |                      |
| 091          | 5B       | [                    | Opening bracket     |                      |
| 092          | 5C       | \                    | Reverse slant       |                      |
| 093          | 5D       | ]                    | Closing bracket     |                      |
| 094          | 5E       | ^                    | Circumflex          |                      |
| 095          | 5F       | _                    | Underline           |                      |
| 096          | 60       | `                    | Grave accent        |                      |
| 123          | 7B       | {                    | Opening brace       |                      |
| 124          | 7C       |                      | Vertical line       |                      |
| 125          | 7D       | }                    | Closing brace       |                      |
| 126          | 7E       | ~                    | Tilde               |                      |





# Messages

C

---

|                              |     |
|------------------------------|-----|
| Understanding Messages ..... | C-1 |
| List of Messages .....       | C-2 |



This appendix alphabetically lists informative and diagnostic messages that the network sends to your terminal.

## Understanding Messages

Each message listing contains two parts:

|             |                                                                                                                                                                         |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Message     | The message that the network sends is listed in boldface, and any variable within that message is shown in italics.                                                     |
| Description | A description follows each message. It explains the status or problem and identifies any variable in the message. In addition, it describes any action you should take. |

If you receive a message that is not listed in this appendix, report it in one of the following ways:

- Ask your site administrator to write a Programming System Report (PSR).
- Note the message on the comment sheet at the back of this manual.

## List of Messages

This alphabetic list contains the messages you receive at your terminal. Messages beginning with symbols (such as dashes) and with variables appear at the end of the list.

### **ACTXPC command not allowed.**

The TIP defined for this terminal does not support the X.PC protocol.

### **Alphabetic character in number: *integer*.**

You entered the value shown as an integer in a network command. Integers used as values in network commands must conform to the syntax described in chapter 2.

If you are entering a radix, use digits within parentheses immediately after the integer. If your use of radix is correct, ensure that the integer does not contain a letter out-of-range for its radix.

### **Attribute name *attribute* is invalid.**

The network did not recognize the attribute you specified on the DISPLAY\_TERMINAL\_ATTRIBUTE or DISPLAY\_CONNECTION\_ATTRIBUTE command.

Look for a typographical error in the attribute name or abbreviation. Check the command format, and reenter the command.

### **Attributes changed.**

The network successfully executed the CHANGE\_TERMINAL\_ATTRIBUTE or CHANGE\_CONNECTION\_ATTRIBUTE command that you just entered.

### **Auto recognition not defined for this line.**

You entered the ACTIVATE\_AUTO\_RECOGNITION command. However, the network cannot perform automatic recognition for your terminal because the site administrator has not configured your communication line for it.

If you need to change PARITY or CODE\_SET, use a CHANGE\_TERMINAL\_ATTRIBUTE command. (Chapter 4 describes the attributes). If you need to change line speed, contact your site administrator.

**Cannot create connection.**

The network cannot find the service name you requested. Try again later.

**Cannot create name starting with \$.**

The connection name in the CREATE\_CONNECTION command just entered began with a dollar sign (\$). Connection names beginning with a dollar sign are reserved for internal CDCNET use. Reenter the command with a unique connection name that does not begin with a dollar sign.

**Cannot delete connection \$NET.**

Only ASYNCTIP or X25\_ASYNCTIP users can delete the \$NET connection with the DELC \$NET command. If you are not using either of these two TIPs, or you did not specify a CONNECTION\_NAME parameter value of \$NET and your working connection is \$NET, the network returns this response.

**Cannot locate service *service name*.**

The network cannot connect you to the service you requested on the CREATE\_CONNECTION command due to one of the following:

- The network does not recognize the service name because it contains a typographical error.
- The service is not currently connected through CDCNET.

If the name is spelled correctly, either reenter the command later or select another comparable service. If the name is misspelled, reenter the command using the correct spelling.

**Character code integer is out of range.**

An integer value for a character is out of range. The network accepts integers within the range of 1 .. FF(16). (See appendix B for information on entering decimal and hexadecimal codes.) Reenter the command with an appropriate integer value.

**Character code name *value* is invalid.**

The control code mnemonic specified in your command is not valid. Table B-1 lists the valid mnemonics for control characters NUL through US. Reenter the command using a valid mnemonic.

**Character code name *value* is too long.**

The specified portion of your last command contains more characters than are allowed. The command contains a typographical or syntax error. If you attempted to enter a hexadecimal value, ensure that the first digit is 0 through 7. Reenter the command using the correct format.

**Character code string is too long.**

The string that you entered as a character value was greater than one character long. (See appendix B for information on using a string as a character value.)

**Client connection complete *system=system\_name line=line\_name*.**

A client, on the named system with the named line, has paired with your passthrough server connection.

**Command only valid for X.25 terminals.**

A SET\_PAD\_MESSAGE (SETPM) command was entered from a non-X.25 terminal.

**Command *entry* not allowed from \$NET.**

Since you are connected to \$NET, you cannot enter a DISPLAY\_CONNECTION\_ATTRIBUTE or CHANGE\_CONNECTION\_ATTRIBUTE command. Enter a CHANGE\_WORKING\_CONNECTION or CREATE\_CONNECTION command to access a service connection and reenter your original command.

**Command *entry* too long.**

The command cited is longer than 256 characters. Work with your site administrator to shorten the command before executing the procedure again.

**Conflict in *attribute* and *attribute*:**

You attempted to change an attribute listed in the message. The attempt failed due to one of the following:

- The attributes cannot have the same values.
- You assigned an incorrect value to one of the attributes.

Reenter the CHANGE\_TERMINAL\_ATTRIBUTE or CHANGE\_CONNECTION\_ATTRIBUTE command with a different value for the attribute you want changed. (See appendix B for information on entering character values.)

**Conflict in TFC and AC.**

The network sends this message, preceded by the message 'No attributes changed.' in response to a CHACA command. The value just declared for the TRANSPARENT\_FORWARD\_CHARACTER is already in use as the ATTENTION\_CHARACTER. When CDCNET receives that value, it processes the value as an ATTENTION\_CHARACTER only. If that usage is not acceptable, you should change one of the two attributes.

**Conflict in TFC and CFC.**

The network sends this message, preceded by the message 'No attributes changed.' in response to a CHACA command. The TRANSPARENT\_FORWARD\_CHARACTER cannot be DC1 or DC3 when CHARACTER\_FLOW\_CONTROL is set to ON. With this setting, CDCNET processes only DC1 or DC3 as a flow control character. If that usage is not acceptable, you should change the TRANSPARENT\_FORWARD\_CHARACTER.

**Conflict in TTC and AC.**

The network sends this message, preceded by the message 'No attributes changed.' in response to a CHACA command. The value just declared for the TRANSPARENT\_TERMINATE\_CHARACTER is already in use as the ATTENTION\_CHARACTER. When CDCNET receives that value, it processes it as an ATTENTION\_CHARACTER only. If that usage is not acceptable, you should change one of the two attributes.



### **Conflict in TTC and CFC.**

The network sends this message, preceded by the message 'No attributes changed.' in response to a CHACA command. The value just declared for the `TRANSPARENT_TERMINATE_CHARACTER` cannot be DC1 or DC3 when `CHARACTER_FLOW_CONTROL` is set to ON. With this setting, CDCNET processes only DC1 or DC3 as a flow control character. If that usage is not acceptable, you should change the `TRANSPARENT_TERMINATE_CHARACTER`.

### **Conflict in TTC and TFC.**

The network sends this message, preceded by the message 'No attributes changed.' in response to a CHACA command. The value just declared for the `TRANSPARENT_TERMINATE_CHARACTER` is already in use as the `TRANSPARENT_FORWARD_CHARACTER`. When CDCNET receives this value, it processes it as the `TRANSPARENT_FORWARD_CHARACTER` only. If that usage is not acceptable, you should change one of the two attributes.

### **Connection to Passthrough Service complete.**

You created a connection to the passthrough service. You are now able to enter a `DEFINE_PASSTHROUGH_TITLE` command.

### **Connection to Site Passthrough service *service name* complete.**

You entered a `CREATE_CONNECTION` command and successfully created a connection to a passthrough service that was defined by your site administrator. The second line of this message identifies the DI system and line that you are using.

**System** = *service name*, **Line** = *line name*.

### **Connection to User Passthrough service *service name* complete.**

You entered a `CREATE_CONNECTION` command and successfully created a connection to a passthrough service that was defined by another user. The second line of this message identifies the DI system and line that you are using.

**System** = *service name*, **Line** = *line name*.

### **Connection *connection name* created.**

The network successfully executed the `CREATE_CONNECTION` command you just entered or your connection that was waiting has completed.

**Connection *connection name* deleted.**

The network successfully executed the DELETE\_CONNECTION command you just entered.

**Connection *connection name* pending.**

The connection name you specified in the CHANGE\_WORKING\_CONNECTION has not been changed because it is pending. This message is issued when you use CREATE\_CONNECTION command with WAIT=YES.

**Connection *connection name* is unknown.**

The connection name you specified in the CHANGE\_WORKING\_CONNECTION or DELETE\_CONNECTION command contained a typographical error or did not exist. As a result, CDCNET cannot identify the correct connection.

Reenter the command if the original problem was a typographical error. If not, enter a DISPLAY\_CONNECTIONS command to see if the connection still exists.

**Connection *connection name* to *service\_name* complete.**

The connection that was pending has successfully been created.

**Copyright Control Data Corporation, 1985, 1986, 1987, 1988.**

The network sends a four-line message when you access CDCNET. In addition to the copyright information, the network sends the following three lines to your terminal. The variable parts of the message are indicated in the following example by the letter x.

```
DI System Name is 080025xxxxxx, xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx
Terminal Name is xxxxxx, xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx
You may enter CDCNET commands.
```

The second line gives the DI system name, the third identifies your terminal name, and the fourth prompts you to enter network commands.

If you need assistance with your connection, knowing the DI system name and terminal name can help the site administrator or network operator respond effectively. (See the DISPLAY\_CONNECTIONS command in chapter 2 for more information on these names.)

**Digit too large for radix of integer: *integer***

A digit within the integer is greater than or equal to the radix value. (See chapter 2 for information on using radices.)

**Duplicate connection name.**

The CREATE\_CONNECTION command that you just entered specified a name of an existing connection.

Use the DISPLAY\_CONNECTIONS command to check the names of your existing connections. Reenter the CREATE\_CONNECTION command with a unique connection name.

**ENGAGED**

The network issues this message after receiving an X.28 command requesting the status of the X.25 connection. The message indicates an X.25 connection exists with a remote DTE.

**Expecting command, found *entry*.**

The network expected a command instead of what it found. Your entry did not adhere to network syntax; a delimiter is probably missing. (See chapter 2 for information on command syntax.)

**Expecting digit in number.**

The network found an alphabetic or special character instead of an integer value.

**Expecting end of default specification for parameter *entry* found *value*.**

The specified text occurred immediately following the default specification and is not meaningful there. A delimiter was probably omitted. Ask your site administrator to write a PSR.

**Expecting end of expression, found '*entry*'.**

The entry was found following an expression that was apparently meant to be part of that expression, but could not be interpreted as such. You probably omitted a delimiter or operator. Correct the expression.

**Expecting end of parameter entry found value.**

The specified entry occurred immediately following the default specification and is not meaningful there. You probably omitted a delimiter. Check the parameter format, and reenter it.

**Expecting end of value for parameter entry found value.**

The specified entry occurred immediately following a value for the parameter and is not meaningful there. You probably omitted a delimiter. Check parameter format, and reenter it.

**Expecting end of value list for parameter entry.**

The command you just entered contained an incorrect parameter. Check command format, and reenter the command.

**Expecting end of value set for parameter entry.**

The specified entry occurred immediately following a value set for the parameter and is not meaningful there. You probably omitted a delimiter. Check parameter format, and reenter it.

**Expecting keyword, found entry.**

The network expected a keyword value, but instead found the entry cited (or empty). The names that many of the terminal attributes and connection attributes accept as values are also called keyword values. For example, the names INPUT\_EDITING\_MODE uses (NORMAL and TRANSPARENT) are keyword values.

**Expecting *type-1*, found *type-2*.**

The command you entered contains the wrong type of parameter value. Type-1 indicates which of the following values the network expected.

- Value
- Boolean
- Name
- Integer
- Character

Instead of finding that type of value, the network encountered one of the following (type-2).

- End of expression
- End of line

This type-2 option means you may have entered an incomplete command or not pressed the RETURN key (not sent an END\_LINE\_CHARACTER). Reenter the command using the correct format.

**Expecting value, found @.**

The procedure name parameter on the DO command begins with the @ character. These names are valid only for TUPs that are executed as a result of a network definition command (such as DEFINE\_LINE).

**FREE**

The network issues this message after receiving an X.28 STAT command, requesting the status of the X.25 connection. Message indicates no X.25 connection with a remote DTE currently exists.

**Improper parameter description table: NAMES is NIL but PARAMETERS is not.**

The network detected an error in the command's parameter description table: no parameter names are specified but parameter values are defined. Ask your site administrator to write a PSR.

**Improper parameter description table: ^NAMES [i].NUMBER > UPPERBOUND(PARAMETERS^).**

The network detected an error in the command's parameter description table: the number of parameter names is greater than the number of parameter definition items. Ask your site administrator to write a PSR.

**Improper parameter description table: Not all PARAMETERS have a NAME.**

The network detected an error in the command's parameter description table: a parameter definition item exists with no name. Ask your site administrator to write a PSR.

**Improper parameter description table: PARAMETERS is NIL but NAMES is not.**

The network detected an error in the command's parameter description table: no parameter value definitions exist but parameter names are defined. Ask your site administrator to write a PSR.

**Improper parameter description table: Too many names.**

The network detected an error in the command's parameter description table: the number of possible parameter values defined in the command's parameter description table exceeds the maximum allowed number of parameter values. Ask your site administrator to write a PSR.

**Improper radix specifier: *entry*.**

The network found a bad radix specifier in the command string. (See chapter 2 for information on using radices.)

**Improper radix value: *entry*.**

The network found an incorrect value in the radix; it must be 8, 10, or 16. (See chapter 2 for information on using radices.)

**Input cancelled.**

You performed an action that caused CDCNET to discard your input. Using a CANCEL\_LINE\_CHARACTER or possibly pressing an ATTENTION\_CHARACTER key causes such a condition. Reenter your input.

**Input discarded.**

The network discarded your last command since you previously entered too many CDCNET commands that the network has not yet processed.

**Insufficient resources to load X.PC TIP.**

No RAM is available on the Communications Interface Module (CIM) to load the X.PC TIP CIM software. Add another CIM for the X.PC device or remove an unrequired TIP from the CIM associated with this device.

**Invalid user interrupt.**

The network returns this response when you enter a Network Command character followed by a character that is not alphabetic or numeric, but a reserved symbol. Only alphabetic or numeric characters may follow a Network Command character.

**Integer value *value* is out of range.**

The network detected an integer value outside the expected range (as defined in the command's parameter description table).

**Invalid value specified for parameter *-entry-*.**

The attribute that you specified on the CHANGE\_TERMINAL\_ATTRIBUTE or CHANGE\_CONNECTION\_ATTRIBUTE command does not apply to the protocol (such as Asynchronous or HASP) you are using. Therefore, you cannot change it.

**Missing radix specifier for integer: *integer*.**

The integer cannot contain letters unless it is a hexadecimal value (with A, B, C, D, E, or F); it must begin with a digit and end with the radix specification (16). Reenter the command and enclose the radix in parentheses.

**Missing string delimiter: *'entry*.**

An apostrophe, which delimits strings, was missing from the string cited. Reenter the command enclosing the string in apostrophes.

**Name value *value* too long.**

The name you specified on the command was longer than the allowed 31 characters. For example, you may have entered a connection name on the CREATE\_CONNECTION command that was too long. Reenter the command using the correct format.

**Name value *value* too short.**

The network detected a name value shorter than expected (as defined in the command's parameter description table).

**Network is currently congested.**

The network cannot process the CREATE\_CONNECTION command you just entered because it lacks the resources now to support another connection. Try again later. Deleting unneeded connections may help relieve the congestion.

**Network operator may have disabled requests.**

If your command was REQUEST\_NETWORK\_OPERATOR, the operator is not receiving messages from terminal users. Contact your site administrator to enable alarm message 168 if you need this capability.

**No attributes changed.**

The message following this one explains why your attributes remain unchanged. Correct the problem and try again. The message also precedes a second message identifying an attribute conflict.

**No attributes changed. Conflict in use of control code *control code*.**

The control or replacement code used is not permitted or out of range.

**No connection present -- timeout.**

You did not create a connection within the allowed time and have been disconnected from the network. Reaccess CDCNET and create a connection when the network prompts you to enter CDCNET commands. (See Understanding Configuration Options in chapter 1 for information on timeouts or contact your site administrator to find out the length of your site's disconnect timeout.)



**No displayable services in list.**

When you enter a DISPLAY SERVICE command, the network sends this message if your site administrator has not specified any service names to be displayed.

**No services are displayable.**

When you enter a DISPLAY\_SERVICE command, the network sends this message if your network administrator has not permitted the display of any services at your terminal.

**Not a required operator device of an I/O station.**

The CREATE\_CONNECTION (CREC) command was rejected because the requested service is a C170 Batch Gateway title and the console from which the CREC command was entered is *not* the required operator device of a batch I/O station. A console can be defined as the required operator device of a batch I/O station using the DEFINE\_I\_O\_STATION (DEFIOS) configuration command.

**Output discarded.**

The network discarded output sent to your terminal on \$NET since the connection's queue is already full.

**Parameter CONNECTION\_NAME is required when DELC is entered from the \$NET connection.**

The network returns this response when you enter the DELC command from the \$NET connection without specifying a CONNECTION\_NAME parameter value.

**Parameter *entry* given more than once.**

The command that caused this message contained duplicate parameters. The network ignored the command and stopped executing the procedure.

Look for a typographical error in a parameter name or abbreviation. Check the command format, and change the command. Rerun the procedure.

**Parameter entry is required but was omitted.**

The command that caused this message does not contain the required parameter cited. The network ignored the command and stopped executing the procedure. Look for a missing blank or comma. Check the command format, and change the command by adding the missing parameter. Rerun the procedure.

**PAR INV:*n***

The network issues this message after receiving an X.25 Terminal Gateway command (SET) specifying an invalid X.3 reference number.

**PAR*n*:INV**

The network issues this message after receiving an X.25 Terminal Gateway command (SET) specifying an invalid value for an X.3 reference number.

**Passthrough client connection disconnected.**

The passthrough service is notifying you, the passthrough server, that the paired client has disconnected.

**Passthrough connection attributes reset.**

By entering the \$NET-switch sequence (BREAK key or attention character, CONTROL key, and C), you escaped to \$NET from your working connection (a passthrough service). Subsequently, you entered a CHANGE\_WORKING\_CONNECTION command and returned to the passthrough-service connection. When you pressed the RETURN key (entered an END\_LINE\_CHARACTER) after returning, the network reset your connection attributes with passthrough connection attribute values.

**Passthrough connection *connection name* timeout.**

Since you did not enter any data during the last 30 seconds, the passthrough service has disconnected your passthrough connection (with the connection name identified in the message) from the passthrough server you were using.

**Passthrough connection *connection name* timeout in 30 seconds.**

After issuing this message, the network sends an ASCII BEL character. To avoid being disconnected, enter data within 30 seconds.

**Passthrough input discarded. Please define titles.**

If you enter input other than a `DEFINE_PASSTHROUGH_TITLE` command after a `CREATE_CONNECTION` command to your site's passthrough service, the network discards the input and prompts you to enter the command.

**Passthrough input discarded. Passthrough connection attributes reset.**

By entering the escape to \$NET connection sequence, you escaped to \$NET from your working connection (a passthrough service). Subsequently, you entered a `CHANGE_WORKING_CONNECTION` command and returned to the passthrough-service connection. The network reset your connection attributes and discarded the data you entered before pressing the RETURN key.

**Passthrough input discarded. Waiting for client.**

After you are configured as a passthrough server, all your input is discarded until a client connection is paired with your server connection.

**Passthrough server connection disconnected.**

The passthrough service is notifying you, the passthrough client, that the paired server connection has disconnected and, as a result, the network will now disconnect your connection.

**Passthrough service stopped.**

Both the server and the client are notified with this message when a network operator stops the passthrough service.

**Passthrough service titles defined.**

In response to your `DEFINE_PASSTHROUGH_TITLE` command, the network has registered the names you specified.

**Passthrough service titles not registered.**

The network sends this message if it cannot register, in the CDCNET directory, the titles specified by your `DEFINE_PASSTHROUGH_TITLE` command. Reenter the `DEFPT` command.

**Passthrough service titles registered.**

The network sends this message after registering the titles specified by your `DEFINE_PASSTHROUGH_TITLE` command.

**Passthrough titles not defined.**

You must enter a `DEFINE_PASSTHROUGH_TITLE` command again in order to configure yourself as a passthrough server.

**PROC statement missing or not first.**

Either the PROC statement is missing, or it is not the first statement in the procedure. Ask your site administrator to change the first statement to an appropriate PROC statement. When the problem has been corrected, execute the procedure again.

**Procedure name mismatch. DO *procedure name* and PROC *procedure name*.**

In the procedure you just tried to execute, the procedure name in the PROC statement does not match the procedure name you specified on the DO command. Correct the problem by doing one of the following:

- Check for typographical errors and reenter the DO command with the correct procedure name.
- Work with your site administrator to make the procedure names specified on the PROC statement and the DO command match.

**Procedure nesting limit reached.**

A terminal user procedure can only contain one DO command for another terminal user procedure. Work with your site administrator to reduce the number of nested procedures to one.

**Procedure service is unavailable.**

The CDCNET software that processes requests to execute terminal user procedures is temporarily unavailable. If you received this message in response to a DO command, try reentering the command later. If it appeared when you initially accessed the service, your automatically executed terminal user procedure did not execute. In either case, you are currently using the default terminal attributes and connection attributes.

**Procedure *procedure name* aborted.**

The network did not successfully execute the cited terminal user procedure. It ignored some or all of the commands. Additional messages should identify the problem that needs fixing.

**Procedure *procedure name* access error.**

The network cannot read the procedure you just tried to execute. The problem may be a non-ASCII88 formatted procedure file.

**Procedure *procedure name* completed.**

The network executed the cited procedure successfully. This procedure was called either automatically when you accessed your service or by a DO command that you just entered.

**Procedure *procedure name* not found.**

Execution of the named procedure was requested, either automatically at initial connection to CDCNET, or by using a DO command. Since this procedure is not available to CDCNET, it did not execute the procedure.

Work with your site administrator to solve this problem. CDCNET may not be able to find the procedure because the site administrator has not yet stored it, or because the procedure name is misspelled.

**Request forwarded to network operator.**

The network successfully executed the REQUEST\_NETWORK\_OPERATOR command that you just entered.

**Searching for service *service name*. Connection *connection\_name* pending.**

The service you asked to be connected to is unavailable, and the connection is pending. This message is issued when you use `CREATE_CONNECTION` command with `WAIT=YES`.

**Service *service name* busy.**

The service cannot accept another connection at this time. Either reenter the command at a later time or select another service. This message is received when you use `CREATE_CONNECTION` with `WAIT=NO`.

**Service *service name* unavailable.**

You cannot use the service specified for one of the following reasons:

- The service cannot accept another connection at the moment.
- You are not allowed access to that service.

Either reenter the command at a later time or select another comparable service. If the name is misspelled, reenter the command using the correct spelling.

## **SET ERR**

The `SET` command contains a syntax error. Correct the syntax and reenter the command.

**String value too long.**

The network detected a string value longer than expected (as defined in the command's parameter description table). For example, the string in a `PUT_STRING` command contained more than 80 characters. Shorten the string and reenter the command.

**String value too short.**

The network detected a string value shorter than expected (as defined in the command's parameter description table).

**Table overflow: pvt names: insufficient memory to parse command.**

An error occurred when the network tried to allocate global memory space for the parameter names. Reenter the command later, or contact your site administrator.

**TIP rejects connection.**

The TIP that provides the interface to this terminal cannot accept this connection. For example, the X.PC TIP supports multiple logical channels over a single communications link and the TIP controls the total number of user connections on the link.

**Table overflow: pvt parameters: insufficient memory to parse command.**

An error occurred when the network tried to allocate global memory space for the parameters. Reenter the command later, or contact your site administrator.

**Table overflow: pvt values: insufficient memory to parse command.**

An error occurred when the network tried to allocate global memory space for the parameter values. Reenter the command later, or contact your site administrator.

**Table overflow: string values: insufficient memory to parse command.**

Memory to hold a string value was requested from the network but not satisfied. Reenter the command later when there is less congestion, or contact your site administrator.

**Too few values given for parameter entry.**

The network found too few values in the parameter. Reenter the command using the correct format.

**Too few values in value set given for parameter *entry*.**

The network found too few values in the value set in the parameter. Reenter the command using the correct format.

**Too few values sets given for parameter *entry*.**

The network found too few value sets in the parameter. Reenter the command using the correct format.

**Too many parameters given.**

More parameters were entered with the command than are defined for the command. This usually occurs when parameters are given positionally or when a command has no parameters. Reenter the command using the correct format.

**Too many values given for parameter *entry*.**

The network found too many values in the parameter. Reenter the command using the correct format.

**Too many values in value set given for parameter *entry*.**

The network found too many values in the value set in the parameter. Reenter the command using the correct format.

**Too many value sets given for parameter *entry*.**

The network found too many value sets in the parameter. Reenter the command using the correct format.

**Unable to process ACTXPC commands (no resources).**

The network currently lacks the resources to process the ACTXPC command. Try again later.

**Unable to process command *entry*.**

The network lacks the resources to process that command at this time. Try again later.



**Unexpected call to *entry*.**

The command processor processing a command made an unexpected call to one of the parser routines. Ask your site administrator to write a PSR.

**Unexpected *entry* after command.**

The specified entry immediately followed a command name. You probably omitted a delimiter. Reenter the command.

**Unknown command *entry*.**

The indicated command does not exist. Check the spelling of the command name or abbreviation, and reenter the command.

**Unknown destination for *put string*.**

The PUT\_STRING command attempted to send data to a service when no connection to it existed. Establish a connection with the CREATE\_CONNECTION command before executing the procedure again.

**User connection limit exceeded.**

You attempted to create a new connection with a valid CREATE\_CONNECTION command, but you have already reached your connection limit. (See Understanding Configuration Options in chapter 1 for more information on this limit.)

You can display your existing connections and connection limit with the DISPLAY\_CONNECTIONS command. Delete a connection with the DELETE\_CONNECTION command, and then reenter the CREATE\_CONNECTION command.

**User interrupt ignored.**

You have already either pressed the BREAK key or the ATTENTION\_CHARACTER key or have entered a %1 or %2. The network can process only one of these at a time.

**Value range not allowed for parameter *entry*.**

The network does not recognize value ranges (such as 1..6) in the parameter cited. Reenter the command using the correct format.

**Working connection changed to *connection name*, service name *service name*.**

The network successfully executed the CHANGE\_WORKING\_CONNECTION command that you just entered. You are communicating on the named working connection. The service on that connection is available for you to use.

**You may enter CDCNET commands.**

You are connected to \$NET, the connection that the network uses to communicate with your terminal. You can enter CDCNET commands without prefixing them with the NETWORK\_COMMAND\_CHARACTER. Either disconnect from CDCNET or enter a command (such as CREATE\_CONNECTION, CHANGE\_WORKING\_CONNECTION, or another CDCNET command).

**--ERROR-- An X25 connection currently exists.**

The network issues this response after receiving a CREATE\_X25\_CONNECTION command from a terminal that already has an active X25 connection.

**--ERROR-- A remote\_dte\_address may include only digits 0 through 9.**

The network issues this message after receiving a CREXC command with an invalid REMOTE\_DTE\_ADDRESS parameter value. The REMOTE\_DTE\_ADDRESS parameter of the CREATE\_X25\_CONNECTION command must contain only digits 0 through 9. Reenter the command with a valid REMOTE\_DTE\_ADDRESS.

**--ERROR-- Connection broken. The local DTE has cleared the connection. Clearing cause code=XX and diagnostic code=YY.**

The network issues this message after the local DTE has broken the X.25 connection. Compare the hexadecimal clearing cause code and the diagnostic code in the message with table values in the CCITT X.25 specifications to determine why the local DTE cleared the connection.

**--ERROR-- Connection broken. The remote DTE has cleared the connection. Clearing cause code=XX and diagnostic code=YY.**

The network issues this message after the remote DTE has broken the X.25 connection. Compare the hexadecimal clearing cause code and the diagnostic code in the message with table values in the CCITT X.25 specifications to determine why the remote DTE cleared the connection.

**--ERROR-- Connection broken. The X.25 interface has been stopped by a network operator.**

The network issues this message when the operator breaks the X.25 physical connection.

**--ERROR-- Connection broken. The X.25 link has temporarily gone down.**

The network issues this message when the X.25 PDN goes down.

**--ERROR-- Connection broken. The X.25 link is currently experiencing problems.**

The network issues this message when it detects an error in the X.25 PDN, indicated by an X.25 restart packet. The problem may be a congested network.

**--ERROR-- Connection broken. The X.25 link is now inoperative.**

The network issues this message when an X.25 trunk goes down during an interactive connection.

**--ERROR-- Connection rejected. All X.25 logical channels are currently busy.**

The network issues this message if it cannot establish an X.25 connection because all X.25 logical channels are currently busy.

**--ERROR-- Connection rejected. The local dte address is currently inoperative.**

The network issues this message when it cannot establish an X.25 connection because the X.25 trunks are down.

**--ERROR-- Connection rejected. The network is currently congested.**

The network issues this message when it cannot create a connection because the NDI memory is congested.

**--ERROR-- Connection rejected. No memory is available.**

The network issues this message when an X.25 connection cannot be established because the device interface does not have enough memory to create the control blocks needed for the connection.

**--ERROR-- Connection to X.25 Terminal Gateway broken. The network operator has stopped the X.25 Terminal Gateway.**

The network issues this message after the network operator has stopped activity through an active X.25 Terminal Gateway. The network disconnects you from the X.25 Terminal Gateway and breaks the connection with the remote DTE with which you were communicating.

**--ERROR-- Parameter COMMAND is required but was omitted.**

The network issues this message after receiving a command with no COMMAND parameter.

**--ERROR-- Parameter SERVICE\_NAME is required but was omitted.**

The CREXC command must include a SERVICE\_NAME parameter value matching a site-defined title. Reenter the command.

**--ERROR-- Too many parameters given.**

The network issues this message when you enter a command with too many parameters. Reenter the command with the correct parameters.

**--ERROR-- Unable to locate service *service\_name*.**

The network issues this message when it cannot find the service specified by the CREXC command.

**--ERROR-- Unauthorized remote DTE address specified.**

The CREATE\_X25\_CONNECTION command specified a remote DTE address for which you are not authorized access.

**--ERROR--xxxx is not a command.**

The command name you specified is not a valid command.

*speed* **bps**, *code set*, **parity**: *parity*.

As a result of the automatic recognition process just completed, CDCNET is indicating the values used for line speed, CODE\_SET, and PARITY. The terminal line speed is given as bits per second. CODE\_SET, and PARITY are identified by attribute values (see chapter 3 for a description of the CODE\_SET and PARITY terminal attributes).

If these values are acceptable, no action is needed. For more information on automatic recognition, see chapter 8 and the description of the ACTIVATE\_AUTO\_RECOGNITION command in chapter 2.

**entry is not a parameter name.**

The indicated portion of the last command you entered was interpreted as a parameter name. No such parameter exists for that command. Check for a typographical error or a misplaced space. Reenter the command using the correct format.

**entry is not an allowed keyword value.**

The network expected a keyword value, but instead found the entry cited (or empty). The names that many of the terminal attributes and connection attributes accept as values are also called keyword values. For example, the names INPUT\_EDITING\_MODE uses (NORMAL and TRANSPARENT) are keyword values.

*remote DTE banner and login prompt*

The network sends the banner and login prompt of the remote DTE after establishing a valid X.25 connection.

**X.PC already activated.**

The network returns this message after receiving an ACTXPC command, although the XPC TIP is currently active.

**X.PC not defined for this line.**

The X.PC TIP has not been defined in the DI connected to this device.

**X.PC protocol being activated.**

The network returns this message after successfully executing the ACTXPC command.



# Migrating from CCP

# D

---

|                                                                      |      |
|----------------------------------------------------------------------|------|
| Using NOS/VE and NOS Commands .....                                  | D-2  |
| Migrating from CCP to CDCNET .....                                   | D-4  |
| Using the CDCNET Default Network Command Character .....             | D-4  |
| Using CDCNET Attributes with the TRMDEF Command .....                | D-4  |
| Using Terminal Definition Mnemonics with the TRMDEF<br>Command.....  | D-9  |
| Corresponding Terminal Attributes and Connection<br>Attributes ..... | D-9  |
| TRANSPARENT Input .....                                              | D-9  |
| Effects of Changing NOS Terminal Classes .....                       | D-12 |
| CDCNET Mapping of Field Number/Field Value Pairs .....               | D-15 |
| Corresponding Terminal Attributes and Connection<br>Attributes ..... | D-15 |
| TRANSPARENT Input .....                                              | D-16 |





This appendix provides the following service-specific information for NOS and NOS/VE users:

- Briefly describes NOS/VE and NOS commands that manipulate CDCNET terminal attributes and connection attributes.
- Discusses migrating to CDCNET from CCP, the communication control program that resides in a 255X communication device.

This service-specific information is based on the assumption you are accessing a NOS/VE or NOS service through CDCNET. That is, you are processing on one of the following:

- NOS/VE on a CYBER 180 mainframe. (You are using NAM/VE and CDCNET.)
- NOS on a CYBER 170 mainframe or a CYBER 180 mainframe that runs NOS-only or NOS and NOS/VE in dual state. (You are using NAM and CDCNET.)

## Using NOS/VE and NOS Commands

Services can provide commands that enable you to change, display, and use terminal attributes and connection attributes.

NOS/VE supports the following:

**CYBIL procedure calls**      On NOS/VE, you can use CYBIL procedure calls to manipulate CDCNET attributes. These include the following:

```
IFP$CHANGE_TERM_CONN_ATTRIBUTES
IFP$CHANGE_TERM_CONN_DEFAULTS
IFP$CHANGE_TERMINAL_ATTRIBUTES
IFP$FETCH_TERM_CONN_ATTRIBUTES
IFP$GET_TERM_CONN_ATTRIBUTES
IFP$GET_TERM_CONN_DEFAULTS
IFP$GET_TERMINAL_ATTRIBUTES
RMP$REQUEST_TERMINAL
IFP$STORE_TERM_CONN_ATTRIBUTES
```

See CYBIL File Management Usage for descriptions of these calls.

**SCL commands**      On NOS/VE, you can use SCL commands to manipulate CDCNET attributes. These include the following:

```
CHANGE_CONNECTION_ATTRIBUTES
CHANGE_TERM_CONN_DEFAULTS
CHANGE_TERMINAL_ATTRIBUTES
DISPLAY_CONNECTION_ATTRIBUTES
DISPLAY_TERM_CONN_DEFAULTS
DISPLAY_TERMINAL_ATTRIBUTES
DISPLAY_TERMINAL_MODEL
SET_TERMINAL_ATTRIBUTES
```

See NOS/VE System Usage for descriptions of SCL commands that change and retrieve CDCNET attributes.

NOS supports the following:

**TRMDEF command**

You may use either CDCNET attributes or CCP mnemonics with the TRMDEF command. However, you cannot use both in the same command. Mnemonics are also used with the CCP terminal definition commands.

In this manual, they are called terminal definition mnemonics. For example, CI is used for carriage-return idle count and CN for cancel character. (See NOS Version 2 Reference Set, Volume 3, System Commands for descriptions of this command and the mnemonics.)

**Control bytes**

In a program, you can use field number/field value pairs (FN/FV) with the 0010 (terminal redefinition for NAM/CDCNET) and 0016 (terminal redefinition) control byte to alter the characteristics of a terminal connected to the Interactive Facility (IAF) on NOS. (See NOS Version 2 Reference Set, Volume 4, Program Interface for more information.)

**CTRL/CHAR/R  
supervisory message**

In an application (such as the Interactive Facility [IAF] and Printer Support Utility [PSU]), you can use field number/field value pairs (FN/FV) with the CTRL/CHAR/R supervisory message to redefine the characteristics of a terminal.

The application sends this message to the Network Access Method (NAM). (See Network Products, Network Access Method [NAM] Version 1, Host Application Programming Reference Manual for more information.)

## Migrating from CCP to CDCNET

If you have been using CCP and are now communicating with your service through CDCNET, the change may affect your use of terminal characteristics in the following ways.

- Using the CDCNET default Network Command Character
- Using CDCNET attributes with the TRMDEF command
- Using terminal definition mnemonics with the TRMDEF command
- Effects of changing NOS terminal classes
- CDCNET mapping of field number/field value (FN/FV) pairs

### Using the CDCNET Default Network Command Character

When accessing NOS through CDCNET, you must be aware that the default Network Command Character (NCC) is a percent sign (%) and not the ESCAPE key (ESC). You can, if you prefer, change the NCC by using the CDCNET command, `CHANGE_TERMINAL_ATTRIBUTE` (CHATA). See chapters 2 and 3 for more information on CHATA and NCC respectively.

### Using CDCNET Attributes with the TRMDEF Command

When accessing NOS through CDCNET, you can specify CDCNET terminal attributes instead of terminal definition mnemonics. To do this, enter terminal attributes in the `tci=vi` parameter of the TRMDEF command.

Using attributes enables you to manipulate a larger set of terminal characteristics than you can with terminal definition mnemonics. However, you must adhere to NOS conventions and TRMDEF requirements when you specify attributes. The following examples illustrate the differences between entering terminal attributes on the `CHANGE_TERMINAL_ATTRIBUTE` (CDCNET) and TRMDEF (NOS) commands.

| Difference           | Examples                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Integer codes        | <p data-bbox="440 199 999 291">CDCNET accepts decimal and hexadecimal codes as values for integers. Hexadecimal codes must include a trailing radix (16).</p> <pre data-bbox="486 326 712 354">%CHATA CLC=21(16)</pre> <p data-bbox="440 383 1034 440">The TRMDEF command requires an X before a hexadecimal value.</p> <pre data-bbox="486 475 672 503">TRMDEF,CLC=X21</pre>                                                                                                                                                                                                                                                            |
| Empty or null        | <p data-bbox="440 531 936 588">CDCNET and the TRMDEF command represent empty strings differently.</p> <p data-bbox="440 618 850 645">CDCNET uses two apostrophes.</p> <pre data-bbox="486 680 658 708">%CHATA EOS=''</pre> <p data-bbox="440 737 1022 795">The TRMDEF command accepts only empty strings for the following terminal attributes:</p> <pre data-bbox="486 829 959 951">CARRIAGE_RETURN_SEQUENCE END_OUTPUT_SEQUENCE FORM_FEED_SEQUENCE LINE_FEED_SEQUENCE</pre> <p data-bbox="440 980 1042 1038">The command recognizes the following format as an empty string.</p> <pre data-bbox="486 1072 647 1100">TRMDEF,EOS=.</pre> |
| Character delimiters | <p data-bbox="440 1130 927 1187">CDCNET uses apostrophes to delimit characters.</p> <pre data-bbox="486 1222 675 1249">%CHATA CLC='!'</pre> <p data-bbox="440 1279 991 1307">The TRMDEF command uses dollar signs.</p> <pre data-bbox="486 1341 678 1369">TRMDEF,CLC=\$!\$</pre>                                                                                                                                                                                                                                                                                                                                                         |

**Difference**

**Examples**

---

Sequences

CDCNET uses sequences for the following terminal attributes:

```
CARRIAGE_RETURN_SEQUENCE
END_OUTPUT_SEQUENCE
FORM_FEED_SEQUENCE
LINE_FEED_SEQUENCE
```

The TRMDEF command allows you to enter hexadecimal codes for these sequences and TERMINAL\_MODEL.

```
TRMDEF,EOS=X072F
```

CDCNET accepts hexadecimal codes as values for sequences.

```
%CHATA EOS=(7(16) 2F(16))
```

In addition, CDCNET recognizes decimal codes, strings, mnemonics, and control characters as values.

```
%CHATA EOS=(7 47)
%CHATA EOS=(BEL '/')
%CHATA EOS=(^G '/')
```

**Difference****Examples****Lists**

CDCNET uses lists for the following connection attributes:

```
TRANSPARENT_FORWARD_
CHARACTER
TRANSPARENT_TERMINATE_
CHARACTER
```

CDCNET recognizes strings, decimal codes, hexadecimal codes, mnemonics, and control characters as values in lists.

```
%CHACA TTC=('a' 'b' ^G)
%CHACA TTC=(97 98 BEL)
%CHACA TTC=(61(16) 62(16) 7(16))
```

When you verify the entries by entering a `DISPLAY_TERMINAL_ATTRIBUTE` command, the values are displayed in lowercase only if they are entered in lowercase. (Likewise, values entered in uppercase are displayed in uppercase.) The displays always show the real value for an attribute.

With the `TRMDEF` command, you can enter a list of characters as strings with slashes (/) alone or surrounded by dollar signs (\$).

```
TRMDEF, TTC=A/B/C
TRMDEF, TTC=A/B/C
```

When you enter uppercase characters in these `TRMDEF` formats, the network displays the values in uppercase. If you try to enter lowercase characters, NOS changes the characters to uppercase before sending them to CDCNET.

To use lowercase characters, enter hexadecimal codes.

```
TRMDEF, TTC=X61/X62/X63
```



**Difference**

**Examples**

---

Use of ASCII characters

CDCNET allows you to enter all character values as a decimal code, hexadecimal code, character string, mnemonic, or control character. (See appendix B.)

The TRMDEF command requires you to enter the ASCII codes represented by decimal values 1 through 31 as octal or hexadecimal values.

```
TRMDEF,CLC=30B
```

```
TRMDEF,CLC=X18
```

Unlike CDCNET, the TRMDEF command does not accept a character represented as a mnemonic or control character. For example, CDCNET accepts the following entries, while the TRMDEF command does not.

```
%CHATA CLC=CAN
```

```
%CHATA CLC=`X
```

## Using Terminal Definition Mnemonics with the TRMDEF Command

If you continue to use terminal definition mnemonics with the TRMDEF command, the network converts them into terminal attributes and connection attributes. However, they are not one-to-one correspondences.

### Corresponding Terminal Attributes and Connection Attributes

Table D-1 shows which attributes CDCNET sets when you enter terminal definition mnemonics as TRMDEF parameters. Due to space considerations, the attributes listed are abbreviated.

#### TRANSPARENT Input

TRMDEF commands may contain one or more values for a DL or XL parameter. Table D-1 shows the change(s) CDCNET makes when you enter a TRMDEF command with a specified DL or XL value. If CDCNET does not establish a value for TRANSPARENT\_CHARACTER\_MODE, TRANSPARENT\_LENGTH\_MODE, or TRANSPARENT\_TIMEOUT\_MODE in this conversion process, the network automatically sets that connection attribute to NONE.

For example, suppose you enter the following TRMDEF command with XL set to C1 to specify the transmission length.

```
TRMDEF, XL=C1
```

In response, CDCNET sets two connection attributes for XL=C1.

```
TRANSPARENT_LENGTH_MODE=FORWARD
TRANSPARENT_MESSAGE_LENGTH=1
```

The network also sets the following connection attributes because the TRMDEF command did not specify XL=Xxx and XL=TO.

```
TRANSPARENT_CHARACTER_MODE=NONE
TRANSPARENT_TIMEOUT_MODE=NONE
```

**Table D-1. Changing CDCNET Attributes with a TRMDEF Command**

| <b>Terminal Definition Mnemonics</b> | <b>Corresponding Terminal Attributes and Connection Attributes</b> |
|--------------------------------------|--------------------------------------------------------------------|
| AB                                   | Ignored.                                                           |
| BF=0                                 | PCF=ON                                                             |
| BF=1                                 | PCF=OFF, IBS=100                                                   |
| BF=2                                 | PCF=OFF, IBS=200                                                   |
| BS=character                         | BC=character                                                       |
| B1                                   | Ignored.                                                           |
| B2                                   | Ignored.                                                           |
| CI=integer                           | CRD=integer*linespeed factor                                       |
| CN=character                         | CLC=character                                                      |
| CP=Y                                 | ELP=LFS, EPP=CRS                                                   |
| CP=N                                 | ELP=NONE, EPP=NONE                                                 |
| CT=character                         | NCC=character                                                      |
| DL=Xxx                               | TCM=T, TFC=character, TTC=character,<br>TLM=N, TTM=N               |
| DL=Ccount                            | TLM=T, TML=integer, TCM=N, TTM=N                                   |
| DL=TO                                | TTM=T, TCM=N, TLM=N                                                |
| EB                                   | Ignored.                                                           |
| EL=character                         | ELC=character                                                      |
| EL=EB                                | Ignored.                                                           |
| EL=EL                                | Ignored.                                                           |
| EL=CR                                | ELP=CRS                                                            |
| EL=LF                                | ELP=LFS                                                            |
| EL=CL                                | ELP=CRSLFS                                                         |
| EL=NO                                | ELP=NONE                                                           |
| EP=Y                                 | E=ON                                                               |
| EP=N                                 | E=OFF                                                              |

*(Continued)*

**Table D-1. Changing CDCNET Attributes with a TRMDEF Command** (*Continued*)

| <b>Terminal Definition Mnemonics</b>                          | <b>Corresponding Terminal Attributes and Connection Attributes</b> |
|---------------------------------------------------------------|--------------------------------------------------------------------|
| FA = Y<br>FA = N                                              | EPC = NUL, SBC = ON, SND = ON<br>EPC = LF, SBC = OFF, SND = OFF    |
| IC = Y <sup>1</sup><br>IC = N <sup>1</sup>                    | CFC = ON<br>CFC = OFF                                              |
| IN = BK<br>IN = KB<br>IN = PT<br>IN = X<br>IN = XK<br>IN = XP | Ignored.<br>IEM = N<br>IEM = N<br>IEM = T<br>IEM = T<br>IEM = T    |
| LI = integer<br>LK = Y<br>LK = N                              | LFD = integer*linespeed factor<br>SA = D<br>SA = S                 |
| OC = Y<br>OC = N                                              | CFC = ON<br>CFC = OFF                                              |
| OP = DI<br>OP = PR<br>OP = PT                                 | FL = OFF<br>FL = ON<br>Ignored.                                    |
| PA = E<br>PA = N<br>PA = O<br>PA = Z<br>PA = I                | P = EVEN<br>P = NONE<br>P = ODD<br>P = ZERO<br>P = NONE            |
| PG = Y<br>PG = N                                              | HP = ON<br>HP = OFF                                                |
| PL = integer                                                  | PL = integer                                                       |
| PW = integer                                                  | PW = integer                                                       |

1. If both the IC and OC terminal definition mnemonics are specified, the last setting the network encounters takes precedence.

(*Continued*)

**Table D-1. Changing CDCNET Attributes with a TRMDEF Command** (*Continued*)

| <b>Terminal Definition Mnemonics</b> | <b>Corresponding Terminal Attributes and Connection Attributes</b> |
|--------------------------------------|--------------------------------------------------------------------|
| SE=Y<br>SE=N                         | CLC=NUL, EPC=NUL, SBC=ON<br>CLC=CAN, EPC=LF, SBC=OFF               |
| XL=Xxx                               | TCM=FT, TFC=character, TTC=character,<br>TLM=N, TTM=N              |
| XL=C1<br>XL=Ccount                   | TLM=F, TML=1, TTM=N, TCM=N<br>TLM=FE, TML=integer, TTM=N,<br>TCM=N |
| XL=TO                                | TTM=T, TLM=N, TCM=N                                                |

**Effects of Changing NOS Terminal Classes**

On NOS, there are three ways to change terminal class:

- TRMDEF command with the TC terminal definition command
- 0016 control byte via a program
- CTRL/CHAR/R supervisory message to NAM via an application (such as IAF or PSU)

Whenever your NOS terminal class is changed by any of these methods, CDCNET automatically changes certain attributes. (CDCNET does not support auto input, the marking of output so that it is returned to the service with input.)

CDCNET sets the following terminal attributes and connection attributes for *all* terminal class changes.

| <u>Type of Attribute</u> | <u>Attribute Settings</u>                                                                                                                                                                                                                                                                                   |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Terminal                 | CANCEL_LINE_CHARACTER=CAN<br>CHARACTER_FLOW_CONTROL=ON<br>END_LINE_CHARACTER=CR<br>END_LINE_POSITIONING=LFS<br>END_PARTIAL_CHARACTER=LF<br>END_PARTIAL_POSITIONING=CRS<br>HOLD_PAGE=OFF<br>NETWORK_COMMAND_CHARACTER=%<br>PARITY=EVEN<br>STATUS_ACTION=SEND                                                 |
| Connection               | BREAK_KEY_ACTION=0<br>PARTIAL_CHARACTER_FORWARDING=OFF<br>STORE_BACKSPACE_CHARACTER=OFF<br>STORE_NULS_DELS=OFF<br>TRANSPARENT_CHARACTER_<br>MODE=TERMINATE<br>TRANSPARENT_FORWARD_CHARACTER=CR<br>TRANSPARENT_LENGTH_<br>MODE=TERMINATE<br>TRANSPARENT_MESSAGE_LENGTH=2043<br>TRANSPARENT_TIMEOUT_MODE=NONE |

In addition to these global effects, CDCNET changes some terminal-attributes settings based on the specified terminal class. Table D-2 shows these settings for the classes that the network supports. (The network does not support terminal class 4.)

**Table D-2. Selected Terminal Attribute Settings for NOS Terminal Classes 1, 2, 3, 5, 6, 7, and 8**

|                  | 1        | 2          | 3   | 5        | 6   | 7              | 8         |
|------------------|----------|------------|-----|----------|-----|----------------|-----------|
| BC               | BS       | BS         | BS  | none     | BS  | BS             | BS        |
| CRD <sup>1</sup> | 2        | 0          | 0   | 1        | 0   | 0              | 0         |
| CRS              | CR       | CR         | CR  | ESC<br>G | CR  | CR             | CR        |
| E                | OFF      | OFF        | OFF | OFF      | OFF | ON             | OFF       |
| FFD              | 2        | 2          | 2   | 2        | 2   | 2              | 999ms     |
| FFS              | 6<br>LFs | EM/<br>CAN | FF  | ESC<br>R | FS  | ESC[H<br>ESC[J | ESC<br>FF |
| FL               | ON       | OFF        | OFF | OFF      | OFF | ON             | OFF       |
| LFD <sup>1</sup> | 1        | 0          | 0   | 3        | 3   | 0              | 0         |
| LFS              | LF       | LF         | LF  | ESC<br>B | 0   | LF             | LF        |
| PL               | 0        | 24         | 30  | 24       | 27  | 24             | 35        |
| PW               | 72       | 80         | 80  | 80       | 74  | 80             | 74        |

1. Millisecond (ms) value is dependent on line speed.

The remaining terminal attributes and connection attributes are *not* affected by terminal class changes.

| Type of Attribute | Attributes                                                                                                                            |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| Terminal          | ATTENTION_CHARACTER<br>BEGIN_LINE_CHARACTER<br>CODE_SET<br>END_OUTPUT_SEQUENCE<br>END_PAGE_ACTION<br>HOLD_PAGE_OVER<br>TERMINAL_MODEL |
| Connection        | ATTENTION_CHARACTER_ACTION<br>INPUT_BLOCK_SIZE<br>INPUT_EDITING_MODE<br>INPUT_OUTPUT_MODE<br>TRANSPARENT_TERMINATE_CHARACTER          |

## CDCNET Mapping of Field Number/Field Value Pairs

When you use one of the following, CDCNET converts the terminal characteristics that you specify as field number/field value pairs to attribute settings.

- IAF 0016 control byte in a NOS program
- CTRL/CHAR/R supervisory message that an application sends to NAM

### Corresponding Terminal Attributes and Connection Attributes

Table D-3 shows the terminal attributes and connection attributes that the network uses when you specify field number/field value pairs in the following.

- 0016 control byte
- CTRL/CHAR/R supervisory message

Because of space considerations, the attribute settings and field names are abbreviated.



### TRANSPARENT Input

Converting field number/field value pairs to CDCNET attributes for TRANSPARENT input is quite complex. You should send the following field number/field value pairs (decimal) together to ensure proper results.

56, 57, 58, 59, 60, 69, 70, and 146

CDCNET converts these field number/field value pairs into the TRANSPARENT\_CHARACTER\_MODE, TRANSPARENT\_LENGTH\_MODE, and TRANSPARENT\_TIMEOUT\_MODE settings, as shown in figures D-1 through D-5.

**Table D-3. Mapping of FN/FV Pairs to CDCNET Attributes**

| Decimal Field Number | Octal Field Number | Field Name | Field Value | Corresponding Terminal Attributes and Connection Attributes          |
|----------------------|--------------------|------------|-------------|----------------------------------------------------------------------|
| 25                   | 31                 | BF         | 0           | PCF=ON                                                               |
|                      |                    |            | 1           | PCF=OFF, IBS=100                                                     |
|                      |                    |            | 2           | PCF=OFF, IBS=200                                                     |
| 30                   | 36                 | XBZ1       | all         | Ignored.                                                             |
| 31                   | 37                 | XBZ2       | all         | Ignored.                                                             |
| 32                   | 40                 | LK         | 0           | SA=S                                                                 |
|                      |                    |            | 1           | SA=D                                                                 |
| 33                   | 41                 | HD         | all         | Ignored.                                                             |
| 34                   | 42                 | TC         | all         | See the preceding section, Effects of Changing NOS Terminal Classes. |
| 35                   | 43                 | PW         | integer     | PW=integer                                                           |
| 36                   | 44                 | PL         | integer     | PL=integer                                                           |
| 37                   | 45                 | PG         | 0           | HP=OFF                                                               |
|                      |                    |            | 1           | HP=ON                                                                |

*(Continued)*

**Table D-3. Mapping of FN/FV Pairs to CDCNET Attributes**  
(Continued)

| Decimal Field Number | Octal Field Number | Field Name | Field Value           | Corresponding Terminal Attributes and Connection Attributes |
|----------------------|--------------------|------------|-----------------------|-------------------------------------------------------------|
| 38                   | 46                 | CN         | character             | CLC = character                                             |
| 39                   | 47                 | BS         | character             | BC = character                                              |
| 40                   | 50                 | CT         | character             | NCC = character                                             |
| 41                   | 51                 | AB         | all                   | Ignored.                                                    |
| 42                   | 52                 | B1         | all                   | Ignored.                                                    |
| 43                   | 53                 | B2         | all                   | Ignored.                                                    |
| 44                   | 54                 | CI         | integer               | CRD = integer*<br>linespeed factor                          |
| 45                   | 55                 | LI         | integer               | LFD = integer*<br>linespeed factor                          |
| 46                   | 56                 | CA         | 1                     | Ignored.                                                    |
| 47                   | 57                 | LA         | 1                     | Ignored.                                                    |
| 49                   | 61                 | EP         | 0<br>1                | E = OFF<br>E = ON                                           |
| 50                   | 62                 | PA         | 0<br>1<br>2<br>3<br>4 | P = ZERO<br>P = ODD<br>P = EVEN<br>P = NONE<br>P = NONE     |
| 51                   | 63                 | BR         | 0<br>1                | BKA = 0<br>BKA = 1                                          |
| 52                   | 64                 | XPT        | 0<br>1                | IEM = N<br>IEM = T                                          |
| 53                   | 65                 | IN         | all                   | Ignored.                                                    |

(Continued)

**Table D-3. Mapping of FN/FV Pairs to CDCNET Attributes**  
(Continued)

| Decimal Field Number | Octal Field Number | Field Name | Field Value | Corresponding Terminal Attributes and Connection Attributes |
|----------------------|--------------------|------------|-------------|-------------------------------------------------------------|
| 54                   | 66                 | OP         | 0           | FL=ON                                                       |
|                      |                    |            | 1           | FL=OFF                                                      |
|                      |                    |            | 2           | Ignored.                                                    |
| 55                   | 67                 | FA         | 0           | EPC=LF, SBC=OFF,<br>ND=OFF                                  |
|                      |                    |            | 1           | EPC=NUL,<br>SBC=ON,<br>SND=ON                               |
| 56                   | 70                 | DL/XL      | 0           | See figure D-1.                                             |
|                      |                    |            | 1           |                                                             |
| 57                   | 71                 | UBTCC      | all         | See figure D-4.                                             |
| 58                   | 72                 | LBTCC      | all         | See figure D-4.                                             |
| 59                   | 73                 | TDC        | all         | See figure D-2.                                             |
| 60                   | 74                 | TTM        | 0           | See figure D-5.                                             |
|                      |                    |            | 1           |                                                             |
| 61                   | 75                 | EL         | character   | ELC=character                                               |
| 62                   | 76                 | ELO        | all         | Ignored.                                                    |
| 63                   | 77                 | CPEL       | 0           | ELP=NONE                                                    |
|                      |                    |            | 1           | ELP=CRS                                                     |
|                      |                    |            | 2           | ELP=LFS                                                     |
|                      |                    |            | 3           | ELP=CRSLFS                                                  |
| 64                   | 100                | EB         | all         | Ignored.                                                    |
| 65                   | 101                | EBO        | all         | Ignored.                                                    |
| 66                   | 102                | CPEB       | all         | Ignored.                                                    |


(Continued)

**Table D-3. Mapping of FN/FV Pairs to CDCNET Attributes**  
(Continued)


| Decimal Field Number | Octal Field Number | Field Name      | Field Value | Corresponding Terminal Attributes and Connection Attributes |
|----------------------|--------------------|-----------------|-------------|-------------------------------------------------------------|
| 67                   | 103                | IC <sup>1</sup> | 0           | CFC=OFF                                                     |
|                      |                    |                 | 1           | CFC=ON                                                      |
| 68                   | 104                | OC <sup>1</sup> | 0           | CFC=OFF                                                     |
|                      |                    |                 | 1           | CFC=ON                                                      |
| 69                   | 105                | MTIC            | all         | See figure D-3.                                             |
| 70                   | 106                | TMM             | 1           | See figures D-1, D-4, and D-5.                              |
| 71                   | 107                | CP              | 0           | ELP=NONE,<br>EPP=NONE                                       |
|                      |                    |                 | 1           | ELP=LFS,<br>EPP=CRS                                         |
| 87                   | 127                | FDLX            | 0           | IOM=S <sup>2</sup>                                          |
|                      |                    |                 | 1           | IOM=F                                                       |
| 102                  | 146                | PP              | character   | EOS=character                                               |
| 112                  | 160                | NTA             | 0           | IOM=U                                                       |
|                      |                    |                 | 1           | IOM=S <sup>2</sup>                                          |
| 146                  | 222                | STTO            | 0           | See figure D-5.                                             |
|                      |                    |                 | 1           |                                                             |
| 147                  | 223                | CRI             | integer     | CRD=integer*4                                               |
| 148                  | 224                | LFI             | integer     | LFD=integer*4                                               |

1. If both the IC and OC field names are specified, the last field value the network encounters takes precedence.


2. Solicited INPUT\_OUTPUT\_MODE differs between CDCNET and CCP. CCP rejects input from the user if the service is not ready to accept input. CDCNET accepts input, but does not edit it until the service requests input.



**Figure D-1. Corresponding TRANSPARENT\_CHARACTER\_MODE Settings**



**Figure D-2. Corresponding TRANSPARENT\_FORWARD\_CHARACTER Settings**



**Figure D-3. Corresponding TRANSPARENT\_TERMINATE\_CHARACTER Settings**

```

If Upper Byte Transparent Character Count (57) is specified and not 0
or Lower Byte Transparent Character Count (58) is specified and not 0
 Then set TRANSPARENT_MESSAGE_LENGTH=(value of 57 * 256) +
 (value of 58)
 If Transparent Message Mode (70) is specified as Multimessage (1)
 If TRANSPARENT_MESSAGE_LENGTH=1
 Then set TRANSPARENT_LENGTH_MODE=FORWARD*
 If not, set TRANSPARENT_LENGTH_MODE=FORWARD_EXACT
 If not, set TRANSPARENT_LENGTH_MODE=TERMINATE
 If not, set TRANSPARENT_LENGTH_MODE=NONE
* CCP forwards the exact length specified for all lengths including 1.

```

**Figure D-4. Corresponding TRANSPARENT\_LENGTH\_MODE Settings**

```

If Transparent Timeout (60) is specified (1)
 Then set TRANSPARENT_TIMEOUT_MODE=TERMINATE
 If Transparent Message Mode (70) is specified as Multimessage (1)
 and "Sticky" Transparent Timeout (146) is specified (1)
 Then set TRANSPARENT_TIMEOUT_MODE=FORWARD
 If not, stop
 If not, set TRANSPARENT_TIMEOUT_MODE=NONE

```

**Figure D-5. Corresponding TRANSPARENT\_TIMEOUT\_MODE Settings**



# Terminal Attribute Settings via **TERMINAL\_MODEL** **E**

---

|                                                          |     |
|----------------------------------------------------------|-----|
| DO Command (CDCNET Procedure Call) .....                 | E-2 |
| CHANGE_TERMINAL_ATTRIBUTE (CDCNET) Command .....         | E-5 |
| NOS/VE Commands .....                                    | E-7 |
| NOS Commands .....                                       | E-8 |
| Terminal Attribute Settings for Selected Terminals ..... | E-8 |





# Terminal Attribute Settings via TERMINAL\_MODEL

---

E

If you are a NOS/VE or NOS user, there are several ways to change your terminal attribute settings. This appendix discusses how using each of the following commands affects these settings.

- DO command (CDCNET procedure call)
- CHANGE\_TERMINAL\_ATTRIBUTE (CDCNET) command
- NOS/VE commands
- NOS commands

The appendix also lists terminal attribute settings for selected terminals.

This information is based on the assumption that you are accessing a NOS/VE or NOS service through CDCNET. That is, you are processing on one of the following:

- NOS/VE on a CYBER 180 mainframe. (You are using NAM/VE and CDCNET.)
- NOS on a CYBER 170 mainframe or a CYBER 180 mainframe that runs NOS-only or NOS and NOS/VE in dual state. (You are using NAM and CDCNET.)

## DO Command (CDCNET Procedure Call)

Both NOS/VE and NOS users can change their attributes with a CDCNET command. If you know your `TERMINAL_MODEL`, you can enter a DO command to change your terminal attributes. This command calls a terminal user procedure that contains the attribute settings for the specified terminal.

First, select the name from table E-1 that best suits your terminal. Next, issue a DO command using this name as the procedure name.

**Table E-1. Procedure Names**

| Name           | Class <sup>1</sup> | Your Terminal                                                                          |
|----------------|--------------------|----------------------------------------------------------------------------------------|
| CDC_721        | 3                  | CDC 721                                                                                |
| CDC_722        | 2                  | CDC 722                                                                                |
| CDC_722_30     | 2                  | CDC 722-30 running in ANSI mode                                                        |
| MAC_CONNECT_10 | 7                  | Macintosh computer using Control Data CONNECT version 1.0                              |
| MAC_CONNECT_11 | 7                  | Macintosh computer using Control Data CONNECT version 1.1                              |
| PC_CONNECT_10  | 7                  | IBM Personal Computer (or supported compatible) using Control Data CONNECT version 1.0 |
| PC_CONNECT_11  | 7                  | IBM Personal Computer (or supported compatible) using Control Data CONNECT version 1.1 |
| PC_CONNECT_12  | 7                  | IBM Personal Computer (or supported compatible) using Control Data CONNECT version 1.2 |

1. This column provides the NOS terminal class associated with each terminal.

*(Continued)*

Table E-1. Procedure Names (Continued)

| Name          | Class <sup>1</sup> | Your Terminal                                                                          |
|---------------|--------------------|----------------------------------------------------------------------------------------|
| PC_CONNECT_13 | 7                  | IBM Personal Computer (or supported compatible) using Control Data CONNECT version 1.3 |
| PC_CONNECT_14 | 7                  | IBM personal Computer (or supported compatible) using Control Data CONNECT version 1.4 |
| IBM_3270      | -                  | IBM 3270                                                                               |
| TV_955        | -                  | Televideo 955                                                                          |
| DEC_VT100     | 7                  | DEC VT100                                                                              |
| DEC_VT220     | 7                  | DEC VT220                                                                              |
| ZEN_Z19       | (None)             | Zenith Z19                                                                             |
| ZEN_Z29       | (None)             | Zenith Z29                                                                             |

1. This column provides the NOS terminal class associated with each terminal.

When the network executes a DO command, it performs three actions:

- Changes your terminal attributes to the appropriate ones for the terminal you have selected. (See tables E-3 through E-7.)
- Changes the value of `TERMINAL_MODEL` and the other attributes in the `DISPLAY_TERMINAL_ATTRIBUTES` display.
- Sends appropriate information to the services on your connections. For a NOS/VE service, the `TERMINAL_MODEL` setting is sent. For a NOS service, the `TERMINAL_MODEL` setting is mapped into a terminal class, and the class is sent. What a service does with the information is service-dependent, but it should be able to handle this unsolicited message.

NOS/VE uses this information to specify the correct terminal model for its `EDIT_FILE` utility. NOS does not use the information, but requires you to enter a `SCREEN (NOS)` command in addition to specifying a terminal model for its Full Screen Editor (FSE).

DO Command (CDCNET Procedure Call)

For example, the following DO command executes the DEC\_VT100 procedure, changes your terminal attributes to the DEC\_VT100 settings, and sends appropriate information to the services on your connections:

```
%DO DEC_VT100
```

Subsequently, when you issue a DISPLAY\_TERMINAL\_ATTRIBUTES command, it displays the same settings as shown in table E-6 for DEC\_VT100.

## CHANGE\_TERMINAL\_ATTRIBUTE (CDCNET) Command

The CHANGE\_TERMINAL\_ATTRIBUTE (CDCNET) command also enables you to change TERMINAL\_MODEL regardless of whether you are working on NOS/VE or NOS.

If you are using the Asynchronous protocol, select a suitable name from table E-1 as the value of TERMINAL\_MODEL. When you use a CHANGE\_TERMINAL\_ATTRIBUTE command to change TERMINAL\_MODEL, the network performs the following actions.

- Changes the value of TERMINAL\_MODEL in the DISPLAY\_TERMINAL\_ATTRIBUTES display.
- Does *not* change your terminal attributes (except for TERMINAL\_MODEL) to those listed in tables E-3 through E-7.
- Sends appropriate information to the services on your connections. For a NOS/VE service, the TERMINAL\_MODEL setting is sent. For a NOS service, the TERMINAL\_MODEL setting is mapped into a terminal class, and the class is sent. What a service does with the information is service-dependent, but it should be able to handle this unsolicited message.

NOS/VE uses this information to specify the correct terminal model for its EDIT\_FILE utility. NOS does not use the information, but requires you to enter a SCREEN command to specify a terminal model for its Full Screen Editor (FSE).

For example, the following CHANGE\_TERMINAL\_ATTRIBUTE command changes the value of TERMINAL\_NAME in the DISPLAY\_TERMINAL\_ATTRIBUTES display.

```
%CHATA TM=DEC_VT100
```

As a NOS user, this change does not affect other terminal attribute settings. As a NOS/VE user, it allows the EDIT\_FILE utility to operate correctly with your terminal in screen mode, but it does not affect the terminal characteristics CDCNET uses.

If you are accessing a NOS service and using the HASP, Mode 4, or Binary Synchronous Communications protocol, you can change the TERMINAL\_MODEL display with the CHANGE\_TERMINAL\_ATTRIBUTE command. Select an appropriate name for the TERMINAL\_MODEL name from table E-2 and enter the command.

**Table E-2. NOS TERMINAL\_MODEL Names**

| <b>Name</b>   | <b>Class<sup>1</sup></b> | <b>Your Terminal</b>                                                                                           |
|---------------|--------------------------|----------------------------------------------------------------------------------------------------------------|
| IBM_HASP_POST | 9                        | Terminal using the HASP protocol with printer devices supporting only postprint carriage control.              |
| IBM_HASP_PRE  | 14                       | Terminal using the HASP protocol with printer devices supporting both postprint and preprint carriage control. |
| MODE4         | 15                       | Terminal using Mode 4A or 4C protocol.                                                                         |
| IBM_3270      | 18                       | Terminal using the 3270 Binary Synchronous Communications protocol.                                            |

1. This column provides the NOS terminal class associated with each terminal.

## NOS/VE Commands

If you are a NOS/VE user, other commands are available for changing `TERMINAL_MODEL`. In addition to the two CDCNET commands, `DO` and `CHANGE_TERMINAL_ATTRIBUTE`, you can use the following:

|                                             |                                                                                                                                      |
|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| <code>CHANGE_TERMINAL_ATTRIBUTE</code>      | SCL commands for NOS/VE users (See NOS/VE System Usage for descriptions of SCL commands that change and retrieve CDCNET attributes.) |
| <code>SET_TERMINAL_ATTRIBUTE</code>         |                                                                                                                                      |
| <code>IFP\$CHANGE_TERMINAL_ATTRIBUTE</code> | CYBIL procedure call (See CYBIL File Management Usage for descriptions of procedure calls.)                                          |

If you set `TERMINAL_MODEL` with either SCL command, NOS/VE uses the name for its `EDIT_FILE` utility, and sends the new `TERMINAL_MODEL` setting to CDCNET. Hence, the display produced by the `DISPLAY_TERMINAL_ATTRIBUTES` command reflects the change.

For example, the following SCL commands change the name used by the `EDIT_FILE` utility and the `TERMINAL_MODEL` setting displayed by CDCNET.

```
CHATA TM=DEC_VT100
SETTA TM=DEC_VT100
```



## NOS Commands

On NOS, you can change `TERMINAL_MODEL` two additional ways. (See appendix D for more details.)

- Enter a `TRMDEF` command. Specify an appropriate name from table E-1 as the value of `TERMINAL_MODEL`. (See NOS Version 2 Reference Set, Volume 3, System Commands, for descriptions of this command and the mnemonics.)

```
TRMDEF, TM=DEC_VT100
```

- Use a 0016 control byte at the program level. (See NOS Version 2 Reference Set, Volume 4, Program Interface, for more information.)

## Terminal Attribute Settings for Selected Terminals

Tables E-3 through E-7 list terminal attribute settings for the terminals named in table E-1. Use the `CDCNET DO` command, described in chapter 2, to set your terminal attributes to the values listed in these tables.

**Table E-3. Selected Terminal Attribute Settings: CDC Terminals**

| Terminal Attribute        | CDC 721 | CDC 722 | CDC 722_30         |
|---------------------------|---------|---------|--------------------|
| Attention_Character       | NUL     | NUL     | NUL                |
| Backspace_Character       | BS      | BS      | BS                 |
| Begin_Line_Character      | NUL     | NUL     | NUL                |
| Cancel_Line_Character     | CAN     | CAN     | CAN                |
| Carriage_Return_Delay     | 0       | 0       | 0                  |
| Carriage_Return_Sequence  | CR      | CR      | CR                 |
| Character_Flow_Control    | ON      | ON      | ON                 |
| Code_Set                  | ASCII   | ASCII   | ASCII              |
| Echoplex                  | OFF     | OFF     | OFF                |
| End_Line_Character        | CR      | CR      | CR                 |
| End_Line_Positioning      | LFS     | LFS     | LFS                |
| End_Output_Sequence       |         |         |                    |
| End_Page_Action           | NONE    | NONE    | NONE               |
| End_Partial_Character     | LF      | LF      | LF                 |
| End_Partial_Positioning   | CRS     | CRS     | CRS                |
| Fold_Line                 | OFF     | OFF     | OFF                |
| Form_Feed_Delay           | 0       | 0       | 0                  |
| Form_Feed_Sequence        | FF      | EM CAN  | ESC [ H<br>ESC [ J |
| Hold_Page                 | OFF     | OFF     | OFF                |
| Hold_Page_Over            | ON      | OFF     | ON                 |
| Line_Feed_Delay           | 0       | 0       | 0                  |
| Line_Feed_Sequence        | LF      | LF      | LF                 |
| Network_Command_Character | %       | %       | %                  |
| Page_Length               | 30      | 24      | 24                 |
| Page_Width                | 80      | 80      | 80                 |
| Parity                    | EVEN    | EVEN    | EVEN               |
| Response_Action           | SEND    | SEND    | SEND               |
| Status_Action             | SEND    | SEND    | SEND               |
| Terminal_Model            | CDC_721 | CDC_722 | CDC_722_30         |

**Table E-4. Selected Terminal Attribute Settings: IBM Computers**

| <b>Terminal Attribute</b> | <b>IBM<br/>Personal<br/>Computer</b> |
|---------------------------|--------------------------------------|
| Attention_Character       | NUL                                  |
| Backspace_Character       | BS                                   |
| Begin_Line_Character      | NUL                                  |
| Cancel_Line_Character     | CAN                                  |
| Carriage_Return_Delay     | 0                                    |
| Carriage_Return_Sequence  | CR                                   |
| Character_Flow_Control    | ON                                   |
| Code_Set                  | ASCII                                |
| Echoplex                  | OFF                                  |
| End_Line_Character        | CR                                   |
| End_Line_Positioning      | LFS                                  |
| End_Output_Sequence       |                                      |
| End_Page_Action           | NONE                                 |
| End_Partial_Character     | LF                                   |
| End_Partial_Positioning   | CRS                                  |
| Fold_Line                 | ON                                   |
| Form_Feed_Delay           | 0                                    |
| Form_Feed_Sequence        | ESC [ H<br>ESC [ J                   |
| Hold_Page                 | OFF                                  |
| Hold_Page_Over            | ON                                   |
| Line_Feed_Delay           | 0                                    |
| Line_Feed_Sequence        | LF                                   |
| Network_Command_Character | %                                    |
| Page_Length               | 24                                   |
| Page_Width                | 80                                   |
| Parity                    | EVEN                                 |
| Response_Action           | SEND                                 |
| Status_Action             | SEND                                 |
| Terminal_Model            | PC_CONNECT_XX <sup>1</sup>           |

1. With Control Data CONNECT version 1.0, set to 10; version 1.1, set to 11; version 1.2, set to 12; version 1.3, set to 13; version 1.4, set to 14.

**Table E-5. Selected Terminal Attribute Settings: Macintosh**

| <b>Terminal Attribute</b> | <b>Macintosh Computer</b>   |
|---------------------------|-----------------------------|
| Attention_Character       | NUL                         |
| Backspace_Character       | BS                          |
| Begin_Line_Character      | NUL                         |
| Cancel_Line_Character     | CAN                         |
| Carriage_Return_Delay     | 0                           |
| Carriage_Return_Sequence  | CR                          |
| Character_Flow_Control    | ON                          |
| Code_Set                  | ASCII                       |
| Echoplex                  | OFF                         |
| End_Line_Character        | CR                          |
| End_Line_Positioning      | LFS                         |
| End_Output_Sequence       |                             |
| End_Page_Action           | NONE                        |
| End_Partial_Character     | LF                          |
| End_Partial_Positioning   | CRS                         |
| Fold_Line                 | OFF                         |
| Form_Feed_Delay           | 0                           |
| Form_Feed_Sequence        | ESC [ H<br>ESC [ J          |
| Hold_Page                 | OFF                         |
| Hold_Page_Over            | ON                          |
| Line_Feed_Delay           | 0                           |
| Line_Feed_Sequence        | LF                          |
| Network_Command_Character | %                           |
| Page_Length               | 24                          |
| Page_Width                | 80                          |
| Parity                    | EVEN                        |
| Response_Action           | SEND                        |
| Status_Action             | SEND                        |
| Terminal_Model            | MAC_CONNECT_xx <sup>1</sup> |

1. With Control Data CONNECT version 1.0, set to 10; version 1.1, set to 11; version 2.0, set to 20; version 2.1, set to 21.

**Table E-6. Selected Terminal Attribute Settings: DEC Terminals**

| <b>Terminal Attribute</b> | <b>DEC VT100/VT220</b>            |
|---------------------------|-----------------------------------|
| Attention_Character       | NUL                               |
| Backspace_Character       | BS                                |
| Begin_Line_Character      | NUL                               |
| Cancel_Line_Character     | CAN                               |
| Carriage_Return_Delay     | 0                                 |
| Carriage_Return_Sequence  | CR                                |
| Character_Flow_Control    | ON                                |
| Code_Set                  | ASCII                             |
| Echoplex                  | ON                                |
| End_Line_Character        | CR                                |
| End_Line_Positioning      | LFS                               |
| End_Output_Sequence       |                                   |
| End_Page_Action           | NONE                              |
| End_Partial_Character     | LF                                |
| End_Partial_Positioning   | CRS                               |
| Fold_Line                 | ON                                |
| Form_Feed_Delay           | 0                                 |
| Form_Feed_Sequence        | ESC [ H                           |
| Function_Key_Class        | DEC_VTxxx <sup>1</sup><br>ESC [ J |
| Hold_Page                 | OFF                               |
| Hold_Page_Over            | OFF                               |
| Line_Feed_Delay           | 0                                 |
| Line_Feed_Sequence        | LF                                |
| Network_Command_Character | %                                 |
| Page_Length               | 24                                |
| Page_Width                | 80                                |
| Parity                    | EVEN                              |
| Response_Action           | SEND                              |
| Status_Action             | SEND                              |
| Terminal_Model            | DEC_VTxxx <sup>2</sup>            |

1. Attribute value for DEC VT100 is DEC\_VT100. Attribute value for DEC VT220 is DEC\_VT220.

2. Attribute value for DEC VT100 is DEC\_VT100. Attribute value for DEC VT220 is DEC\_VT110.

**Table E-7. Selected Terminal Attribute Settings: Zenith Computers**

| <b>Terminal Attribute</b> | <b>Zenith Z19/Z29</b> |
|---------------------------|-----------------------|
| Attention_Character       | NUL                   |
| Backspace_Character       | BS                    |
| Begin_Line_Character      | NUL                   |
| Cancel_Line_Character     | CAN                   |
| Carriage_Return_Delay     | 0                     |
| Carriage_Return_Sequence  | CR                    |
| Character_Flow_Control    | ON                    |
| Code_Set                  | ASCII                 |
| Echoplex                  | OFF                   |
| End_Line_Character        | CR                    |
| End_Line_Positioning      | LFS                   |
| End_Output_Sequence       |                       |
| End_Page_Action           | NONE                  |
| End_Partial_Character     | LF                    |
| End_Partial_Positioning   | CRS                   |
| Fold_Line                 | OFF                   |
| Form_Feed_Delay           | 0                     |
| Form_Feed_Sequence        | ESC [ H<br>ESC [ J    |
| Hold_Page                 | OFF                   |
| Hold_Page_Over            | ON                    |
| Line_Feed_Delay           | 0                     |
| Line_Feed_Sequence        | LF                    |
| Network_Command_Character | %                     |
| Page_Length               | 24                    |
| Page_Width                | 80                    |
| Parity                    | EVEN                  |
| Response_Action           | SEND                  |
| Status_Action             | SEND                  |
| Terminal_Model            | ZEN_Zxx <sup>1</sup>  |

1. Attribute value for Zenith Z19 is ZEN\_Z19. Attribute value for Zenith Z29 is ZEN\_Z29.



# 3270 Binary Synchronous Communications Protocol

F

---

|                                    |      |
|------------------------------------|------|
| Your Display Station .....         | F-2  |
| Capabilities .....                 | F-3  |
| Features Not Supported .....       | F-3  |
| Attribute Support .....            | F-4  |
| Terminal Attributes .....          | F-4  |
| Data Link Control Characters ..... | F-8  |
| Using END_PAGE_ACTION .....        | F-9  |
| Transparent Mode .....             | F-9  |
| Connection Attributes .....        | F-10 |
| Migrating from CCP .....           | F-12 |





# 3270 Binary Synchronous Communications Protocol

F

The 3270 Binary Synchronous Communications protocol users can access NOS/VE and NOS services from an IBM 3270 Information Display System, connected via multipoint Binary Synchronous Communications (BSC) lines, with the BSC3270TIP terminal interface program (TIP).


In general, this TIP follows the same conventions as those TIPs for other CDCNET-supported protocols. All commands, attributes, or other features supported by the 3270 Binary Synchronous protocol with similar requirements as those of the Asynchronous protocol are documented elsewhere in this manual.

This appendix supplements rather than replaces the other documentation. The following sections contain differences and unique capabilities that you may encounter while using your 3270 display station (terminal).

| <b>Section</b>       | <b>Description</b>                                                                            |
|----------------------|-----------------------------------------------------------------------------------------------|
| Your display station | Discusses your display station's place in the network and general screen capabilities.        |
| Attribute support    | Describes the subset of CDCNET terminal and connection attributes that the protocol supports. |
| Migrating from CCP   | Highlights differences between CCP and CDCNET support.                                        |

## Your Display Station

Your site administrator can configure a display station in two different ways depending upon the site's hardware and software requirements. Some display stations (and 3270 printers) connect directly to the network; others go through an IBM passthrough service before connecting to the network.



## Capabilities

Since the network supports Nontransparent IBM Multipoint Bisynchronous Communications, you can use the CDCNET capabilities described in the rest of the manual when working at a 3270 display station connected to CDCNET. However, the screen display on your 3270 display station differs from that of other terminals. Unless you are using a full-screen application like Full Screen Editor (FSE), the network treats the display station like a "line-at-a-time" terminal.

- The first character of each line is reserved for the field attribute character. Therefore, the number of characters allowed on a line is usually one character less than the PAGE\_WIDTH setting (that is, 79 out of 80 characters).
- When you enter input, it always appears after the last output line on the display. For example, if you enter the ASCII command (ascii), NOS responds with the command name (ASCII) and a prompt (/). Then you begin typing on the following line.

```

ascii
ASCII
/
(At this point, you enter input.)

```

## Features Not Supported

Since CDCNET does not support Transparent IBM Multipoint Bisynchronous Communications, certain features normally available on 3270 display stations cannot be used. Unavailable features include color, extended highlighting, field validation, character attributes, extended character sets, and partitions. If your service attempts to use any of these features, it usually disconnects your display station. If this happens, call the site administrator and report the difficulty.

## Attribute Support

You can change and display certain terminal and connection attributes from your 3270 display station.

### Terminal Attributes

The 3270 Binary Synchronous Communications protocol supports a subset of the available terminal attributes. The BSC3270TIP supports this attribute subset. The default settings for these supported attributes are displayed in figure F-1.

|                           |           |
|---------------------------|-----------|
| Cancel_Line_Character     | :NUL      |
| Code_Set                  | :EBCDIC   |
| End_Page_Action           | :NONE     |
| Hold_Page                 | :OFF      |
| Hold_Page_Over            | :OFF      |
| Network_Command_Character | :%        |
| Page_Length               | :24       |
| Page_Width                | :80       |
| Response_Action           | :SEND     |
| Status_Action             | :SEND     |
| Terminal_Model            | :IBM_3270 |

**Figure F-1. 3270 Binary Synchronous Communications Protocol Terminal Attribute Defaults**

Table F-1 compares the way 3270 uses certain terminal attributes with their quick-reference descriptions in chapter 3.

**Table F-1. Terminal Attribute Differences**

| <b>Terminal Attribute<br/>(Abbreviation)</b> | <b>Default<br/>Setting</b> | <b>Comparison</b>                                                                                                                                                                                        |
|----------------------------------------------|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CANCEL_LINE_<br>CHARACTER (CLC)              | NUL                        | Same description applies in both cases. This attribute provides another way to erase, in addition to the following keys typically used at a 3270 display station.<br><br>DEL<br>ERASE EOF<br>ERASE INPUT |
| CODE_SET (CS)                                | EBCDIC                     | CDCNET translates between ASCII and the code set used by 3270 equipment by default, which is EBCDIC. Site-defined code sets are also allowed.                                                            |
| END_PAGE_ACTION<br>(EPA)                     | NONE                       | Same description applies in both cases.                                                                                                                                                                  |
| HOLD_PAGE (HP)                               | OFF                        | Same description applies in both cases.                                                                                                                                                                  |
| HOLD_PAGE_OVER<br>(HPO)                      | OFF                        | Same description applies in both cases.                                                                                                                                                                  |

*(Continued)*

**Table F-1. Terminal Attribute Differences (Continued)**

| Terminal Attribute<br>(Abbreviation)    | Default<br>Setting       | Comparison                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                      |                          |    |    |    |    |    |     |    |    |    |    |
|-----------------------------------------|--------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|--------------------------|----|----|----|----|----|-----|----|----|----|----|
| NETWORK_<br>COMMAND_<br>CHARACTER (NCC) | %                        | <p>Use any character in table B-6, except for data link control characters in table F-2.</p> <p>If you enter a NCC, press ENTER to go from the bottom of the page to the top when HOLD_PAGE is set to ON.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                      |                          |    |    |    |    |    |     |    |    |    |    |
| PAGE_LENGTH (PL)                        | 24                       | <p>You can use 12 through 43 lines. This is a subset of the values (0, 2 through 255) that the network provides.<sup>1</sup> The value 0, used in other protocols to suppress page division, is not valid for the 3270 protocol.</p> <p>To avoid display problems, specify your PAGE_LENGTH setting as the actual length of your screen. The following chart lists typical length and width combinations for screens on 3270 display stations.</p> <table border="1" data-bbox="592 1067 1009 1307"> <thead> <tr> <th data-bbox="592 1067 726 1130">Length<br/>(in Lines)</th> <th data-bbox="796 1067 957 1130">Width (in<br/>Characters)</th> </tr> </thead> <tbody> <tr> <td data-bbox="592 1154 621 1178">24</td> <td data-bbox="796 1154 830 1178">40</td> </tr> <tr> <td data-bbox="592 1185 621 1209">24</td> <td data-bbox="796 1185 830 1209">80</td> </tr> <tr> <td data-bbox="592 1216 621 1241">27</td> <td data-bbox="796 1216 844 1241">132</td> </tr> <tr> <td data-bbox="592 1248 621 1272">32</td> <td data-bbox="796 1248 830 1272">80</td> </tr> <tr> <td data-bbox="592 1279 621 1303">43</td> <td data-bbox="796 1279 830 1303">80</td> </tr> </tbody> </table> | Length<br>(in Lines) | Width (in<br>Characters) | 24 | 40 | 24 | 80 | 27 | 132 | 32 | 80 | 43 | 80 |
| Length<br>(in Lines)                    | Width (in<br>Characters) |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                      |                          |    |    |    |    |    |     |    |    |    |    |
| 24                                      | 40                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                      |                          |    |    |    |    |    |     |    |    |    |    |
| 24                                      | 80                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                      |                          |    |    |    |    |    |     |    |    |    |    |
| 27                                      | 132                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                      |                          |    |    |    |    |    |     |    |    |    |    |
| 32                                      | 80                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                      |                          |    |    |    |    |    |     |    |    |    |    |
| 43                                      | 80                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                      |                          |    |    |    |    |    |     |    |    |    |    |

1. If the page size (PAGE\_LENGTH setting [lines] multiplied by PAGE\_WIDTH [characters]) exceeds 3564, the result is unpredictable.

(Continued)

Table F-1. Terminal Attribute Differences (Continued)

| Terminal Attribute<br>(Abbreviation) | Default<br>Setting | Comparison                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                  |                   |          |           |          |           |
|--------------------------------------|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|-------------------|----------|-----------|----------|-----------|
| PAGE_WIDTH (PW)                      | 80                 | <p>You can use 40 through 132 characters. This is a subset of the values (0, 10 through 255) that the network provides.<sup>1</sup> The value 0, used in other protocols to suppress line division, is not valid for the 3270 protocol.</p> <p>To avoid display problems, use the actual width of your screen as your PAGE_WIDTH setting. If your display station supports the ERASE_WRITE_ALTERNATE command and has an alternate screen width, select the appropriate width. The following are alternate length (in lines) and width (in characters) combinations for screens on 3270 display stations.</p> <table border="1"> <thead> <tr> <th>Standard<br/>Size</th> <th>Alternate<br/>Size</th> </tr> </thead> <tbody> <tr> <td>32 by 80</td> <td>27 by 132</td> </tr> <tr> <td>43 by 80</td> <td>27 by 132</td> </tr> </tbody> </table> | Standard<br>Size | Alternate<br>Size | 32 by 80 | 27 by 132 | 43 by 80 | 27 by 132 |
| Standard<br>Size                     | Alternate<br>Size  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                  |                   |          |           |          |           |
| 32 by 80                             | 27 by 132          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                  |                   |          |           |          |           |
| 43 by 80                             | 27 by 132          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                  |                   |          |           |          |           |
| RESPONSE_ACTION<br>(RA)              | SEND               | Same description applies in both cases.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                  |                   |          |           |          |           |
| STATUS_ACTION<br>(SA)                | SEND               | Same description applies in both cases.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                  |                   |          |           |          |           |
| TERMINAL_MODEL<br>(TM)               | IBM_3270           | Same description applies in both cases.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                  |                   |          |           |          |           |

1. If the page size (PAGE\_LENGTH setting [lines] multiplied by PAGE\_WIDTH [characters]) exceeds 3564, the result is unpredictable.



### Data Link Control Characters


The data link control characters, listed in table F-2, control communications with your display station. Since they are reserved for this purpose, they may not appear in output from the service or in terminal attribute settings.

**Table F-2. Data Link Control Characters**

| <b>Graphic/Mnemonic</b> | <b>Name or Meaning</b> |
|-------------------------|------------------------|
| SOH                     | Start of heading       |
| STX                     | Start of text          |
| ETX                     | End of text            |
| EOT                     | End of transmission    |
| ENQ                     | Enquiry                |
| ACK                     | Acknowledge            |
| NAK                     | Negative acknowledge   |
| SYN                     | Synchronous idle       |

## Using END\_PAGE\_ACTION

If the network is formatting your screen in line mode, it repositions the cursor at the top of the screen after filling the last line with input or output. (This occurs when INPUT\_EDITING\_MODE is normal.) By setting END\_PAGE\_ACTION, you can control whether the network clears the screen when it moves the cursor.



## Transparent Mode

When the service is sending transparent output and formatting your display, the network passes the data from the service to the display without editing it. (This occurs when INPUT\_EDITING\_MODE is transparent.) The service must then include all the necessary 3270 display orders to position the field attribute characters (not BSC characters) that format the screen.

## Connection Attributes

The 3270 Binary Synchronous Communications protocol supports a subset of the available connection attributes. The BSC3270TIP supports this attribute subset. The default settings for these supported attributes are displayed in figure F-3.

|                            |               |
|----------------------------|---------------|
| Break_Key_Action           | : 1           |
| Input_Block_Size           | : 160         |
| Input_Editing_Mode         | : NORMAL      |
| Input_Output_Mode          | : UNSOLICITED |
| Transparent_Character_Mode | : TERMINATE   |

**Figure F-2. 3270 Binary Synchronous Communications Protocol Connection Attribute Defaults**

Table F-3 compares the way 3270 uses certain connection attributes with their quick-reference descriptions in chapter 4.

**Table F-3. Connection Attribute Differences**

| <b>Connection Attribute (Abbreviation)</b> | <b>Default Setting</b> | <b>Comparison</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| BREAK_KEY_ACTION (BKA)                     | 1                      | Same description applies in both cases.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| INPUT_BLOCK_SIZE (IBS)                     | 160                    | Same description applies in both cases.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| INPUT_EDITING_MODE (IEM)                   | NORMAL                 | Same description applies in both cases.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| INPUT_OUTPUT_MODE (IOM)                    | UNSOLICITED            | <p>You can use all three settings. The display station only sends input when the network requests it, and the network sends output whenever the station is able to accept it.</p> <p>For unsolicited mode, the TIP immediately clears the next line after input and unlocks the keyboard before the input is forwarded to the host service. For solicited mode, the TIP leaves the keyboard locked after input until the host service solicits the next input. For either mode, the TIP clears the line following any output from the service and unlocks the keyboard.</p> |
| TRANSPARENT_CHARACTER_MODE (TCM)           | TERMINATE              | Same description applies in both cases.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

## Migrating from CCP

If you have been using CCP and are migrating to CDCNET, your processing may be affected by some of the differences listed in table F-4. (Also see appendix D.)

**Table F-4. CCP and CDCNET Differences**

| Feature      | CDCNET Support                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | CCP Support                                                                                                                                      |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| Secure input | <p>Ensures a secure environment in which all existing connections are deleted before you establish one to your service. Performing the secure-access sequence prevents someone else from obtaining and using your validation information.</p> <ol style="list-style-type: none"> <li>1. Press the PA1 key.</li> <li>2. Wait for the service to reenab the keyboard.</li> <li>3. Press A (lowercase or uppercasing).</li> <li>4. Press T (lowercase or uppercasing).</li> <li>5. Press the ENTER key.</li> </ol> | <p>Uses the following sequence:</p> <p>CLEAR (PA4)<br/>           PA1<br/>           Network Security Character (CCP installation parameter)</p> |

*(Continued)*

Table F-4. CCP and CDCNET Differences (Continued)

| Feature      | CDCNET Support                                                                                                                                                                                                                                                                                                                                                                   | CCP Support                                                                                                                                                                                                                                        |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Interrupts   | <p>Supports user interrupts. (See chapter 6 for more information.) You can issue an interrupt by doing either of the following:</p> <ul style="list-style-type: none"> <li>● Enter the NETWORK_ COMMAND_ CHARACTER followed by an integer or letter (for example, %1 and %2).</li> <li>● Press the PA1 key. It performs the interrupt specified by BREAK_KEY_ ACTION.</li> </ul> | <p>Provides interrupts called User Breaks. You can issue a User Break by doing either of the following:</p> <ul style="list-style-type: none"> <li>● Press the PA1 key for User Break 1.</li> <li>● Press the PA2 key for User Break 2.</li> </ul> |
| Page holding | <p>Stops output when HOLD_PAGE is ON at PAGE_LENGTH less one line. If the PAGE_LENGTH setting is same as the actual screen length, your output stops at the end of the physical screen.</p>                                                                                                                                                                                      | <p>If the your setting is the same as the actual screen length, your output stops whenever the number of lines minus one has been displayed. If your output starts in the middle of the screen, it may stop in the middle of the screen.</p>       |

(Continued)

**Table F-4. CCP and CDCNET Differences** *(Continued)*

| Feature                       | CDCNET Support                                                                                                                                                                                                                                                 | CCP Support                                                                     |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------|
| Initiating transparent input  | Establishes transparent input by setting INPUT_EDITING_MODE. Using this setting enables the service to control input.                                                                                                                                          | Initiates transparent input by making the last output transmission transparent. |
| Terminating transparent input | Enables you to terminate transparent input (emergency transparent sequence) by escaping to \$NET:                                                                                                                                                              | Does not support a similar feature.                                             |
|                               | <ol style="list-style-type: none"> <li>1. Press the PA1 key.</li> <li>2. Wait for the service to reenale the keyboard.</li> <li>3. Press A (lowercase or uppercase).</li> <li>4. Press X (lowercase or uppercase).</li> <li>5. Press the ENTER key.</li> </ol> |                                                                                 |

## **X.25 Asynchronous Protocol**

---

**G**

|                                                 |     |
|-------------------------------------------------|-----|
| The Protocol .....                              | G-2 |
| The Environment .....                           | G-2 |
| The Terminal-to-PAD Connection .....            | G-3 |
| CDCNET and the X25_ASYNC_TIP .....              | G-3 |
| Automatic Recognition .....                     | G-4 |
| User Interrupt Function .....                   | G-4 |
| BREAK Key and Attention Character Actions ..... | G-4 |
| Attribute Support and PAD Parameters .....      | G-5 |
| Connection Attributes .....                     | G-5 |
| Terminal Attributes .....                       | G-6 |
| PAD Parameter Settings .....                    | G-8 |





# X.25 Asynchronous Protocol

The X.25 asynchronous protocol allows asynchronous interactive terminal users to access a service across an X.25 link. CDCNET supports the X.25 asynchronous protocol through a terminal interface program (TIP). This TIP supports asynchronous terminals using the X.25 asynchronous protocol that are connected to CDCNET through an X.29 PAD (Packet Assembler/Disassembler).

Features available to an X.25 asynchronous protocol user accessing CDCNET over an X.25 link are generally the same as the features available to users of asynchronous terminals connected directly to CDCNET.

Since CDCNET's implementation of X.25 follows the same conventions as the other CDCNET-supported protocols, this appendix supplements the existing CDCNET documentation. The following sections describe only the differences and unique capabilities of the terminal interface program supporting the X.25 asynchronous protocol. The commands, attributes, and features described in general CDCNET documentation also apply to connections made through an X.25 link, except where noted in this appendix.

| <b>Section</b>                       | <b>Description</b>                                                                                                             |
|--------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| The Protocol                         | Describes general features of the X.25 asynchronous protocol as supported by the X.25 asynchronous terminal interface program. |
| The Environment                      | Discusses the relationships among components in the connection from terminal to CDCNET.                                        |
| Attribute Support and PAD Parameters | Describes the CDCNET terminal and connection attributes, and packet assembler/disassembler (PAD) parameter settings.           |

## The Protocol

The X.25 asynchronous protocol, as supported by the X.25 asynchronous terminal interface program, provides asynchronous interactive terminal users access to CDCNET across an X.25 link. Recommendation X.25 (1980) is a data communications standard published by the Consultative Committee of International Telephone and Telegraph (CCITT). The terminal interface program conforms to this standard, which is part of the International Standard Organization/Open Systems Interconnection (ISO/OSI) model.

## The Environment

The X.25 environment consists of:

- A terminal
- A packet assembler/disassembler (PAD)
- CDCNET, configured with the X.25\_ASYNC TIP

Figure G-1 illustrates the relationships in this environment.




Figure G-1. X.25 Environment

## The Terminal-to-PAD Connection

X.25 is a packet-switching protocol. So that terminals can communicate using this protocol, data from the terminal must be assembled into packets that conform to the protocol, and output to the terminal must be disassembled for use by the terminal. This function is performed by a packet assembler/disassembler, or PAD. A PAD can reside on an X.25 public data network (PDN), in specialized communications equipment, or is sometimes a feature of the workstation itself.

### CDCNET and the X25\_ASYNC\_TIP

CDCNET supports the X.25 protocol through its X.25 asynchronous terminal interface program, X25\_ASYNC\_TIP. When CDCNET is configured to support the X.25 asynchronous protocol, the X25\_ASYNC\_TIP resides in one or more of the device interfaces (DIs) on the network. The X25\_ASYNC\_TIP works with the PAD to manage the terminal-to-application communications..

The X25\_ASYNC\_TIP provides the following features:

- Performs validation of X.25 facilities in determining acceptance or rejection of an incoming call.
- Accesses and sets PAD parameters based on terminal and connection attributes specified by the application and terminal user.
- Performs character formatting/conversion between the virtual terminal protocol and the data sent to and from the terminal.

Using CDCNET across an X.25 link via the X25\_ASYNC\_TIP is the same as using CDCNET across a direct connection on an asynchronous terminal via the ASYNCTIP, except for the following features:

- Automatic recognition
- User interrupt function
- BREAK key and attention character actions

These three exceptions are described on the following pages.

## Automatic Recognition

When using the X.25 asynchronous protocol through the X25\_ASYNCTIP, the automatic recognition sequence, if any, is performed by the PAD. CDCNET cannot control whether or how the PAD performs automatic recognition. CDCNET determines the speed of a remotely connected terminal by reading PAD reference #11 (see Attribute Support and PAD Parameters, later in this appendix). Use the CODE\_SET terminal attribute to establish your terminal's code set (CHATA CS=value).

### NOTE

---

The X25\_ASYNCTIP does not recognize the ACTIVATE\_AUTO\_RECOGNITION (ACTAR) terminal user command.

---

## User Interrupt Function

A user interrupt of 0 (%0) synchronizes the input path between CDCNET and the service or application. User interrupts in the range from 1 through 9 synchronize both the input and output paths between CDCNET and the service or application. User interrupts do not affect data that has already been passed from the X25\_ASYNCTIP to the PAD. This data is still forwarded to the terminal or service.

## BREAK Key and Attention Character Actions

Output data is lost if you strike the BREAK key while receiving output. When the PAD receives the BREAK key it stops delivering data to the terminal and discards all data that has been forwarded by the X25\_ASYNCTIP.

The secure access sequence, described in chapter 6, can be used with the X25\_ASYNCTIP to delete all existing connections.

You can terminate transparent input mode by entering the following sequence:

1. Press the BREAK key or enter the attention character.
2. Hold down the CONTROL (or CTRL) key and enter AX.

3. Press <CR>.

Only a BREAK key sequence is guaranteed to work regardless of the state of your virtual circuit.

## Attribute Support and PAD Parameters

Connection and terminal attributes, as well as PAD parameters, affect the communications from terminal to application over an X.25 link.

### Connection Attributes

The X25\_ASYNCTIP supports all of the connection attributes available to asynchronous protocol users through the ASYNCTIP. The default values for all connection attributes supported by the X25\_ASYNCTIP are the same as for the ASYNCTIP connection attribute values documented earlier in this manual.

#### NOTE

---

Input does not interrupt output while the value of the unsolicited INPUT\_OUTPUT\_MODE parameter is UNSOLICITED. The only way to interrupt output is by using the BREAK key or attention character, or X-OFF (only if the CHARACTER\_FLOW\_CONTROL terminal attribute is set to TRUE).

Output is deferred when the connection is in unsolicited mode and input is active. However, determination by the X.25 protocol of when input is active differs from a determination made by the asynchronous protocol. The X.25 asynchronous protocol considers input active when a data packet is received with the more-bit (M-bit) set, or one not terminated with a non-partial forwarding character (ELC/TFC/TTC). The asynchronous protocol considers input active when the first character of a message is entered.

---

## Terminal Attributes

When you use CDCNET through an X.25 link, some of your terminal attributes are controlled directly by CDCNET, while others are controlled by the PAD, under the direction of CDCNET (CDCNET sets PAD references).

The CDCNET X25\_ASYNCTIP manages the following terminal attributes directly:

- Attention\_Character (AC)
- Backspace\_Character (BC)
- Begin\_Line\_Character (BLC)
- Cancel\_Line\_Character (CLC)
- Carriage\_Return\_Delay (CRD)
- Carriage\_Return\_Sequence (CRS)
- Code\_Set (CS)
- Control\_Code\_Replacement (CCR)
- End\_Line\_Character (ELC)
- End\_Line\_Positioning (ELP)
- End\_Output\_Sequence (EOS)
- End\_Page\_Action (EPA)
- End\_Partial\_Character (EPC) <sup>1</sup>
- End\_Partial\_Positioning (EPP)
- Fold\_Line (FL)
- Form\_Feed\_Delay (FFD)
- Form\_Feed\_Sequence (FFS)
- Hold\_Page (HP)
- Hold\_Page\_Over (HPO)
- Line\_Feed\_Delay (LFD)
- Line\_Feed\_Sequence (LFS)
- Network\_Command\_Character (NCC)
- Page\_Length (PL)
- Page\_Width (PW)
- Parity (P)
- Response\_Action (RA) <sup>2</sup>
- Status\_Action (SA)
- Terminal\_Model (TM)

---

1. Performance is optimal if the EPC and EPP attributes are set to their negative values (EPC=NULL, EPP=NONE).

2. The RA terminal attribute has no affect on any PAD parameter settings.

The following terminal attributes are set in the PAD by CDCNET, but are controlled and used by the PAD.

| <u>Terminal Attribute</u>    | <u>Description</u>                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Character_Flow_Control (CFC) | Flow control is managed by the PAD, not by CDCNET. CDCNET can manipulate flow control, however, by setting the appropriate PAD parameters. EIA flow control using RTS and CTS is not supported by the X25_ASYNCTIP.                                                                                                                                                                                                                           |
| Echoplex (E)                 | <p>CDCNET does not echo received input. If echoplex is turned on and data is typed ahead while the connection is in solicited mode, the data is echoed immediately by the PAD, not when processed by CDCNET.</p> <p>In certain environments, the PAD sends line feeds if the terminal attribute echoplex (E) is set to TRUE. Assuming the default values of ELC=CR, ELP=LFS, and LFS=LF, CDCNET need not send END_LINE_POSITIONING (ELP).</p> |
| Parity (P)                   | CDCNET generates the correct parity for output to the terminal. Checking for correct parity on input is a function of the PAD.                                                                                                                                                                                                                                                                                                                |



## PAD Parameter Settings

If you do not change the CDCNET terminal and connection attributes, the X25\_ASYNCTIP sets PAD parameters to their default values at initial connection time (consult CCITT Recommendation X.3). These default values, which are listed in the following table, can be adjusted using the CHACA and CHATA commands.

**Table G-1. PAD Parameter Values**

| PAD Parameter  | Description                         | Default Value | Optional Values                                                                                                                                                                                                                                                                                                                   |
|----------------|-------------------------------------|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1              | PAD recall using a character        | 1(10)         | If the input editing mode (IEM) is transparent, then this parameter is set to zero (0).                                                                                                                                                                                                                                           |
| 2              | Echoplex                            | 1(10)         | If the echoplex terminal attribute is not TRUE, this PAD parameter is set to zero (0).                                                                                                                                                                                                                                            |
| 3 <sup>1</sup> | Selection of data-forwarding signal | 34(10)        | <p>If IEM=NORMAL, this parameter is ELC + AC (if AC≠NULL) + EPC (if EPP=T).</p> <p>If input editing mode is transparent, this parameter is the aggregate of AC and the type of transparent mode, as follows:</p> <ul style="list-style-type: none"> <li>● If TTM or TLM, then zero (0).</li> <li>● If TCM=F, then TFC.</li> </ul> |

1. CDCNET defines the transparent forwarding and terminating characters (TFC/TTC) as 8-bit characters, but since the X.25 specification has no provision for mapping 8-bit characters to PAD parameter 3, the X25\_ASYNCTIP does not attempt to map these characters to parameter 3 or 4 if the higher order bit is set.

*(Continued)*

**Table G-1. PAD Parameter Values** *(Continued)*

| <b>PAD Parameter</b>          | <b>Description</b>                                   | <b>Default Value</b> | <b>Optional Values</b>                                                                                                                                                                                                                                                                                                                                  |
|-------------------------------|------------------------------------------------------|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3 <sup>1</sup><br>(Continued) |                                                      |                      | <ul style="list-style-type: none"> <li>● If TCM=T, then TTC.</li> <li>● If TCM=FT, then TFC and TTC.</li> <li>● If no transparent mode is selected, then zero (0).</li> </ul>                                                                                                                                                                           |
| 4 <sup>2</sup>                | Selection of idle timer delay (in 0.05 second units) | 0(10)                | <p>If input editing mode is transparent and:</p> <ul style="list-style-type: none"> <li>● TTM is selected, then 1(10) through 20(10) based on PAD parameter 11.</li> <li>● TLM is selected, then 20(10). If TML=1, then 1(10).</li> <li>● No transparent mode is selected, then 20(10).</li> </ul> <p>If input editing mode is normal, then 20(10).</p> |
| 5                             | Ancillary device control                             | 0(10)                | If CFC=TRUE, then 1.                                                                                                                                                                                                                                                                                                                                    |

1. CDCNET defines the transparent forwarding and terminating characters (TFC/TTC) as 8-bit characters, but since the X.25 specification has no provision for mapping 8-bit characters to PAD parameter 3, the X25\_ASYNCTIP does not attempt to map these characters to parameter 3 or 4 if the higher order bit is set.

2. If an AC, ELC, EPC, TTC, TFC character cannot be mapped to parameter 3, or if the computed value for parameter 3 is rejected by the PAD (nonsupported value), parameter 4 is set to 20(10).

*(Continued)*

Table G-1. PAD Parameter Values (Continued)

| PAD Parameter | Description                                                                           | Default Value | Optional Values                                                                                              |
|---------------|---------------------------------------------------------------------------------------|---------------|--------------------------------------------------------------------------------------------------------------|
| 6             | Control of PAD service signals                                                        | N/A           | This PAD parameter is not modified or referenced by CDCNET.                                                  |
| 7             | Selection of operation of PAD on receipt of break signal from the start-stop mode DTE | 21(10)        | N/A                                                                                                          |
| 8             | Discard output                                                                        | 0(10)         | N/A                                                                                                          |
| 9             | Padding after carriage return (CR)                                                    |               | This PAD parameter is not modified or referenced by CDCNET.                                                  |
| 10            | Line folding                                                                          | 0(10)         | N/A                                                                                                          |
| 11            | Binary speed of start-stop mode DTE                                                   | N/A           | This is a read-only parameter that is never modified. It is referenced when computing FFD, CRD and LFD NULs. |

*(Continued)*

Table G-1. PAD Parameter Values (Continued)

| PAD Parameter   | Description                                        | Default Value | Optional Values                                                                                    |
|-----------------|----------------------------------------------------|---------------|----------------------------------------------------------------------------------------------------|
| 12 <sup>1</sup> | Flow control of the PAD by the start-stop mode DTE | 0(10)         | If CFC=TRUE, then 1(10).                                                                           |
| 13              | Linefeed insertion after carriage return           | 4(10)         | If IEM=NORMAL, E=TRUE, ELC=CR, and ELP=LF, then 4; if EPC=CR, and EPP=LF, then 4; otherwise, zero. |
| 14 <sup>2</sup> | Padding after linefeed                             |               | Not applicable.                                                                                    |
| 15              | Editing                                            | 0(0)          | Not applicable.                                                                                    |
| 16 <sup>2</sup> | Character delete                                   |               | Not applicable.                                                                                    |
| 17 <sup>2</sup> | Line delete                                        |               | Not applicable.                                                                                    |
| 18 <sup>2</sup> | Line display                                       |               | Not applicable.                                                                                    |
| 19 <sup>2</sup> | Editing PAD service signals                        |               | Not applicable.                                                                                    |
| 20 <sup>2</sup> | Echo mask                                          |               | Not applicable.                                                                                    |
| 21              | Parity treatment                                   | 0(10)         | Not applicable.                                                                                    |
| 22 <sup>1</sup> | Page wait                                          | 0(10)         | Not applicable.                                                                                    |

1. PAD parameters 12 through 22 provide user facilities that are not necessarily provided in all PADs.

2. PAD parameters 14, and 16 through 20 are not modified or referenced by CDCNET.

## Attribute Support and PAD Parameters

If an error PAD message is received in response to a setting of parameter 3, CDCNET sets parameter 3 to 126 (this means that all control characters, and the DEL character, are used as data-forwarding signals; in other words, single-character forwarding is used). Any other errors reported by the PAD are ignored.

CDCNET recomputes the values of the PAD parameters each time a CDCNET attribute is changed (by a terminal user or application, or when terminating transparent mode). If the computed values are different (previously computed values are maintained for each virtual circuit), a set pad parameter message is sent to the PDN PAD with the updated values.

# **X.PC Communications Protocol H**

---

- The Protocol ..... H-2
- The Environment ..... H-2
  - The Microcomputer Connection ..... H-3
  - The Microcomputer's Data Communications Software ..... H-5
  - CDCNET and the XPC Protocol ..... H-5
  - CDCNET Configuration of X.PC on an Asynchronous Line ..... H-6
- Attribute Support ..... H-7
  - Terminal Attributes ..... H-7
  - Connection Attributes ..... H-12



X.PC<sup>1</sup> is an asynchronous data communications protocol developed to improve the networking capabilities of microcomputers. CDCNET support of the X.PC protocol and the microcomputer X.PC data communications software provides powerful capabilities such as windowing, delivery-assurance of all data transfers, and multiple, simultaneous connections between separate applications and microcomputer windows over low-cost communication lines.

Since the implementation of X.PC on CDCNET follows the same conventions as do the other CDCNET-supported protocols, this appendix supplements the existing CDCNET and microcomputer documentation. The following sections describe the differences and unique capabilities of the software supporting the X.PC protocol. The commands, attributes, and features in the general CDCNET documentation also apply to connections made through an X.PC .link, except where noted in this appendix.

| <b>Section</b>    | <b>Description</b>                                                                                   |
|-------------------|------------------------------------------------------------------------------------------------------|
| The Protocol      | Describes general features of the X.PC protocol as supported by CDCNET.                              |
| The Environment   | Discusses your microcomputer requirements, the CDCNET network, and X.PC operational characteristics. |
| Attribute Support | Describes the CDCNET terminal and connection attributes which are supported by the X.PC protocol.    |

---

1. X.PC is a trademark of TYMNET, Incorporated.



## The Protocol

The X.PC protocol program provides the user of a microcomputer with enhanced access to CDCNET through the use of packet-switching data communications techniques. X.PC was derived from the Consultative Committee of International Telephone and Telegraph Recommendation X.25 (CCITT X.25 or X.25) and conforms to the International Standard Organization/Open Systems Interconnection (ISO/OSI) model. The name X.PC was chosen to indicate the functional similarity to the X.25 recommendation. The CDCNET support of the protocol conforms to this standard.

X.PC is an error-checking asynchronous protocol with the ability to support up to 15 simultaneous logical channels over a single physical communications link. Error checking and recovery capability is provided by using sequenced packets and CCITT 16-bit cyclic redundancy checksum (CRC-16). A logical channel identifier that provides for multiple logical connections is built into the packet header.

## The Environment

The X.PC environment consists of:

- A microcomputer
- X.PC data communications software for the microcomputer
- CDCNET, configured for X.PC support
- Up to 15 separate host or information services

Figure H-1 illustrates the X.PC environment




Figure H-1. X.PC Environment

## The Microcomputer Connection

The microcomputer is connected to CDCNET through one of the following:

- A full-duplex, RS-232, asynchronous interface, with or without modems. The line can be dedicated or switched. The carrier must be constant. Line speeds are from 75 to 38,400 bits per second (bps). These lines are configured with the Asynchronous or X.PC protocols.
- An X.25 packet-switching network configured to support the X.25 Asynchronous protocol.

Automatic recognition of line speed is allowed only for the first type of connection. (Refer to the `ACTIVATE_AUTO_RECOGNITION` command in chapter 2). The X.PC character set is always ASCII, and parity is set to zero or none by CDCNET. See the terminal attribute `PARITY` description in table H-1.

**NOTE**

---

Certain microcomputer X.PC software products support only line speeds equal to, or greater than 600 bps. Reference the specific documentation for your microcomputer data communications software to determine whether this line speed requirement is applicable to your system.

---

## The Microcomputer's Data Communications Software

The X.PC protocol is implemented in two parts: an X.PC driver within your microcomputer's data communications software; and a terminal interface program (TIP), which resides within CDCNET. The microcomputer's X.PC driver is used by microcomputer applications to build and transmit (or to receive and disassemble) packets of information which are exchanged between the microcomputer and CDCNET. The microcomputer's X.PC driver software provides access to the specific features of X.PC on CDCNET.

Control Data's Desktop/VE, Microsoft's ACCESS, and Microstuff's CROSSTALK<sup>2</sup> are examples of microcomputer software products which support the X.PC protocol. The documentation for these products, or any other microcomputer X.PC data communications products, should provide instructions for installing and initializing X.PC on your microcomputer. Reference the documentation for your microcomputer software to determine the explicit X.PC protocol features your microcomputer supports.

### NOTE

---

The CDCNET implementation of the X.PC protocol supports microcomputer data communications software which has passed TYMNET certification. To avoid problems, please ensure that your microcomputer software has this certification. This can be accomplished by referencing the documentation with your microcomputer data communications software or by asking the vendor.

---

## CDCNET and the XPC Protocol

The other part of the X.PC protocol implementation is the software within CDCNET. The software differs depending on how the microcomputer is connected to CDCNET.

---

2. ACCESS and CROSSTALK are registered trademarks.

## **CDCNET Configuration of X.PC on an Asynchronous Line**

The CDCNET site administrator can configure an X.PC or an asynchronous data communications line in two different ways. Some lines can be connected directly to the XPCTIP; others can be initially connected to the ASYNCTIP as an asynchronous ASCII terminal before being switched to the XPCTIP. The second of these options provides greater flexibility in allowing microcomputers and standard data communications terminals to connect to the same switched lines. Contact your CDCNET site administrator to determine which configuration is available to your microcomputer.

If your microcomputer is not initially connected to the XPCTIP, you can switch to the X.PC protocol by issuing the terminal user command `ACTIVATE_X_PERSONAL_COMPUTER (ACTXPC)`. `ACTXPC` can be issued directly by the microcomputer user or from within the microcomputer's data communications software. `ACTXPC` is described in chapter 2 of this manual; however, you should reference the documentation for your microcomputer's data communications software to understand how the X.PC connection is accomplished on your system.

The CDCNET site administrator can configure the `X.25_ASYNC_TIP` for microcomputers connected via an X.29 PAD facility. No special configuration is required for X.PC support. CDCNET does no switching between terminal interface programs when X.PC is run over this type of interface. A terminal user activates the X.PC protocol by using the terminal user command `ACTXPC`.

### **NOTE**

---

For lines using the X.PC protocol, user connections are counted in the following manner: each logical channel without any service connections is counted as having one user connection. The number of user connections from any other logical channel is equal to the number of service connections it has.

When the user connection limit is reached on a line using the X.PC protocol, no new logical channels are permitted, and existing logical channels with active service connections are not permitted to create new service connections. Logical channels without any existing service connections are permitted to create a single service connection.

---

## Attribute Support

You can change and display certain terminal and connection attributes from your X.PC microcomputer. However, some microcomputer data communications software products can set these terminal and connection attributes directly. Reference the documentation with your microcomputer software to determine whether you should change any of these attributes with CDCNET commands.

### Terminal Attributes

CDCNET supports a set of terminal attributes that apply to all of your terminal's X.PC connections. The default settings of these terminal attributes are displayed in figure H-2.

|                           |        |
|---------------------------|--------|
| Attention_Character       | :NUL   |
| Backspace_Character       | :BS    |
| Cancel_Line_Character     | :CAN   |
| Carriage_Return_Delay     | :0     |
| Carriage_Return_Sequence  | :CR    |
| Code_Set                  | :ASCII |
| Echoplex                  | :OFF   |
| End_Line_Character        | :CR    |
| End_Line_Positioning      | :LF    |
| End_Output_Sequence       | :1     |
| End_Page_Action           | :NONE  |
| End_Partial_Character     | :LF    |
| End_Partial_Positioning   | :CR    |
| Fold_Line                 | :ON    |
| Form_Feed_Delay           | :0     |
| Form_Feed_Sequence        | :FF    |
| Hold_Page                 | :OFF   |
| Hold_Page_Over            | :ON    |
| Line_Feed_Delay           | :0     |
| Line_Feed_Sequence        | :LF    |
| Network_Command_Character | :%     |
| Page_Length               | :24    |
| Page_Width                | :80    |
| Parity                    | :NONE  |
| Response_Action           | :SEND  |
| Status_Action             | :SEND  |
| Terminal_Model            | :NONE  |
| Backspace_Window          | :PW    |

<sup>1</sup>The default EOS is an empty sequence.

**Figure H-2. X.PC Protocol Terminal Attribute Defaults**

The following list of terminal attributes are only supported as shown in figure H-2, and cannot be changed:

- Backspace\_Character
- Carriage\_Return\_Delay
- Code\_Set
- Echoplex
- End\_Line\_Character
- End\_Partial\_Character
- Form\_Feed\_Delay
- Line\_Feed\_Delay

For those terminal attributes that the X.PC protocol treats differently from the asynchronous protocol, table H-1 contains the default setting and a comparison of the way X.PC protocol uses the attribute relative to the quick-reference description in chapter 3.

Some of the terminal attributes are supported with a fixed value. If changed by the terminal user or microcomputer data communications software, the change is rejected or ignored.

**Table H-1. Terminal Attribute Differences**

| <b>Terminal Attribute<br/>(Abbreviation)</b> | <b>Default<br/>Setting</b> | <b>Chapter 3<br/>Comparison</b>                                                              |
|----------------------------------------------|----------------------------|----------------------------------------------------------------------------------------------|
| ATTENTION_<br>CHARACTER (AC)                 | NUL                        | Same description applies.                                                                    |
| BACKSPACE_<br>CHARACTER (BC)                 | BS                         | Cannot be changed.                                                                           |
| BEGIN_LINE_<br>CHARACTER (BLC)               |                            | Unused.                                                                                      |
| CANCEL_LINE_<br>CHARACTER (CLC)              | CAN                        | Same description applies. This option can be deactivated by assigning NUL to this attribute. |
| CARRIAGE_RETURN_<br>DELAY (CRD)              | 0                          | Cannot be changed.                                                                           |

*(Continued)*



**Table H-1. Terminal Attribute Differences (Continued)**

| <b>Terminal Attribute<br/>(Abbreviation)</b> | <b>Default<br/>Setting</b> | <b>Chapter 3<br/>Comparison</b>                                             |
|----------------------------------------------|----------------------------|-----------------------------------------------------------------------------|
| CARRIAGE_RETURN_<br>SEQUENCE (CRS)           | CR                         | Same description applies.                                                   |
| CHARACTER_FLOW_<br>CONTROL (CFC)             |                            | Unused.                                                                     |
| CODE_SET (CS)                                | ASCII                      | Cannot be changed.                                                          |
| ECHOPLEX (E)                                 | OFF                        | Cannot be changed.                                                          |
| END_LINE_CHARACTER<br>(ELC)                  | CR                         | Cannot be changed.                                                          |
| END_LINE_<br>POSITIONING (ELP)               | LF                         | Same description applies. The<br>allowed values are: NONE,<br>CR, LF, CRLF. |
| END_OUTPUT_<br>SEQUENCE (EOS)                | nothing<br>sent            | Same description applies.<br>Defaults to send no extra<br>characters.       |
| END_PAGE_ACTION<br>(EPA)                     | NONE                       | Same description applies.                                                   |
| END_PARTIAL_<br>CHARACTER (EPC)              | LF                         | Cannot be changed.                                                          |
| END_PARTIAL_<br>POSITIONING (EPP)            | CR                         | Same description applies.<br>Allowed values are: NONE,<br>CR, LF, CRLF.     |
| FOLD_LINE (FL)                               | ON                         | Same description applies.                                                   |
| FORM_FEED_DELAY<br>(FFD)                     | 0                          | Cannot be changed.                                                          |
| FORM_FEED_<br>SEQUENCE (FFS)                 | FF                         | Same description applies.                                                   |

*(Continued)*

**Table H-1. Terminal Attribute Differences (Continued)**

| <b>Terminal Attribute<br/>(Abbreviation)</b> | <b>Default<br/>Setting</b> | <b>Chapter 3<br/>Comparison</b>                                                                                                                                |
|----------------------------------------------|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| HOLD_PAGE (HP)                               | OFF                        | Same description applies.                                                                                                                                      |
| HOLD_PAGE_OVER<br>(HPO)                      | ON                         | Same description applies.                                                                                                                                      |
| LINE_FEED_DELAY<br>(LFD)                     | 0                          | Cannot be changed.                                                                                                                                             |
| LINE_FEED_SEQUENCE<br>(LFS)                  | LF                         | Same description applies.                                                                                                                                      |
| NETWORK_COMMAND_<br>CHARACTER (NCC)          | %                          | Same description applies.                                                                                                                                      |
| PAGE_LENGTH (PL)                             | 24                         | Same description applies.                                                                                                                                      |
| PAGE_WIDTH (PW)                              | 80                         | Same description applies.                                                                                                                                      |
| PARITY (P)                                   | NONE                       | Allowed values are ZERO and NONE. Parity type of NONE has significance only during transparent input or output. In all other cases, parity is treated as ZERO. |
| RESPONSE_ACTION (RA)                         | SEND                       | Same description applies.                                                                                                                                      |
| STATUS_ACTION (SA)                           | SEND                       | Same description applies.                                                                                                                                      |
| TERMINAL_MODEL (TM)                          | NONE                       | Same description applies.                                                                                                                                      |

## Connection Attributes

The X.PC protocol supports a set of connection attributes that regulate certain aspects of the connection between your microcomputer and the CDCNET service. The default settings for these connection attributes are displayed in figure H-3.

|                                 |               |
|---------------------------------|---------------|
| Attention_Character_Action      | : 2           |
| Break_Key_Action                | : 0           |
| Input_Block_Size                | : 160         |
| Input_Editing_Mode              | : NORMAL      |
| Input_Output_Mode               | : UNSOLICITED |
| Partial_Character_Forwarding    | : OFF         |
| Store_Backspace_Character       | : OFF         |
| Store_Nuls_Dels                 | : OFF         |
| Transparent_Character_Mode      | : TERMINATE   |
| Transparent_Forward_Character   | : CR          |
| Transparent_Length_Mode         | : NONE        |
| Transparent_Message_Length      | : 255         |
| Transparent_Terminate_Character | : CR          |

**Figure H-3. X.PC Protocol Connection Attribute Defaults**

For each connection attribute that the X.PC protocol treats differently from the asynchronous protocol, table H-2 contains the default setting and a comparison of the way X.PC protocol uses the attribute relative to the quick-reference description in chapter 4.

**Table H-2. Connection Attribute Differences**

| Connection Attribute<br>(Abbreviation) | Default<br>Setting | Chapter 4<br>Comparison                                                                                                                                                                                                                  |
|----------------------------------------|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ATTENTION_CHARACTER_<br>ACTION (ACA)   | 2                  | Same description applies. Allowed values are 0 through 9. Values 1 through 9 cancel output as well as input. Depending upon the buffering and the actions taken locally at your microcomputer, there can be a delay before output stops. |
| BREAK_KEY_ACTION<br>(BKA)              | 0                  | Same description applies. Allowed values are 0 through 9. Depending upon the buffering and the actions taken locally at your microcomputer, there can be a delay before output stops.                                                    |

*(Continued)*

**Table H-2. Connection Attribute Differences** *(Continued)*

| <b>Connection Attribute<br/>(Abbreviation)</b> | <b>Default<br/>Setting</b> | <b>Chapter 4<br/>Comparison</b> |
|------------------------------------------------|----------------------------|---------------------------------|
| INPUT_BLOCK_SIZE (IBS)                         | 160                        | Same description applies.       |
| INPUT_EDITING_MODE (IEM)                       | NORMAL                     | Same description applies.       |
| INPUT_OUTPUT_MODE (IOM)                        | UNSOLICITED                | Same description applies.       |
| PARTIAL_CHARACTER_FORWARDING (PCF)             | OFF                        | Same description applies.       |
| STORE_BACKSPACE_CHARACTER (SBC)                | OFF                        | Cannot be changed.              |
| STORE_NULS_DELS (SND)                          | OFF                        | Cannot be changed.              |
| TRANSPARENT_CHARACTER_MODE (TCM)               | TERMINATE                  | Same description applies.       |
| TRANSPARENT_FORWARD_CHARACTER (TFC)            | CR                         | Same description applies.       |
| TRANSPARENT_LENGTH_MODE (TLM)                  | NONE                       | Same description applies.       |
| TRANSPARENT_MESSAGE_LENGTH (TML)               | 255                        | Same description applies.       |
| TRANSPARENT_TERMINATE_CHARACTER (TTC)          | CR                         | Same description applies.       |
| TRANSPARENT_TIMEOUT_MODE (TTM)                 |                            | Unused.                         |

# Mode 4 Protocol

I

---

|                                               |      |
|-----------------------------------------------|------|
| Your Mode 4 Terminal .....                    | I-2  |
| Mode 4A Terminals .....                       | I-2  |
| Mode 4C Terminals .....                       | I-2  |
| Supported Features .....                      | I-3  |
| Multiple Connections .....                    | I-3  |
| Paging .....                                  | I-4  |
| Interactive Interrupt .....                   | I-5  |
| Automatic Recognition of Code Set .....       | I-6  |
| Security Character Sequence .....             | I-6  |
| Virtual Line Mode .....                       | I-7  |
| Transparent Input Mode .....                  | I-8  |
| Transparent Output Mode .....                 | I-8  |
| CDC 714-30 Terminal Underline Character ..... | I-9  |
| Attribute Support .....                       | I-10 |
| Terminal Attributes .....                     | I-10 |
| Connection Attributes .....                   | I-12 |
| Migrating from CCP .....                      | I-14 |



The Mode 4 protocol is a data communications protocol supporting two-way alternate communications (messages may be sent in one direction or another, but not in both directions simultaneously). The Mode 4 terminal interface program (TIP) enables synchronous terminals using the Mode 4 protocol to communicate with NOS and NOS/VE hosts using CDCNET. In general, this protocol adheres to the same conventions as other CDCNET-supported protocols.

Since CDCNET's implementation of the Mode 4 protocol follows the same conventions as other CDCNET-supported protocols, this appendix supplements, rather than replaces, the other documentation. The following sections describe differences and unique capabilities that you may encounter while using your Mode 4 terminal. The commands, attributes, and features described in general CDCNET documentation also apply to connections made using the Mode 4 protocol, except where noted in this appendix.

| <b>Topic</b>         | <b>Description</b>                                                                                                                                  |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| Your Mode 4 Terminal | Discusses Mode 4 terminals.                                                                                                                         |
| Supported Features   | Lists the features of the Mode 4 protocol as supported by the Mode 4 terminal interface program.                                                    |
| Attribute support    | Describes the subset of CDCNET terminal and connection attributes supported by the asynchronous protocol that are supported by the Mode 4 protocol. |
| Migrating from CCP   | Highlights differences between CCP and CDCNET support.                                                                                              |



## Your Mode 4 Terminal

Two types of Mode 4 terminals are supported by the Mode 4 protocol as implemented by the MODE4TIP:

- Mode 4A terminals
- Mode 4C terminals

### Mode 4A Terminals

Mode 4A terminals can consist of a group of several clusters consisting of one console, a line printer, and a card reader. Each terminal cluster must have one console device, and can have one optional card reader and one optional line printer.

Mode 4A console operation is suspended when either the card reader or the line printer becomes active.

Mode 4A terminals include the CDC 200UT, CDC 731, CDC 732, CDC 734, and equivalent terminals on a cluster.

### Mode 4C Terminals

Mode 4C terminals can consist of several clusters of consoles and line printers. Each terminal cluster must have at least one console and can have up to 14 additional optional devices. These optional devices can be either consoles or line printers.

All Mode 4C devices can be active at a given time. Interactive operations can be concurrent with batch operations.

Mode 4C terminals include the CDC 711, CDC 714, and equivalent terminals.

## Supported Features

The CDCNET MODE4TIP supports the following features:

- Synchronous line speeds from 1200 through 19200 bits per second
- Multiple terminal clusters on the same communications line
- Automatic recognition of code set, ASCII or BCD
- Virtual terminal protocol (VTP) for console devices
- Normal and transparent input/output mode for console devices
- /\*STAB (START\_BATCH) command for switching Mode 4A terminals from interactive mode to batch mode
- Status request and device polling. Cluster polling *is not* supported

## Multiple Connections

The MODE4TIP supports multiple connections for one console. See chapter 1 for information about managing these connections.

## Paging

Output sent to the console can be displayed page by page. When you enable the `HOLD_PAGE` terminal attribute, the `MODE4TIP` stops output to the terminal after `PAGE_LENGTH` minus 1 lines are displayed. When the `HOLD_PAGE_OVER` terminal attribute is also enabled, the `TIP` stops output after `PAGE_LENGTH` minus 2 lines are output and displays an `<OVER>` message at the bottom of the screen.

Output resumes when you enter any input line. If you enter an empty input line or the `NETWORK_COMMAND_CHARACTER (%)` followed by `SEND`, no input data is sent upline and the next page is displayed.

### NOTE

---

For Mode 4A equipment that cannot recognize an empty line, use the `NETWORK_COMMAND_CHARACTER (%)` to page forward.

---

If the `PAGE_WIDTH` terminal attribute value is set to 0, the paging options are ignored and no paging takes place. This also eliminates normal cursor positioning to the beginning of the next line after each input or output block.

## Interactive Interrupt

You can switch your Mode 4A terminal from interactive mode to batch mode by entering the `/*STAB` command at the console.

The `MODE4TIP` may also switch from interactive to batch mode if a file transfer to the printer begins and no input or output is received or sent to the console for 20 seconds.

You must enter the `/*STAB` command to begin reading cards unless the terminal is already in batch mode because the printer is active.

If batch input or output is interrupted by pressing the batch interrupt key/switch or because output data was received for the console, you may either wait 20 seconds for batch output to resume, or you may enter a `/*STAB` command to resume batch mode.

If batch input or output is interrupted because a printer message (PM) was encountered in the print file and sent to the console, the operator must first acknowledge the message on an `OPES` or `RBF` command before batch input/output can resume.

When batch input/output completes, the `MODE4TIP` automatically resumes polling for interactive input.

## Automatic Recognition of Code Set

The MODE4TIP performs automatic recognition of code set when a communication line becomes active and the terminal type is not known to be either Mode 4A or Mode 4C. If the terminal type is known to be Mode 4C from the configuration, the code set is assumed to be ASCII and code set recognition is completed. If the terminal type is either unknown or known to be 4A from the configuration, the Mode 4 TIP waits for the first SEND or ETX to be entered.

Automatic recognition must complete before the MODE4TIP knows the code set. While the MODE4TIP is waiting for automatic recognition input to be entered, no devices on the cluster are active.

After logging out, a Mode 4 device is not physically disconnected from the network until all Mode 4 devices in the cluster are logged out. Disconnection occurs only if the communication line is a dialup line. Terminals on hardwired communication lines are never disconnected.

Until physical disconnection occurs, you can start new host connection and login procedures without repeating any of the preliminary dialup or automatic recognition access procedures.

## Security Character Sequence

The MODE4TIP recognizes a special 4-character sequence of /\*AT (the AT must be uppercase). When you enter this character sequence on a Mode 4 console as the first and only four characters of a line, all interactive connections for the console are disconnected.

Any files being transferred are completed, but new files are not started. The terminal can be disconnected from the network after all devices are idle.

## Virtual Line Mode

Virtual Line Mode output consists of ASCII text. Each output line can be preceded by an optional ASCII character identified as a format effector. Output lines longer than the set value of `PAGE_WIDTH` are continued on the next line.

The format effector at the beginning of each line specifies vertical spacing and is optional. If a format effector is present, the `MODE4TIP` converts the format effector to the display operations shown in table I-1.

**Table I-1. Mode 4 Console Format Effectors**

| Format Effector | Before Output <sup>1</sup>                    | After Output <sup>1</sup> |
|-----------------|-----------------------------------------------|---------------------------|
| Space           | None                                          | Space 1 line              |
| 0 (zero)        | Space 1 line                                  | Space 1 line              |
| - (dash)        | Space 2 lines                                 | Space 1 line              |
| + (plus)        | None                                          | Space 1 line              |
| 1               | Clear screen and move cursor to top of screen | Space 1 line              |
| *               | Move cursor to top of screen                  | Space 1 line              |

1. After each input and output line, the `TIP` returns the cursor to the beginning (left) margin of the next line.

All other format effectors are treated as a space.

If `PAGE_WIDTH=0`, the `MODE4TIP` does not move the cursor to the beginning of the next line after input or output; this allows the application to control the cursor in Virtual Line Mode.

## Transparent Input Mode

When transparent input editing mode is specified, the MODE4TIP removes the Mode 4 protocol header and trailer characters, but no code translation takes place. Cursor positioning to the next line after input or output is also eliminated.

The MODE4TIP supports the TRANSPARENT\_CHARACTER\_MODE (TCM) terminal attribute. TRANSPARENT\_LENGTH\_MODE (TLM) and TRANSPARENT\_TIMEOUT\_MODE (TTM) are not supported.

Transparent Character Mode is supported as follows:

| TCM Value             | Description                                                                                                                            |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| FORWARD               | Each protocol block received from the device is forwarded as nonpartial data and transparent input mode remains in effect.             |
| FORWARD and TERMINATE | The next protocol block received from the device is forwarded as nonpartial data and transparent input mode remains in effect.         |
| NONE                  | Each protocol block received from the device is forwarded as partial data and transparent input mode is in effect.                     |
| TERMINATE             | The next protocol block received from the device is forwarded as nonpartial data and transparent input mode does not remain in effect. |

## Transparent Output Mode

Selection of output type is controlled by the application through the selection of the data attributes included for each downline data block.

In transparent output mode, the MODE4TIP outputs the data to the device as received. Parity is added to each character. Mode 4 protocol header and trailer characters are also added. No code translation or cursor positioning is performed.

The application program sending the data is responsible for ensuring that the transparent data is acceptable to the terminal.

## CDC 714-30 Terminal Underline Character

The CDC 714-30 Mode 4C terminal does not have an underline (  ) character on its keyboard. Since the    character is frequently used in NOS/VE SCL names, a special feature of the MODE4TIP allows you to use the tilde (~) character in place of the    character. The ~ character is converted by the MODE4TIP to an    character for both input from and output to the terminal. In this way, a CDC 714-30 terminal can be used on a NOS/VE system.

To enable this feature, use the CHANGE\_TERMINAL\_ATTRIBUTE (CHATA) command with the TERMINAL\_MODEL (TM) parameter to change your terminal model name to MODE4C30:

```
%CHATA TM=MODE4C30
```

This command can be entered on your terminal or placed in a TUP file that is called whenever the line becomes active.

When this feature is enabled and the NETWORK\_COMMAND\_CHARACTER is 7E(16) (the ~ character), the NETWORK\_COMMAND\_CHARACTER is stored internally as the underscore character (  ). This allows you to enter the ~ character as the NETWORK\_COMMAND\_CHARACTER. (This is necessary because, on input, the    character is substituted for a ~ character before any testing of the input character against the NCC is performed.)

To disable this feature, enter the CHANGE\_TERMINAL\_ATTRIBUTE command with the TERMINAL\_MODEL parameter specified as any character string other than MODE4C30. (The default is MODE4.)



## Attribute Support

You can change and display certain terminal and connection attributes from your Mode 4 terminal.

### Terminal Attributes

The Mode 4 protocol, as supported by the MODE4TIP uses the default terminal attributes displayed in figure I-1.

|                           |        |
|---------------------------|--------|
| Cancel_Line_Character     | :NUL   |
| End_Output_Sequence       | :NONE  |
| Fold_Line                 | :TRUE  |
| Hold_Page                 | :OFF   |
| Hold_Page_Over            | :ON    |
| Network_Command_Character | :%     |
| Page_Length               | :24    |
| Page_Width                | :80    |
| Response_Action           | :SEND  |
| Status_Action             | :SEND  |
| Terminal_Model            | :MODE4 |

**Figure I-1. Mode 4 Protocol Terminal Attribute Defaults**

For terminal attributes that the Mode 4 protocol treats differently from the Asynchronous protocol, table I-2 compares the way the MODE4TIP uses these terminal attributes with the way ASYNCTIP uses the attributes, as described in chapter 3.

**Table I-2. Terminal Attribute Differences**

| <b>Terminal Attribute<br/>(Abbreviation)</b> | <b>Default<br/>Setting</b> | <b>Chapter 3<br/>Comparison</b>            |
|----------------------------------------------|----------------------------|--------------------------------------------|
| CANCEL_LINE_<br>CHARACTER (CLC)              | NUL                        | Same description applies<br>in both cases. |
| END_OUTPUT_<br>SEQUENCE (EOS)                | None                       | Same description applies<br>in both cases. |
| HOLD_PAGE (HP)                               | OFF                        | Same description applies<br>in both cases. |
| HOLD_PAGE_OVER<br>(HPO)                      | ON                         | Same description applies<br>in both cases. |
| NETWORK_<br>COMMAND_<br>CHARACTER (NCC)      | %                          | Same description applies<br>in both cases. |
| PAGE_LENGTH (PL)                             | 24                         | Same description applies<br>in both cases. |
| PAGE_WIDTH (PW)                              | 80                         | Same description applies<br>in both cases. |
| RESPONSE_ACTION<br>(RA)                      | SEND                       | Same description applies<br>in both cases. |
| STATUS_ACTION (SA)                           | SEND                       | Same description applies<br>in both cases. |
| TERMINAL_MODEL<br>(TM)                       | MODE4                      | Same description applies<br>in both cases. |

## Connection Attributes

Figure I-2 displays the default connection attributes supported by the Mode 4 protocol via the MODE4TIP.

|                            |             |
|----------------------------|-------------|
| Input_Block_Size           | : 160       |
| Input_Editing_Mode         | : NORMAL    |
| Transparent_Character_Mode | : TERMINATE |

**Figure I-2. Mode 4 Protocol Connection Attribute Defaults**

For connection attributes that the Mode 4 protocol treats differently from the Asynchronous protocol, table I-3 compares the way the MODE4TIP uses these connection attributes with the way ASYNCTIP uses the attributes as described in chapter 4.

**Table I-3. Connection Attribute Differences**

| Connection Attribute<br>(Abbreviation)  | Default<br>Setting | Chapter 4<br>Comparison                                                                                                                                                                                                                                                                         |
|-----------------------------------------|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| INPUT_BLOCK_SIZE<br>(IBS)               | 160                | Same description applies<br>in both cases.                                                                                                                                                                                                                                                      |
| INPUT_EDITING_<br>MODE (IEM)            | NORMAL             | 7-bit ASCII, user<br>interrupt, transparent<br>mode, and the<br>CANCEL_LINE_<br>CHARACTER are<br>supported.<br><br>The BREAK key, the<br>ATTENTION_<br>CHARACTER,<br>X-ON/X-OFF flow<br>control, PARTIAL_<br>CHARACTER_<br>FORWARDING, and the<br>BACKSPACE_<br>CHARACTER are not<br>supported. |
| TRANSPARENT_<br>CHARACTER_MODE<br>(TCM) | TERMINATE          | See Transparent Input<br>Mode in this appendix<br>for a discussion of Mode<br>4 support of the<br>TRANSPARENT_<br>CHARACTER_MODE<br>connection attribute.                                                                                                                                       |

## Migrating from CCP

If you have been using CCP and are migrating to CDCNET, your processing may be affected by some of the differences listed in table I-4. (Also see appendix D.)

**Table I-4. CCP and CDCNET Differences**

| <b>Feature</b>        | <b>CDCNET Support</b>                                                                                      | <b>CCP Support</b>                                                              |
|-----------------------|------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------|
| Automatic recognition | Only the code set that your terminal uses is automatically recognized.                                     | CCP automatically recognizes the cluster address and device configuration also. |
| Bottom-of-form        | Supports skipping to the bottom-of-form (BOF) format, effector on impact printers.                         | Does not support a similar feature.                                             |
| Page width            | If PW=0, then CDCNET does not position the cursor to the beginning of the next line after input or output. | Does not support a similar feature.                                             |

*(Continued)*

**Table I-4. CCP and CDCNET Differences** *(Continued)*

| <b>Feature</b>    | <b>CDCNET Support</b>                                                  | <b>CCP Support</b>                                                                                                                                                                            |
|-------------------|------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Resume batch mode | Uses the /*STAB command to switch from interactive mode to batch mode. | Uses the Remote Batch Facility GO or RESUME command. The GO or RESUME command causes the terminal to return immediately to batch mode if at least one batch input or output device is active. |
| Secure input      | Clear the screen and type, in uppercase only: /*AT (send key).         | Clear the screen and type the network security character (CCP installation parameter).                                                                                                        |



---

|                                                 |      |
|-------------------------------------------------|------|
| The Protocol .....                              | J-2  |
| Code Translation .....                          | J-2  |
| Virtual Line Mode .....                         | J-2  |
| Input Processing .....                          | J-3  |
| Output Positioning .....                        | J-3  |
| Cursor Positioning After Output .....           | J-3  |
| <br>                                            |      |
| The Environment .....                           | J-4  |
| <br>                                            |      |
| Attribute Support .....                         | J-5  |
| Terminal Attributes .....                       | J-5  |
| Using END_PAGE_ACTION .....                     | J-7  |
| Page Length and Widths .....                    | J-8  |
| Connection Attributes .....                     | J-8  |
| INPUT_OUTPUT_MODE (IOM) Differences .....       | J-9  |
| Break Key and Attention Character Actions ..... | J-10 |
| Special Break Sequences .....                   | J-11 |
| Secure Access Sequence .....                    | J-11 |
| Terminate Transparent Input Sequence .....      | J-11 |
| Escape to \$NET Connection Sequence .....       | J-12 |
| Attention Signal .....                          | J-12 |
| <br>                                            |      |
| Program Attention Key Processing .....          | J-13 |





The 3270 Systems Network Architecture (SNA) Communications protocol users can access NOS/VE and NOS applications from an IBM 3270 Information Display System connected to an SNA network. CDCNET supports the 3270 SNA protocol through a terminal interface program. The terminal interface program supporting the protocol communicates with an IBM host passthrough facility called the Host Command Facility (HCF).

Since CDCNET's implementation of the 3270 SNA Communications protocol follows the same conventions as other CDCNET-supported protocols, this appendix supplements the existing CDCNET documentation. The following sections describe only the differences and unique capabilities of the terminal interface program supporting the 3270 SNA protocol. The commands, attributes, and features described in general CDCNET documentation also apply to connections made through a 3270 SNA link, except where noted in this appendix.

| <b>Section</b>                   | <b>Description</b>                                                                                                          |
|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| The Protocol                     | Describes general features of the 3270 SNA Communications protocol as supported by the 3270 SNA terminal interface program. |
| The Environment                  | Illustrates the 3270 SNA interconnection with CDCNET.                                                                       |
| Attribute Support                | Describes the subset of CDCNET terminal and connection attributes that the protocol supports.                               |
| Program Attention Key Processing | Describes the program attention key processing differences between virtual line mode and transparent mode input editing.    |

## The Protocol

The 3270 SNA Communications protocol, as supported by the 3270 SNA terminal interface program (SNA3270\_TIP), provides IBM 3270 Information Display System users access to CDCNET through an SNA network. This section discusses the following areas of difference between the asynchronous protocol and the 3270 SNA protocol, as supported by their respective terminal interface programs.

- Code Translation
- Virtual Line Mode
- Input Processing
- Output Positioning
- Cursor Positioning

### Code Translation

The 3270 SNA protocol, as implemented by the 3270 SNA terminal interface program, translates all output from the 7-bit ASCII code set to the EBCDIC code set, and translates all input from the EBCDIC code to the 7-bit ASCII code set. Some EBCDIC characters are not supported by the 3270 terminals. Those output characters that translate to unsupported EBCDIC characters are, instead, translated to null.

### Virtual Line Mode

The SNA3270\_TIP formats a Virtual Line Mode (VLM) display as a PAGE\_LENGTH number of separate lines. The SNA3270\_TIP uses 3270 field attribute characters to define the VLM lines on a display. The TIP redefines the entire display whenever the display is cleared or the terminal returns to normal editing.

The first character of each line is reserved for the field attribute character. Therefore, the number of characters allowed on a line is usually one character less than the PAGE\_WIDTH setting (that is, 79 out of 80 characters).

## Input Processing

During input, the SNA3270\_TIP treats each display line separately. The TIP does not combine the entry across display lines into a single message forwarded to the CYBER host. Instead, the TIP processes input entered on multiple lines as multiple input messages. For example, you may type several host commands on separate display lines before pressing the ENTER key. The TIP forwards each command as a separate message to the host. The TIP forwards lines from the top to the bottom of the display.

## Output Positioning

The SNA3270\_TIP starts VLM output on the next line following the last cursor position at input. Generally, output follows the last input line in a fashion similar to output on an asynchronous terminal. However, you are free to position the cursor anywhere on the VLM display. The SNA3270\_TIP positions its output to wherever you desire. For example, you may choose to enter all VLM input on the last line, position the cursor on the home line at the top of the display, and then press ENTER. In this case, the TIP begins all output on the second display line even though the commands were entered at the last line.

## Cursor Positioning After Output

The SNA3270\_TIP cursor positioning is similar to that provided by the asynchronous TIP. If the last line of output in a complete message repositions the cursor to the next line, the TIP clears the next line and places the cursor on the second column of the next line. If the last line of output does not reposition the cursor, the TIP defines a new input field on the same line as the last output, clears the new field, and positions the cursor at the beginning of the new field. In effect, the last line of output consists of two fields with a blank character before the first field and between the two fields. Neither blank character can be overwritten. Since the last line of output is usually an input prompt, positioning the cursor in the second field allows you to type on the same line as the prompt.

# The Environment

Figure J-1 illustrates the 3270 SNA environment. The SNA implementation requires a network DI running 3270 SNA gateway software be connected between the SNA network and CDCNET.




Figure J-1. 3270 SNA Environment

## Attribute Support

You can change and display certain terminal and connection attributes from your display station.

### Terminal Attributes

The 3270 SNA Communications protocol, as supported by the SNA3270\_TIP, supports a subset of the terminal attributes supported by the ASYNCTIP. The default settings for the attributes supported by SNA3270\_TIP are displayed in figure J-2.

|                           |           |
|---------------------------|-----------|
| Cancel_Line_Character     | :NUL      |
| End_Page_Action           | :FFS      |
| Hold_Page                 | :ON       |
| Hold_Page_Over            | :ON       |
| Network_Command_Character | :%        |
| Response_Action           | :SEND     |
| Status_Action             | :SEND     |
| Terminal_Model            | :IBM_3270 |

**Figure J-2. 3270 SNA Communications Protocol Terminal Attribute Defaults**

For terminal attributes that the 3270 SNA Communications protocol treats differently from the Asynchronous protocol, see table J-1. The table compares the way the SNA3270\_TIP uses these terminal attributes with the way the ASYNCTIP uses the attributes as described in chapter 3.


**Table J-1. Terminal Attribute Differences**

| <b>Terminal Attribute<br/>(Abbreviation)</b> | <b>Default<br/>Setting</b> | <b>Chapter 3<br/>Comparison</b>                                                                                                                                                        |
|----------------------------------------------|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CANCEL_LINE_<br>CHARACTER (CLC)              | NUL                        | Any character that can be generated by a 3270 terminal except field mark. Field mark is used as a break key character. See Break Key and Attention Character Actions in this appendix. |
| END_PAGE_ACTION<br>(EPA)                     | FFS                        | NONE or Form Feed Sequence. See Using END_PAGE_ACTION, following this table.                                                                                                           |
| HOLD_PAGE (HP)                               | ON                         | Same description applies.                                                                                                                                                              |
| HOLD_PAGE_OVER<br>(HPO)                      | ON                         | Same description applies.                                                                                                                                                              |
| NETWORK_<br>COMMAND_<br>CHARACTER (NCC)      | %                          | Any character that can be generated by a 3270 terminal except field mark. Field mark is used as a break key character. See Break Key and Attention Character Actions in this appendix. |
| RESPONSE_ACTION<br>(RA)                      | SEND                       | Same description applies.                                                                                                                                                              |
| STATUS_ACTION<br>(SA)                        | SEND                       | Same description applies.                                                                                                                                                              |
| TERMINAL_MODEL<br>(TM)                       | IBM_3270                   | Same description applies.                                                                                                                                                              |

## Using END\_PAGE\_ACTION

For Virtual Line mode (VLM) output, the 3270 SNA Communications protocol supports either an END\_PAGE\_ACTION (EPA) of NONE or the Form Feed sequence (FFS). When EPA is set to NONE, the SNA3270\_TIP overwrites the existing display lines with new output. The overwriting begins at the top of the screen and continues to the bottom of the screen as new lines are input or output. The resulting display consists of lines from the previous display page at the bottom of the screen and lines for the current display at the top.

When EPA is set to FFS, the SNA3270\_TIP clears the 3270 screen before writing output to the top of the screen. Under this formatting only the current display page appears on the screen.





## Page Length and Widths

The 3270 SNA Communications protocol supports page lengths of 12, 24, 32, and 43 lines. The SNA3270\_TIP determines the page length for a terminal when the terminal connects to CDCNET. The TIP uses the same page length that the terminal uses to communicate with HCF. You cannot change the page length while connected to CDCNET.

The SNA3270\_TIP supports only a fixed page width of 80 columns because HCF supports only 80-column terminals. The TIP does not support the 3270 alternate screen size for terminals that provide alternate sizes. You cannot change page width.

## Connection Attributes

The 3270 SNA Communications protocol as implemented by SNA3270\_TIP supports a subset of the available connection attributes supported by the ASYNCTIP. The default settings for these attributes are displayed in figure J-3.

|                    |              |
|--------------------|--------------|
| Break_Key_Action   | :0           |
| Input_Block_Size   | :160         |
| Input_Editing_Mode | :NORMAL      |
| Input_Output_Mode  | :UNSOLICITED |

**Figure J-3. 3270 SNA Communications Protocol Connection Attribute Defaults**

The connection attributes are used as described in chapter 4.

## INPUT\_OUTPUT\_MODE (IOM) Differences

The 3270 SNA Communications protocol supports all INPUT\_OUTPUT\_MODES: FULLDUPLEX (F), SOLICITED (S), and UNSOLICITED (U). The SNA3270\_TIP forwards input for each mode to the CYBER host application in the same way as the Asynchronous TIP does. (See INPUT\_OUTPUT\_MODE in chapter 4). For fullduplex or unsolicited mode, the TIP positions the cursor on the next line after input and reenables input until output is available from the CYBER application. For solicited mode, the TIP neither repositions the cursor nor reenables input until the CYBER application solicits more input by completing its output. Once solicited, all input that has been entered is forwarded to the application.

However, because the 3270 terminal operates differently than asynchronous terminals, in most cases the differences between the various INPUT\_OUTPUT\_MODES are lost to the 3270 terminal user.

The 3270 operates only in a block mode. That is, the terminal sends the data for an input message all at once rather than character-by-character as keys are pressed. The terminal sends the complete input message when you press the ENTER key, or press either the PF or PA key. If the 3270\_TIP is sending output to a terminal, input is inhibited and the terminal locks its keyboard to prevent key entry that would be overwritten by output. Thus, you are unable to interrupt output in unsolicited mode, enter input to be forwarded, or enter network commands while unsolicited input is sent.

Should you begin key entry during a pause in output, however, the SNA3270\_TIP halts output for all modes until you complete the input. At that point, all three INPUT\_OUTPUT\_MODES appear essentially the same.

## Break Key and Attention Character Actions

The 3270 SNA Communications protocol recognizes either the Program Access 1 (PA1) key or the field mark character as a break key. To be recognized as a break key, the field mark character must be the first character you enter as input.

When you press the PA1 key or begin input with a field mark character, the SNA3270\_TIP performs the user interrupt specified by the BREAK\_KEY\_ACTION (BKA) connection attribute (see chapter 4).

A 3270 terminal always forwards the PA1 key by itself to the SNA3270\_TIP. Therefore, break key sequences (for example, trusted path sequence) require you to perform a two-step sequence when you use the PA1 key. That is, you must first press the PA1 key, wait for the SNA3270\_TIP to reenable input (the 3270 input inhibited status to clear), and then enter the key sequence as a second input.

On the other hand, the 3270 terminal forwards the field mark character with any other input you enter with it. In this case, you enter the break key sequence as a single input; the field mark followed by the key sequence.

When invoking a break action, a break key sequence should be the only data forwarded in the input field. For example, no data is allowed to follow a fieldmark C in the same field.

### **NOTE**

---

For some terminals, the IBM host resident HCF program does not forward the PA1 key. Instead, when the PA1 key is pressed, the HCF program forwards the Attention signal (see Attention Signal in this appendix). In this case, you cannot use the PA1 key as a break key.

---

The 3270 SNA Communications protocol (or the SNA3270\_TIP) does not support an attention character.

## Special Break Sequences

The SNA3270\_TIP examines the characters following a break key for one of the following special sequences:

- Secure access sequence
- Terminate transparent input sequence
- Escape to \$NET connection sequence

These special character sequences, which cannot be altered, are described in the following sections.

### Secure Access Sequence

The secure access sequence is entered as follows:

1. Press the PA1 key or the field mark character.
2. If you used the PA1 key, wait for input to be reenabled.
3. Press A and then T (lowercase or uppercase), and then clear the remainder of the field.
4. Press the ENTER key.

The SNA3270\_TIP terminates all existing data connections.

### Terminate Transparent Input Sequence

The terminate transparent input sequence is entered as follows:

1. Press the PA1 key or the field mark character.
2. If you used the PA1 key, wait for input to be reenabled.
3. Press X (uppercase or lowercase), and then clear the remainder of the field.
4. Press the ENTER key.

The SNA3270\_TIP terminates transparent input.

## Escape to \$NET Connection Sequence

The escape to \$NET connection sequence is entered as follows:

1. Press the PA1 key or the field mark character.
2. If you used the PA1 key, wait for input to be reenabled.
3. Press AC or C (lowercase or uppercase), and then clear the remainder of the field.
4. Press the ENTER key.

The SAN3270\_TIP changes your working connection to the \$NET connection.

## Attention Signal

The 3270 terminal provides an Attention key that you can use for signaling to the TIP. You can use the Attention key when all other keyboard entry is inhibited. The IBM resident HCF program does not process an Attention signal for terminals connected to CDCNET, but forwards the signal to the SNA3270\_TIP for processing. Thus, you can use the Attention key to signal the TIP for special processing.

IBM applications, in general, treat an Attention signal as a request to enable input. The SNA3270\_TIP also treats the Attention signal as a request to enable input. If the TIP is outputting data in Virtual Line mode (VLM) when it receives an Attention signal, the TIP responds by holding output at the next end of page. The TIP clears the last display line, positions the cursor at the last line, and enables input as though the HOLD\_PAGE attribute were set. In effect, the Attention signal acts as a *one shot* HOLD\_PAGE. If VLM output completes before the next end of page, the TIP ignores the Attention signal and reenables input as part of its normal end-of-output processing.

If the SNA3270\_TIP is outputting data in Transparent mode when it receives an Attention signal, the TIP suspends output and reenables input at the end of the next transparent output block. If the TIP has no output to send when it receives an Attention signal, the TIP sends an unlock keyboard command to the 3270 terminal. Thus, the unlock keyboard command enables input should a poorly behaving transparent application leave input inhibited at the end of output.

## Program Attention Key Processing

The Program Access (PA) and Program Function (PF) keys on the 3270 terminal keyboard are called Program Attention keys. These keys are similar in function to function keys on asynchronous terminals. The SNA3270\_TIP processes these keys differently for Virtual Line mode than for Transparent mode input editing. The tables J-2 and J-3 summarize the actions taken by the SNA3270\_TIP for Program Attention Keys in Virtual Line mode and Transparent mode, respectively. As noted above, the PA1 functions can also be initiated by entering a field mark character.

**Table J-2. Program Attention Key Processing, Virtual Line Mode**

| Key | Action Taken                                                                             |
|-----|------------------------------------------------------------------------------------------|
| PA1 | Break_Key_Action (BKA).                                                                  |
| PA2 | Forwards an <i>empty</i> message to the host application.                                |
| PA3 | Forwards an <i>empty</i> message to the host application.                                |
| PA4 | Forwards an <i>empty</i> message to the host application and reformats the 3270 display. |
| PF  | Treats entry as ENTER key.                                                               |

**Table J-3. Program Attention Key Processing, Transparent Mode**

| Key | Action Taken                                                                    |
|-----|---------------------------------------------------------------------------------|
| PA1 | Break_Key_Action (BKA). If BKA is followed by AX, terminates transparent input. |
| PA2 | Forwards an <i>empty</i> message to the host application.                       |
| PA3 | Forwards an <i>empty</i> message to the host application.                       |
| PA4 | Forwards key input to the host application as part of the transparent message.  |
| PF  | Forwards key input to the host application as part of the transparent message.  |



# Index

---

## A

### Abbreviations

Description 2-3

Accessing a service 1-1

ACTIVATE\_AUTO\_

RECOGNITION command 2-8

APL 3-21

NETWORK\_COMMAND\_

CHARACTER 3-52

Summary 2-6

ACTIVATE\_X\_PERSONAL\_

COMPUTER command 2-11;

H-6

Summary 2-6

APL

Automatic recognition 2-9

Terminal attribute

examples 3-21

Terminal-attribute

examples 3-53

ASCII character set 2-11

ASCII characters 2-5

ASCII coded character set B-1

Asynchronous protocol 2-23

END\_LINE\_

POSITIONING 5-12

End-of-line positioning 5-23

End-of-page positioning 5-27

END\_PARTIAL\_

POSITIONING 5-10

Line speed 1-13

Stop bits 1-13

Asynchronous protocol

support 1-9

Asynchronous terminal interface

program

Description 1-9

Attention character 6-2

ATTENTION\_

CHARACTER 3-5; 6-4

ATTENTION\_CHARACTER\_

ACTION 3-5; 4-6

BREAK key 3-5

BREAK signal 4-8

CHARACTER\_FLOW\_

CONTROL 3-5

Implied X-ON 3-5

NETWORK\_COMMAND\_

CHARACTER 3-52, 53

TRANSPARENT mode 4-11;

5-28

ATTENTION\_CHARACTER\_

ACTION 4-6; 6-4

ATTENTION\_

CHARACTER 3-5

Editing mode 4-6, 8

SNA3270\_TIP J-10

ATTENTION\_CHARACTER\_

ENABLE 4-7

Editing mode 4-7

Attention character support

SNA3270\_TIP J-10

Attention signal J-12

Attribute settings

Data placement 5-3, 5

Flow control 5-4

Interrupts 5-4

Normal input 5-3

Output 5-3

Transparent input 5-3

Attribute support F-1, 4; J-1

Automatic configuration 1-3

Automatic control 5-31

Automatic recognition 1-8, 13,

14

ACTIVATE\_AUTO\_

RECOGNITION

command 2-8

Difficulties 9-2

## B

BACKSPACE\_

CHARACTER 3-7

BACKSPACE\_WINDOW 3-7, 10

Batch console 1-5, 9

BEGIN\_LINE\_

CHARACTER 3-11

Booleans 2-5

Break action

CCITT X.3 parameter 8-10



BREAK key 5-4; 6-2, 4  
 ATTENTION\_  
 CHARACTER 3-5  
 BREAK\_KEY\_ACTION 4-8  
 Interrupting output 4-14  
 SNA3270\_TIP J-10  
 TRANSPARENT input 4-11;  
 5-28  
 BREAK\_KEY\_ACTION 4-8;  
 6-4  
 ATTENTION\_  
 CHARACTER 3-5  
 ATTENTION\_CHARACTER\_  
 ACTION 4-8  
 Editing mode 4-8  
 Interrupt F-13  
 SNA3270\_TIP J-10

## C

CANCEL\_LINE\_  
 CHARACTER 3-12  
 Description F-5  
 Examples B-4; D-5  
 Capabilities F-3  
 CARRIAGE\_RETURN\_  
 DELAY 3-14  
 Combined delays 3-49  
 Delaying data  
 transmission 5-7  
 End-of-line positioning 5-21  
 PAGE\_WIDTH 3-56  
 Partial transmissions 5-12  
 CARRIAGE\_RETURN\_  
 SEQUENCE 3-16  
 Cursor positioning 5-6  
 Data placement 5-5, 18  
 Delaying data  
 transmission 5-7  
 End-of-line positioning 5-21  
 END\_PARTIAL\_  
 POSITIONING 3-37  
 Example 5-20  
 FORM\_FEED\_  
 SEQUENCE 3-43  
 Line folding 3-37, 49  
 CARRIAGE\_RETURN\_  
 SSEQUENCE  
 Partial transmissions 5-12

CCITT X.3 parameter 1 8-10  
 CCITT X.3 parameter 7 8-10  
 CCP D-1; F-12  
 CDC terminals E-9  
 CDC 721 3-19; E-9  
 PAGE\_WIDTH 3-56  
 CDCNET commands 2-2  
 CDCNET features 1-7  
 CDCNET mapping of field  
 number D-15  
 CDCNET mapping of field  
 value D-15  
 CHANGE\_CONNECTION\_  
 ATTRIBUTE 4-1  
 Summary 2-6  
 CHANGE\_CONNECTION\_  
 ATTRIBUTE command 2-13  
 CHANGE\_CONNECTION\_  
 ATTRIBUTES  
 Within an X25 session 8-9  
 X.25 interactive terminal  
 gateway 8-3  
 CHANGE\_TERMINAL\_  
 ATTRIBUTE  
 Summary 2-6  
 CHANGE\_TERMINAL\_  
 ATTRIBUTE command 2-1, 15  
 Suppressing displays 3-61  
 CHANGE\_TERMINAL\_  
 ATTRIBUTE command  
 (CDCNET)  
 APL 3-21  
 Examples 1-5; 3-6  
 Initial access 3-21, 56  
 TERMINAL\_MODEL E-5  
 CHANGE\_TERMINAL\_  
 ATTRIBUTE command  
 (NOS/VE) 1-5; D-2; E-7  
 CHANGE\_WORKING\_  
 CONNECTION command 2-17  
 Summary 2-6  
 Changing an attribute B-2  
 Changing connection  
 attributes 4-1  
 Changing pages 5-26  
 Changing terminal  
 attributes 3-1

**CHARACTER\_FLOW\_**  
**CONTROL** 3-17  
**ATTENTION\_**  
**CHARACTER** 3-5  
**ECHOPLEX** 3-28  
 Flow control 5-30  
**INPUT\_OUTPUT\_FLOW\_**  
**CONTROL\_ENABLE** 4-12  
 Interrupting output 4-14  
 Mapped to X.3 PAD 8-5  
**OUTPUT\_FLOW\_CONTROL\_**  
**ENABLE** 4-15  
**TRANSPARENT** input 4-22,  
 26, 27; 5-28  
**Characters** 2-5  
 ASCII characters 5-17  
 Forwarding **TRANSPARENT**  
 data 5-29  
 Parameter values B-1, 4;  
 D-5, 8  
 Terminal attributes 3-5, 7,  
 11, 12, 29, 35, 52  
**CLR**  
 X.25 gateway command 8-11  
**Code set**  
 Automatic recognition 2-8  
 Terminal switches 2-8  
**CODE\_SET** 3-21  
 Automatic recognition 1-14  
 Initial access 3-58  
**NETWORK\_COMMAND\_**  
**CHARACTER** 3-52, 53  
**Code translation** J-2  
**Coded character set**  
 Automatic recognition 1-14  
**CODE\_SET** 3-21  
 Output 5-16  
 Site-defined 3-21  
 Terminal switches 3-21  
**COMMAND**  
 X.25 gateway command  
 parameter description 8-16  
**Commands**  
 Description 1-7  
 Formatting 2-2; 3-53  
 Spacing 2-3  
**Complete transmissions**  
 Description 5-9  
 Example 5-10  
**Concatenated names** 2-2

**CONNECT** 1-5; E-10, 11  
 Connect timeout 1-8, 14  
 Connecting SNA and  
**CDCNET** J-1  
 Connecting to a remote  
**DTE** 8-8  
 Connecting to a remote  
 service 8-8  
 Connecting to a service 1-3  
 Connecting to **CDCNET** 1-1  
**Connection attribute**  
 Defaults 4-2  
**Connection attributes**  
 Changing 4-1  
 Data transfer mode 8-4  
 Description 1-7  
 Displaying 4-1  
 Gateway command mode 8-2  
 Input editing modes 4-4  
 NOS correspondences D-8, 15  
 X.25 interactive terminal  
 gateway 8-2, 4  
 3270 differences F-10  
 3270 SNA Communications  
 protocol J-8  
**Connection attributes and**  
**protocols** 4-2  
**Connection limit** 1-8; 2-20, 30  
**DEFINE\_LINE**  
 command 1-16  
**Connection name** 2-30  
**Connection status** 2-30  
**Control bytes** D-3; E-8  
**Control characters** B-1  
**CONTROL\_CODE\_**  
**REPLACEMENT** 3-25  
**Corresponding connection**  
**attributes** D-8, 15  
**Corresponding terminal**  
**attributes** D-8, 15  
**CREATE\_CONNECTION**  
 command 2-19, 31; 8-6, 7  
 Disconnect timeout 1-15  
 Initial access 1-3  
 Summary 2-6  
**CREATE\_X25\_CONNECTION**  
 command 8-6, 7  
**CTRL/CHAR/R supervisory**  
**message** D-3

Cursor positioning 5-6, 9, 10

Difficulties 9-6

Normal input 5-8

SNA3270\_TIP J-3

CYBIL procedure calls D-2

## D

Data editing 5-2, 14, 28

Data forwarding

Normal input 5-8

Data link control characters F-8

Data mode

Transparent mode 5-1

Virtual line mode 5-1

Data placement 5-5

Attribute settings 5-3, 5

Data transfer mode

X.25 interactive terminal gateway 8-1

Data type

Normal data 5-1

Transparent data 5-1

DEC computers E-12

DEC VT100 3-43; E-3, 5, 7, 8, 12

FUNCTION\_KEY\_

CLASS 3-44

DEC VT220

FUNCTION\_KEY\_

CLASS 3-44

Dedicated line 1-1, 4, 11

Description 1-12

Disconnecting 1-4

Default connection 1-16

Default connection

attributes 4-2

DEFINE\_LINE command 1-8; 5-30

DEFINE\_PASSTHROUGH\_

TITLE command 7-11

DEFINE\_TERMINAL\_DEVICE command 1-15

DEL characters 4-19; 5-15

Delays

Data placement 5-5, 7

Terminal attributes 3-14, 41, 49

DELETE\_CONNECTION

command 2-22

Summary 2-6

Deleting \$NET connection 2-23

Deleting passthrough

connection 2-22

Desktop/VE H-5

Determining PAGE\_

LENGTH 5-25

Determining PAGE\_

WIDTH 5-22

DI system name 1-2; 2-29

Diagnostic messages C-1

Disconnect timeout 1-8, 15

Disconnecting from

CDCNET 1-4

Disconnecting from service 1-3

DISPLAY\_COMMAND\_

INFORMATION command 2-25

Summary 2-6

DISPLAY\_COMMAND\_LIST

command 2-26

Summary 2-7

DISPLAY\_CONNECTION\_

ATTRIBUTE command 2-27;

4-1

DISPLAY\_CONNECTION\_

ATTRIBUTES command

Summary 2-7

DISPLAY\_CONNECTIONS

command 2-28

Summary 2-7

Suppressing displays 3-61

DISPLAY\_SERVICE

command 2-32

Summary 2-7

Display station 1-5; F-1; J-1

DISPLAY\_TERMINAL\_

ATTRIBUTE command 2-35

Summary 2-7

DISPLAY\_TERMINAL\_

ATTRIBUTES command

Displaying connection

attributes 4-1

Displaying terminal

attributes 3-1

DO command 2-16, 36

Connecting to service 1-3

Summary 2-7

TERMINAL\_MODEL E-2

Duplex switch 3-27

**E**

EBCDIC J-2

ECHO\_ENABLE 4-9

ECHOPLEX 3-27

Mapped to X.3 PAD 8-5

Echoing

ECHO\_ENABLE 4-9

ECHOPLEX 3-27; 5-28

Duplex switch 3-27

ECHO\_ENABLE 3-27; 4-9

Mapped to X.3 PAD 8-5

EDIT\_FILE utility E-3, 5

Edited input 5-2

Editing NORMAL data 5-14

Editing TRANSPARENT  
data 5-28

Effects of changing NOS

terminal classes D-12

EIA flow control 1-8

Automatic flow control 3-17

DEFINE\_LINE

command 1-16

Description 5-4, 30, 32

Empty strings B-4; D-5

END\_LINE\_

CHARACTER 3-29

Backspacing 3-7

BEGIN\_LINE\_

CHARACTER 3-11

Cancelling line 3-12

Complete transmissions 5-9

Forwarding character 4-10,  
14; 5-9

Normal input 5-8

Page turn 3-45

Partial transmissions 4-10;  
5-11

END\_LINE\_

POSITIONING 3-29, 30

CARRIAGE\_RETURN\_

SEQUENCE 3-30

Complete transmissions 5-9

Delays 3-15, 50

END\_LINE\_

CHARACTER 3-29

LINE\_FEED\_

SEQUENCE 3-30

Normal input 5-8

Partial transmissions 5-11

Sequences 3-16, 51

End-of-line positioning 5-3, 16,  
21End-of-page positioning 5-3, 16,  
24

END\_OUTPUT\_

SEQUENCE 3-32

CONTROL\_CODE\_

REPLACEMENT 3-25

Cursor positioning 5-6

Data placement 5-6

Examples 3-32; B-4; D-5

TRANSPARENT input 5-28

END\_PAGE\_ACTION 3-33

Cursor positioning 5-6

Data placement 5-6; F-9

Description F-5

Determining PAGE\_

LENGTH 5-25

End-of-page positioning 5-24

FORM\_FEED\_

SEQUENCE 3-41, 43

HOLD\_PAGE\_OVER 3-47

Order 3-45

PAGE\_LENGTH 3-54

Page turn 3-45, 46

SNA3270\_TIP J-7

END\_PARTIAL\_

CHARACTER 3-35

Backspacing 3-7

END\_PARTIAL\_

POSITIONING 3-35, 37

Forwarding character 4-10,  
17

INPUT\_EDITING\_

MODE 3-35

Normal input 5-8

PARTIAL\_CHARACTER\_

FORWARDING 3-35; 4-17

Partial transmissions 4-10;  
5-11

END\_PARTIAL\_

POSITIONING 3-37

Delays 3-15, 50

Normal input 5-8

Partial transmissions 5-11

- Sequences 3-16
- Entering ASCII characters B-4
- Entering examples B-4
- Entering lists B-5
- Entering sequences B-4
- Error messages C-1
- Escape to \$NET connection
- Escape to \$NET connection sequence 5-2; 6-5, 8
- 3270 SNA
- Communications J-12
- Executing procedures 1-3

**F**

- Features 1-7
- Features not supported F-3
- Field mark character J-10
- Field number/field value pairs D-15
- Flow control 5-30
  - Attribute settings 5-4
  - Difficulties 9-3
- FOLD\_LINE 3-39
  - End-of-line positioning 5-22
  - PAGE\_WIDTH 3-56
  - Sequences 3-16, 51
- FORM\_FEED\_DELAY 3-41
  - Delaying data transmission 5-7
  - End-of-page positioning 5-24
- FORM\_FEED\_SEQUENCE 3-43, 45
  - Cursor positioning 5-6
  - Data placement 5-6, 18
  - Delay 3-41
  - Delaying data transmission 5-7
  - Determining PAGE\_LENGTH 5-25
  - End-of-page positioning 5-24
  - END\_PAGE\_ACTION 3-33
  - HOLD\_PAGE\_OVER 3-47
  - PAGE\_LENGTH 3-54
- Format effectors
  - Delays 3-14, 41, 49
  - Description 5-18
  - Sequences 3-16, 43, 51
- Formatting characters 5-17

- Formatting output 5-2, 3
- Formatting virtual line output 5-17
- Forwarding characters 5-11, 29
- Forwarding complete transmissions 5-9
- Forwarding NORMAL data 5-3, 10
- Forwarding partial transmissions 5-11
- Forwarding TRANSPARENT data 5-3, 29
- Full Screen Editor E-3, 5; F-3
- FULLDUPLEX
- INPUT\_OUTPUT\_MODE 4-13
- FUNCTION\_KEY\_CLASS 3-44
- TRANSPARENT input 5-29

**G**

- Gateway command mode
- X.25 interactive terminal gateway 8-1

**H**

- Hardcopy terminal 1-5
- HASP protocol
  - Line speed 1-13
  - TERMINAL\_MODEL E-6
- HASP protocol support 1-9
- HASP terminal interface program
  - Description 1-9
- HELP 2-26
- HOLD\_PAGE 3-45, 47
  - Action 3-54; F-13
  - Description F-5
  - Determining PAGE\_LENGTH 5-25
  - End-of-page positioning 5-24
  - Order 3-33
  - PAGE\_LENGTH 3-54
- HOLD\_PAGE\_OVER 3-47
  - Description F-5
  - End-of-page positioning 5-24
  - Order 3-33
- Host Command Facility J-1, 10

**I**

IBM computers E-10  
 IBM passthrough service F-2  
 IBM 3270 Information Display System F-1; J-1  
 IFP\$CHANGE\_TERMINAL\_ATTRIBUTE 1-5; D-2; E-7  
 Implied X-ON ATTENTION\_CHARACTER 3-5  
 Informative messages C-1  
 Initiating TRANSPARENT input F-14  
 Input 5-8, 28  
 INPUT\_BLOCK\_SIZE 4-10  
 Input editing mode 2-1  
 INPUT\_EDITING\_MODE 4-11  
   ATTENTION\_CHARACTER\_ENABLE 4-7  
   Backspacing 3-7  
   Description 5-2; F-9  
   FUNCTION\_KEY\_CLASS 3-44  
   INPUT\_OUTPUT\_FLOW\_CONTROL 4-12  
   OUTPUT\_FLOW\_CONTROL\_ENABLE 4-15  
   PARITY 3-59  
   PARITY\_ENABLE 4-16  
   TRANSPARENT\_CHARACTER\_MODE 4-3  
   TRANSPARENT\_FORWARD\_CHARACTER 4-3  
   TRANSPARENT\_LENGTH\_MODE 4-3  
   TRANSPARENT\_MESSAGE\_LENGTH 4-3, 24  
   TRANSPARENT mode 5-28; F-9, 14  
   TRANSPARENT\_PROTOCOL\_MODE 4-3, 25  
   TRANSPARENT\_TERMINATE\_CHARACTER 4-3  
   TRANSPARENT\_TIMEOUT\_INTERVAL 4-3  
   TRANSPARENT\_TIMEOUT\_MODE 4-3

INPUT\_FLOW\_CONTROL\_ENABLE  
   Mapped to X.3 PAD 8-5  
 INPUT\_OUTPUT\_FLOW\_CONTROL\_ENABLE 4-12  
 INPUT\_OUTPUT\_MODE 4-13; F-11  
   SNA3270\_TIP J-9  
 Input processing by 3270 SNA TIP J-3  
 Integer  
   Connection attributes 4-26  
   Terminal attributes 3-54  
 Interrupts 2-5  
   Delays 3-14, 41, 49  
   Description D-5  
   Interrupt actions 4-8  
   Page size 3-54, 56  
   Transmission size 4-10, 24  
 Interactive Facility D-3  
 Interrupt  
   Within an X25 session 8-10  
 Interrupt character 6-1  
 Interrupts F-13  
   Attribute settings 5-4

**K**

Keywords 2-5

**L**

Lear Siegler terminals 3-15  
 Leaving a service 1-1  
 LIM 2-29  
 LINE\_FEED\_DELAY 3-49  
   Combined delays 3-15  
   Complete transmissions 5-10  
   Delaying data transmission 5-7  
   End-of-line positioning 5-21  
   PAGE\_WIDTH 3-56  
 LINE\_FEED\_SEQUENCE 3-51  
   Complete transmissions 5-10  
   CONTROL\_CODE\_REPLACEMENT 3-25  
   Cursor positioning 5-6  
   Data placement 5-6, 18

- Delaying data transmission 5-7
- Delays 3-15
- End-of-line positioning 5-21
- Example 5-20
- LINE\_FEED\_DELAY 3-50
- Line folding 3-39
- Line folding 3-39
- Line speed 1-8
  - Automatic recognition 1-14; 2-8
  - Description 1-13
  - TRANSPARENT\_TIMEOUT\_MODE 4-28
- Line type 1-8, 11
- List
  - Description B-5; D-7
  - Messages C-2
- Lists 2-5
- Local area network 1-6
- Logging off 1-3
- Logging on 1-1
  - Procedure 1-3
- Logical names 1-2

## M

- Macintosh computers E-11
- Manual control 5-32
- Messages 2-5
  - Description C-1
  - Receiving messages 3-61
- Microcomputers 1-4, 5
  - Printer example 3-46, 50
  - Terminals 1-5
- Migrating from CCP D-1, 4; F-1, 12
- Mnemonics B-4; D-3
- Mode 4
  - Automatic recognition of code set I-6
  - CDC 714-30 terminal
    - underline character I-9
  - Connection attributes I-12
  - Interactive interrupt I-5
  - Migrating from CCP I-14
  - Multiple connections I-3
  - Paging I-4
  - Protocol I-1

- Security character
  - sequence I-6
- Terminal attributes I-10
- Terminal interface
  - program I-1
  - Transparent input mode I-8
  - Transparent output mode I-8
  - Virtual line mode I-7
- Mode 4 protocol support 1-10
- Mode 4 terminal interface
  - program
    - Description 1-10
  - Mode 4A terminals I-2
  - Mode 4C terminals I-2
- Multiple connections 1-16; 2-17

## N

- Names 2-5
  - TERMINAL\_MODEL E-2
- NET\_COMMAND connection
- \$NET\_COMMAND-switch
  - sequence
- \$NET connection 1-2; 2-1, 13, 17, 21, 28; 6-2
  - deleting 2-23
  - Disconnect timeout 1-15
  - Initial access 1-16
  - NETWORK\_COMMAND\_CHARACTER 2-2
  - TRANSPARENT data 4-11
- NET connection
- \$NET-switch
  - sequence
  - CCP difference F-14
- Network 1-5
  - Diagram 1-6; F-2
  - Other networks 1-5
- Network Access Method D-3
- Network command
  - character 2-1; 6-2
- NETWORK\_COMMAND\_CHARACTER
  - Command format 2-2; 4-11
  - Description F-6
  - Page turn 3-45
  - User interrupt F-13
- Network failures 9-1
- Network operator
  - Suppressing messages 3-62

Nontransparent IBM Multipoint  
 Bisynchronous  
 Communications F-3  
 Normal data  
   Data type 5-1  
 Normal input  
   Attribute settings 5-3  
 NORMAL mode 2-1; 4-11  
   Connection attributes 4-4, 8  
   Description 5-8; F-11  
   Input 5-8  
   INPUT\_BLOCK\_SIZE 4-10  
   STORE\_BACKSPACE\_  
   CHARACTER 4-18  
   STORE\_NULS\_DELS 4-19  
 NOS D-1; E-2  
 NOS commands D-2; E-8  
 NOS terminal classes D-12;  
   E-2, 6  
 NOS/VE D-1; E-2  
 NOS/VE commands D-2; E-7  
 NUL characters 5-15  
   Delays 3-15, 41, 49; 5-7  
   Editing data 4-19  
   Line folding 3-56; 5-22

**O**

Omitting format effectors 5-18  
 Other networks 1-5  
 Output 4-13; 5-16, 30  
   Attribute settings 5-3  
 Output action 2-31  
 OUTPUT\_FLOW\_CONTROL\_  
   ENABLE 4-15  
   Mapped to X.3 PAD 8-5  
 Output positioning by  
   SNA3270\_TIP J-3

**P**

Packet  
   assembler/disassembler 1-11;  
   G-1  
 Pad recall character  
   CCITT X.3 parameter 8-10  
 Page holding F-13

PAGE\_LENGTH 3-54  
   CCP difference F-13  
   Description F-6  
   Determining PAGE\_  
   LENGTH 5-25  
   End-of-page positioning 5-24  
   END\_PAGE\_ACTION 3-33  
   Page turn 3-45, 47  
   SNA3270\_TIP J-8  
   3270 Information Display  
   Station J-2  
 PAGE\_WIDTH 3-10, 56  
   Backspacing 3-9  
   Delays 3-14, 49  
   Description F-7  
   End-of-line positioning 5-21  
   Line folding 3-39  
   Sequences 3-16, 51  
   SNA3270\_TIP J-8  
   3270 display stations F-3  
 PAR?  
   X.28 command 8-10  
 Parameter position 2-4  
   Position-dependent 2-4  
   Position-independent 2-4  
 Parameter values 2-5  
 Parameters  
   Spacing 2-3  
 Parity 1-8, 16; 3-58  
   Automatic recognition 1-14;  
   2-8  
   CDC 721 3-19  
   DEFINE\_LINE  
   command 1-16  
   TRANSPARENT input 5-28  
   Transparent output 5-30  
 PARITY 3-58  
 PARITY\_ENABLE 4-16  
   Mapped to X.3 PAD 8-5  
 PARTIAL\_CHARACTER\_  
   FORWARDING 4-17  
   Backspacing 3-7  
   END\_PARTIAL\_  
   CHARACTER 3-37; 5-11  
   Partial transmissions 5-11  
 Partial transmission 5-3, 11  
   Description 5-3  
   Example 5-12  
 Partial transmissions 5-11



## Passthrough

- Client 7-1, 4
- Connection attributes 7-9
- Controlling service messages 7-8
- Creating a connection 7-2
- DEFINE\_PASSTHROUGH\_TITLE 7-11
- Defining a title 7-3
- Deleting a connection 7-7
- Entering normal input editing mode 7-5
- IBM Host Command Facility J-1
- Letting a connection time out 7-7
- Managing a connection 7-4
- Putting a connection on hold 7-5
- Server 7-1, 3
- Service difficulties 9-4
- Terminal attributes 7-10
- User 7-1
- Using flow control 7-10
- Using the attention character or BREAK key 7-8
- Passthrough connection deleting 2-22
- Passthrough service 1-9
  - Protocol support 1-9
- Personal computers
  - X.PC terminal interface protocol 1-11
- Plural commands 2-3
- Positioning after output 5-19
- Positioning before output 5-19
- Printer Support Utility 3-61; D-3
- Printers 1-9; F-2
- Procedures
  - Description 1-7
  - Executing 1-3
  - Names E-2
- Program Access key J-10
- Program attention keys J-13
- Programming System Report C-1
- protocol

## Protocol 1-8

- Protocol-defined 1-12
  - Site-defined 1-12
  - Terminal attributes F-4
- Protocol support
  - Description 1-9
- PSR C-1
- Public data network 1-6

## Q

## QUIT

- X.25 gateway command 8-11

## R

- Radix B-4
- Remote DTE
  - Connecting 8-8
- Remote service
  - Connecting 8-8
- REQUEST\_NETWORK\_OPERATOR command 2-37
  - Summary 2-7
- RESPONSE\_ACTION 3-61

## S

## SCL

- See system command language 2-2
- SCL commands D-2
- Secure access sequence 1-2; 6-5
  - SNA3270\_TIP J-11
- Secure input F-12
- Sequences 2-5
  - Description B-4; D-6
  - Terminal attributes 3-16, 32, 43, 51

## Service

- Accessing 1-1
- Availability 2-32
- Connecting to 1-3
- Disconnecting 1-3
- Leaving 1-1
- Name 2-30
- Service failures 9-6

SERVICE\_NAME  
 X.25 gateway command  
 parameter description 8-13

SERVICE\_NAME  
 parameter 8-6

Services

SET\_TERMINAL\_ATTRIBUTE  
 command 1-5

Signing on 1-1

Singular commands 2-3

Site-defined passthrough  
 service 1-9

Site-defined terminal interface  
 program 1-12

Slave devices 1-6

SNA, See 3270 SNA  
 Communications protocol

SNA3270\_TIP  
 Attention signal J-12  
 BREAK key J-10  
 BREAK\_KEY\_ACTION J-10  
 END\_PAGE\_ACTION J-7  
 Escape to \$NET  
 connection J-12  
 INPUT\_OUTPUT\_MODE J-9  
 PAGE\_LENGTH J-8  
 PAGE\_WIDTH J-7  
 Program attention keys J-13  
 Secure access sequence J-11  
 Terminating TRANSPARENT  
 input J-11  
 User interrupts J-10

SOLICITED  
 INPUT\_OUTPUT\_  
 MODE 4-13

Spacing 2-3

Special break sequences 6-5

Special characters 2-2, 19

Special sequences 6-1

Status action 2-30

STATUS\_ACTION 3-62  
 TRANSPARENT input 5-28

Stop bits 1-13

STORE\_BACKSPACE\_  
 CHARACTER 4-18  
 Backspacing 3-7  
 Echoing 3-28

STORE\_NULS\_DELS 4-19

Strings 2-2; D-5

SUN\_160  
 FUNCTION\_KEY\_  
 CLASS 3-44

Switched line 1-1, 4, 9, 11

System command language 2-2

## T

TDP, See Terminal definition  
 procedure

Terminal  
 Definition 1-5  
 Service characteristics 1-5

Terminal attribute  
 Defaults 3-2

Terminal-attribute settings for  
 selected terminals E-8

Terminal attribute settings via  
 TERMINAL\_MODEL E-2

Terminal attributes  
 CCP correspondences D-8, 15  
 Changing 3-1  
 Description 1-7  
 Displaying 3-1  
 Input editing modes 3-3  
 3270 differences F-5  
 3270 SNA Communications  
 differences J-5

Terminal definition  
 commands D-3

Terminal definition  
 procedure 1-8; 2-36

DEFINE\_LINE  
 command 1-15

Terminal interface commands  
 ACTIVATE\_AUTO\_  
 RECOGNITION 2-8  
 ACTIVATE\_X\_PERSONAL\_  
 COMPUTER 2-11  
 CHANGE\_CONNECTION\_  
 ATTRIBUTE 2-13  
 CHANGE\_TERMINAL\_  
 ATTRIBUTE 2-15  
 CHANGE\_WORKING\_  
 CONNECTION 2-17  
 CREATE\_  
 CONNECTION 2-19  
 DELETE\_  
 CONNECTION 2-22

- DISPLAY\_COMMAND\_INFORMATION 2-25
- DISPLAY\_COMMAND\_LIST 2-26
- DISPLAY\_CONNECTION\_ATTRIBUTE 2-27
- DISPLAY\_CONNECTIONS 2-28
- DISPLAY\_SERVICE 2-32
- DISPLAY\_TERMINAL\_ATTRIBUTE 2-35
- REQUEST\_NETWORK\_OPERATOR 2-37
- Terminal interface program 1-8
  - Description 1-9
  - Protocol 1-8
- TERMINAL\_MODEL 3-63
  - Description F-7
  - Names E-2
- Terminal name 1-2; 2-29
- Terminal user procedure 1-8; 2-36
  - DEFINE\_LINE command 1-15
- Terminals
  - Switches 3-21, 58
- Terminating TRANSPARENT input F-14
  - SNA3270\_TIP J-11
- Timeout 1-8, 15; 4-28; 5-29
- TIPs, See Terminal Interface Programs
- TRANSPARENT\_CHARACTER\_MODE 4-20
  - Description F-11
- FUNCTION\_KEY\_CLASS 3-44
- INPUT\_EDITING\_MODE 4-3, 11
- TRANSPARENT input 5-29
- Transparent data
  - Data type 5-1
- TRANSPARENT data 4-11, 20
  - Connection attributes 4-4, 8
  - Description F-9
  - Editing 5-28
  - Forwarding 5-29
  - Input 5-28; D-9, 16
  - INPUT\_BLOCK\_SIZE 4-10
- TRANSPARENT\_FORWARD\_CHARACTER 4-22
  - INPUT\_EDITING\_MODE 4-3
  - Mapped to X.3 PAD 8-5
- TRANSPARENT\_CHARACTER\_MODE 4-20
- TRANSPARENT input 5-29
- TRANSPARENT\_FORWARDING\_CHARACTER
  - TRANSPARENT\_TERMINATE\_CHARACTER 4-26
- Transparent IBM Multipoint Bisynchronous Communications F-3
- Transparent input
  - Attribute settings 5-3
  - Difficulties 9-3
- TRANSPARENT input editing mode escape sequence 6-7
- TRANSPARENT\_LENGTH\_MODE 4-23
  - INPUT\_EDITING\_MODE 4-3
  - TRANSPARENT input 5-29
- TRANSPARENT\_MESSAGE\_LENGTH 4-23
- TRANSPARENT\_MESSAGE\_LENGTH 4-24
  - INPUT\_EDITING\_MODE 4-3
  - TRANSPARENT input 5-29
- TRANSPARENT\_LENGTH\_MODE 4-23
- Transparent mode
  - Data mode 5-1
  - Description 5-2
- TRANSPARENT mode 2-1
- TRANSPARENT\_PROTOCOL\_MODE 4-25
  - INPUT\_EDITING\_MODE 4-3
- TRANSPARENT\_TERMINATE\_CHARACTER 4-26
  - Examples B-5; D-7
  - INPUT\_EDITING\_MODE 4-3

TRANSPARENT\_  
 CHARACTER\_MODE 4-20  
 TRANSPARENT input 5-29  
 TRANSPARENT\_TIMEOUT\_  
 INTERVAL 4-27  
 INPUT\_EDITING\_  
 MODE 4-3  
 Mapped to X.3 PAD 8-5  
 TRANSPARENT\_TIMEOUT\_  
 MODE 4-29  
 INPUT\_EDITING\_  
 MODE 4-3  
 Mapped to X.3 PAD 8-5  
 TRANSPARENT input 5-29  
 TRANSPARENT\_TIMEOUT\_  
 INTERVAL 4-27  
 TRMDEF command D-3, 4, 8;  
 E-8  
 TUP, See Terminal user  
 procedure  
 Type-ahead 4-13

## U

Underline character 2-2  
 Understanding configuration  
 options 1-8  
 Unit Record Interface protocol  
 support 1-10  
 Unit Record Interface terminal  
 interface program  
 Description 1-10  
 Unit separator 5-17  
 UNSOLICITED  
 INPUT\_OUTPUT\_  
 MODE 4-13  
 User-defined passthrough  
 service 1-9  
 User interrupt  
 Description 5-4  
 NETWORK\_COMMAND\_  
 CHARACTER 3-52  
 User interrupts 6-1  
 Example 6-3  
 Using the BREAK key or  
 attention character 6-2  
 Using the network command  
 character 6-2

3270 SNA Communications  
 protocol J-10  
 Using CDCNET attributes with  
 the TRMDEF command D-4  
 Using CDCNET capabilities 1-4  
 Using CDCNET default network  
 command character D-4  
 Using certain ASCII  
 characters 5-18  
 Using examples B-4  
 Using FOLD\_LINE 5-22  
 Using format effectors 5-18  
 Using NOS/VE and NOS  
 commands D-2  
 Using other networks 1-6  
 Using sequences 5-6  
 Using slave devices 1-6  
 Using terminal definition  
 mnemonics with the TRMDEF  
 command D-4

## V

Validation 1-3  
 Video-display terminal 1-5  
 Virtual line mode  
 Data mode 5-1  
 Description 5-2  
 3270 Information Display  
 Station J-2

## W

Working connection 2-17, 19,  
 22, 28, 30  
 Connection limit 1-16  
 Workstation 1-5

## X

X-ON/X-OFF flow control  
 CHARACTER\_FLOW\_  
 CONTROL 3-17  
 Description 5-4, 30, 31  
 Editing data 5-31  
 TRANSPARENT input 4-25,  
 26

X.PC protocol H-1  
 Automatic recognition 2-10  
 Connection attributes H-12  
 Driver H-5  
 Microcomputer  
 connection H-3  
 Switching from asynchronous  
 protocol 2-11; H-6  
 Terminal attributes H-7  
 Terminal interface  
 program H-5  
 X.PC protocol support 1-11  
 X.PC terminal interface  
 program  
 Description 1-11  
 X.25  
 Asynchronous protocol G-1  
 Asynchronous terminal  
 interface program G-3  
 Automatic recognition G-4  
 BREAK key and attention key  
 actions G-4  
 Connection attributes G-5  
 Link G-1  
 PAD parameter settings G-8  
 Public data network G-3  
 Terminal attributes G-6  
 User interrupt function G-4  
 X.25 asynchronous protocol 2-11  
 X.25 Asynchronous protocol  
 support 1-11  
 X.25 Asynchronous terminal  
 interface program  
 Description 1-11  
 X.25 environment G-2  
 X.25 Interactive terminal  
 gateway modes 8-1  
 X.25 PAD 1-11  
 X.25 protocol 2-23  
 X.25 service 8-3  
 X.25 session 8-3  
 X.28 commands 8-6  
 XMODEM 3-20

## Y

Your display station F-1, 2

## Z

Zenith computers E-13

## 2

255X communication device D-1

## 3


3270 Binary Synchronous  
 Communications protocol  
 Description F-1  
 Line speed 1-13  
 TERMINAL\_MODEL E-6  
 3270 Binary Synchronous  
 Communications protocol  
 support 1-11  
 3270 Binary Synchronous  
 Communications terminal  
 interface program 1-11  
 3270 Information Display  
 Station  
 PAGE\_LENGTH J-2  
 Virtual line mode J-2  
 3270 protocol  
 Difficulties 9-8  
 3270 SNA Communications  
 protocol  
 Connection attributes J-8  
 Description J-2  
 Terminal attributes J-5  
 3270 SNA Communications  
 protocol support 1-12  
 3270 SNA Communications  
 terminal interface program  
 Description 1-12  
 3270 SNA environment J-4  
 3270 SNA gateway software J-4  
 3270 SNA TIP J-2  
 Cursor positioning J-3  
 Input processing J-3  
 Output positioning J-3  
 Terminal attributes J-5

old on dotted line;  
es with tape only.



FOI

NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES



**BUSINESS REPLY MAIL**  
First-Class Mail Permit No. 8241 Minneapolis, MN

POSTAGE WILL BE PAID BY ADDRESSEE

**CONTROL DATA**  
Technical Publications  
ARH219  
4201 N. Lexington Avenue  
Arden Hills, MN 55126-9983



We would like your comments on this manual to help us improve it. Please take a few minutes to fill out this form.

Who are you?

- Manager
- Systems analyst or programmer
- Applications programmer
- Operator
- Other \_\_\_\_\_

How do you use this manual?

- As an overview
- To learn the product or system
- For comprehensive reference
- For quick look-up
- Other \_\_\_\_\_

What programming languages do you use? \_\_\_\_\_

How do you like this manual? Answer the questions that apply.

- | Yes                      | Somewhat                 | No                       |                                                                                                         |
|--------------------------|--------------------------|--------------------------|---------------------------------------------------------------------------------------------------------|
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Does it tell you what you need to know about the topic?                                                 |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Is the technical information accurate?                                                                  |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Is it easy to understand?                                                                               |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Is the order of topics logical?                                                                         |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Can you easily find what you want?                                                                      |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Are there enough examples?                                                                              |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Are the examples helpful? ( <input type="checkbox"/> Too simple? <input type="checkbox"/> Too complex?) |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Do the illustrations help you?                                                                          |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Is the manual easy to read (print size, page layout, and so on)?                                        |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Do you use this manual frequently?                                                                      |

Comments? If applicable, note page and paragraph. Use other side if needed. \_\_\_\_\_

Check here if you want a reply:  \_\_\_\_\_

\_\_\_\_\_  
Name

\_\_\_\_\_  
Company

\_\_\_\_\_  
Address

\_\_\_\_\_  
Date

\_\_\_\_\_  
Phone

Please send program listing and output if applicable to your comment.

# Quick Reference Index

---

## CDCNET Commands

|                                             |      |
|---------------------------------------------|------|
| ACTIVATE_AUTO_RECOGNITION (ACTAR) .....     | 2-8  |
| ACTIVATE_X_PERSONAL_COMPUTER (ACTXPC) ..... | 2-11 |
| CHANGE_CONNECTION_ATTRIBUTE (CHACA) .....   | 2-13 |
| CHANGE_TERMINAL_ATTRIBUTE (CHATA) .....     | 2-15 |
| CHANGE_WORKING_CONNECTION (CHAWC) .....     | 2-17 |
| CREATE_CONNECTION (CREC) .....              | 2-19 |
| DEFINE_PASSTHROUGH_TITLE (DEFPT) .....      | 7-11 |
| DELETE_CONNECTION (DELC) .....              | 2-22 |
| DISPLAY_COMMAND_INFORMATION (DISCI) .....   | 2-25 |
| DISPLAY_COMMAND_LIST (DISCL) .....          | 2-26 |
| DISPLAY_CONNECTION_ATTRIBUTE (DISCA) .....  | 2-27 |
| DISPLAY_CONNECTIONS (DISC) .....            | 2-28 |
| DISPLAY_SERVICE (DISS) .....                | 2-32 |
| DISPLAY_TERMINAL_ATTRIBUTE (DISTA) .....    | 2-35 |
| DO .....                                    | 2-36 |
| REQUEST_NETWORK_OPERATOR (REQNO) .....      | 2-37 |

## Terminal Attributes

|                                      |      |
|--------------------------------------|------|
| ATTENTION_CHARACTER (AC) .....       | 3-5  |
| BACKSPACE_CHARACTER (BC) .....       | 3-7  |
| BACKSPACE_WINDOW (BW) .....          | 3-10 |
| BEGIN_LINE_CHARACTER (BLC) .....     | 3-11 |
| CANCEL_LINE_CHARACTER (CLC) .....    | 3-12 |
| CARRIAGE_RETURN_DELAY (CRD) .....    | 3-14 |
| CARRIAGE_RETURN_SEQUENCE (CRS) ..... | 3-16 |
| CHARACTER_FLOW_CONTROL (CFC) .....   | 3-17 |
| CODE_SET (CS) .....                  | 3-21 |
| CONTROL_CODE_REPLACEMENT (CCR) ..... | 3-25 |
| ECHOPLEX (E) .....                   | 3-27 |
| END_LINE_CHARACTER (ELC) .....       | 3-29 |
| END_LINE_POSITIONING (ELP) .....     | 3-30 |
| END_OUTPUT_SEQUENCE (EOS) .....      | 3-32 |
| END_PAGE_ACTION (EPA) .....          | 3-33 |
| END_PARTIAL_CHARACTER (EPC) .....    | 3-35 |
| END_PARTIAL_POSITIONING (EPP) .....  | 3-37 |
| FOLD_LINE (FL) .....                 | 3-39 |
| FORM_FEED_DELAY (FFD) .....          | 3-41 |
| FORM_FEED_SEQUENCE (FFS) .....       | 3-43 |
| FUNCTION_KEY_CLASS (FKS) .....       | 3-44 |
| HOLD_PAGE (HP) .....                 | 3-45 |
| HOLD_PAGE_OVER (HPO) .....           | 3-47 |
| LINE_FEED_DELAY (LFD) .....          | 3-49 |
| LINE_FEED_SEQUENCE (LFS) .....       | 3-51 |



# Quick Reference Index

---

## Terminal Attributes (Continued)

|                                       |      |
|---------------------------------------|------|
| NETWORK_COMMAND_CHARACTER (NCC) ..... | 3-52 |
| PAGE_LENGTH (PL) .....                | 3-54 |
| PAGE_WIDTH (PW) .....                 | 3-56 |
| PARITY (P) .....                      | 3-58 |
| RESPONSE_ACTION (RA) .....            | 3-61 |
| STATUS_ACTION (SA) .....              | 3-62 |
| TERMINAL_MODEL (TM) .....             | 3-63 |

## Connection Attributes

|                                             |      |
|---------------------------------------------|------|
| ATTENTION_CHARACTER_ACTION (ACA) .....      | 4-6  |
| ATTENTION_CHARACTER_ENABLE (ACE) .....      | 4-7  |
| BREAK_KEY_ACTION (BKA) .....                | 4-8  |
| ECHO_ENABLE (EE) .....                      | 4-9  |
| INPUT_BLOCK_SIZE (IBS) .....                | 4-10 |
| INPUT_EDITING_MODE (IEM) .....              | 4-11 |
| INPUT_FLOW_CONTROL_ENABLE .....             | 4-12 |
| INPUT_OUTPUT_MODE (IOM) .....               | 4-13 |
| OUTPUT_FLOW_CONTROL_ENABLE (OFCE) .....     | 4-15 |
| PARITY_ENABLE (PE) .....                    | 4-16 |
| PARTIAL_CHARACTER_FORWARDING (PCF) .....    | 4-17 |
| STORE_BACKSPACE_CHARACTER (SBC) .....       | 4-18 |
| STORE_NULS_DELS (SND) .....                 | 4-19 |
| TRANSPARENT_CHARACTER_MODE (TCM) .....      | 4-20 |
| TRANSPARENT_FORWARD_CHARACTER (TFC) .....   | 4-22 |
| TRANSPARENT_LENGTH_MODE (TLM) .....         | 4-23 |
| TRANSPARENT_MESSAGE_LENGTH (TML) .....      | 4-24 |
| TRANSPARENT_PROTOCOL_MODE (TPM) .....       | 4-25 |
| TRANSPARENT_TERMINATE_CHARACTER (TTC) ..... | 4-26 |
| TRANSPARENT_TIMEOUT_INTERVAL (TTM) .....    | 4-27 |
| TRANSPARENT_TIMEOUT_MODE (TTM) .....        | 4-29 |



