

NSCSBS

SE640-AZ-MMM-010

**MAINTENANCE MANUAL
FOR
INPUT/OUTPUT CONSOLE
0A-7984(V)/UYK**

- CHAPTER 1 - GENERAL INFORMATION**
- CHAPTER 2 - OPERATION**
- CHAPTER 3 - FUNCTIONAL DESCRIPTION**
- CHAPTER 4 - SCHEDULED MAINTENANCE**
- CHAPTER 5 - TROUBLESHOOTING**
- CHAPTER 6 - CORRECTIVE MAINTENANCE**
- CHAPTER 7 - PARTS LIST**
- CHAPTER 8 - INSTALLATION**



THIS PUBLICATION IS REQUIRED FOR OFFICIAL USE OR FOR ADMINISTRATIVE OR OPERATIONAL PURPOSES. DISTRIBUTION IS LIMITED TO U.S. GOVERNMENT AGENCIES ONLY. OTHER REQUESTS FOR THIS DOCUMENT MUST BE REFERRED TO: COMMANDING OFFICER, NAVAL SHIP WEAPON SYSTEMS ENGINEERING STATION CODE 5H00, PORT HUENEME, CA 93043-5007.

THIS PUBLICATION SUPERSEDES NAVSEA 0967-LP-307-3010 THROUGH -3030, -3050, -3070 THROUGH -3090 DATED OCTOBER 1970 AND NAVSEA 0967-LP-575-3010 DATED JULY 1975.

PUBLISHED BY DIRECTION OF COMMANDER, NAVAL SEA SYSTEMS COMMAND

FOR OFFICIAL USE ONLY

1 OCTOBER 1985

LIST OF EFFECTIVE PAGES

Insert latest pages; dispose of superseded pages in accordance with applicable regulations.

NOTE: On a changed page, the portion of the text affected by the latest change is indicated by a vertical line or other change symbol in the outer margin of the page.

Total number of pages in this volume is 570, consisting of the following:

Page No.	#Change in effect
Title.	0
A thru C	0
Change Record.	0
Change Record-2 blank.	0
Foreword-1	0
Foreword-2 blank	0
i thru xxi	0
xxii blank	0
1-1 thru 1-11.	0
1-12 blank	0
2-1 thru 2-21.	0
2-22 blank	0
3-1 thru 3-55.	0
3-56 blank	0
3-57	0
3-58 blank	0
3-59	0
3-60 blank	0
3-61	0
3-62 blank	0
3-63	0
3-64 blank	0
3-65 thru 3-99	0
3-100 blank.	0
3-101.	0
3-102 blank.	0
3-103 thru 3-109	0
3-110 blank.	0
3-111 thru 3-127	0
3-128 blank.	0
3-129 thru 3-171	0
3-172 blank.	0
3-173.	0

LIST OF EFFECTIVE PAGES (Contd)

Page No.	#Change in effect
3-174 blank.	0
3-175 thru 3-189	0
3-190 blank.	0
4-1 and 4-2.	0
5-1 thru 5-3	0
5-4 blank.	0
5-5.	0
5-6 blank.	0
5-7.	0
5-8 blank.	0
5-9.	0
5-10 blank	0
5-11	0
5-12 blank	0
5-13	0
5-14 blank	0
5-15	0
5-16 blank	0
5-17	0
5-18 blank	0
5-19	0
5-20 blank	0
5-21	0
5-22 blank	0
5-23	0
5-24 blank	0
5-25	0
5-26 blank	0
5-27	0
5-28 blank	0
5-29	0
5-30 blank	0
5-31	0
5-32 blank	0
5-33	0
5-34 blank	0
5-35	0
5-36 blank	0
5-37	0
5-38 blank	0
5-39	0
5-40 blank	0
5-41	0
5-42 blank	0
5-43 thru 5-49	0

LIST OF EFFECTIVE PAGES (Contd)

Page No.	#Change in effect
5-50 blank	0
5-51	0
5-52 blank	0
5-53 thru 5-59	0
5-60 blank	0
6-1 thru 6-83.	0
6-84 blank	0
7-1 thru 7-131	0
7-132 blank.	0
7-133 thru 7-154	0
8-1 thru 8-3	0
8-4 blank.	0
8-5.	0
8-6 blank.	0
8-7 thru 8-16.	0

FOREWORD

This technical manual describes the operation and maintenance for Input/Output Console OA-7984(V)/UYK (I/O Console). The publication is for the training of, and use by, personnel responsible for the operation and maintenance of the I/O Console. This maintenance manual supersedes NAVSEA 0967-LP-307-3010 through -3030, -3050, -3070 through -3090 dated October 1970 and NAVSEA 0967-LP-575-3010 dated July 1975 and all changes thereto.

The chapters are as follows:

- Chapter 1 - General Information
- Chapter 2 - Operation
- Chapter 3 - Functional Description
- Chapter 4 - Scheduled Maintenance
- Chapter 5 - Troubleshooting
- Chapter 6 - Corrective Maintenance
- Chapter 7 - Parts List
- Chapter 8 - Installation

Foldout illustrations and page-sized illustrations are placed as near as possible to the point at which they are first referenced in the text. A foldout illustration is identified in the text by the abbreviation FO.

Ships, training activities, supply points, depots, Naval Shipyards and Supervisors of Shipbuilding are requested to arrange for the maximum practical use and evaluation of NAVSEA technical manuals. All errors, omissions, discrepancies, and suggestions for improvements to NAVSEA technical manuals shall be reported to the Commanding Officer, Naval Ship Weapon Systems Engineering Station (Code 5H00), Port Hueneme, CA 93043-5007 on NAVSEA Technical Manual Deficiency/Evaluation Report, Form NAVSEA 9086/10. To facilitate such reporting, three copies of Form 9086/10 are included at the end of each technical manual. All feedback comments shall be thoroughly investigated and originators will be advised of action resulting therefrom. Extra copies of Form NAVSEA 9086/10 may be requisitioned from the Naval Publications and Forms Center (NPFC), Philadelphia, PA 19120-5099.

TABLE OF CONTENTS

Chapter/Paragraph	Page
1	General Information 1-1
1-1	Introduction 1-1
1-2	General Overview 1-1
1-3	General Description. 1-1
1-4	Equipment Description. 1-1
1-5	Major Assemblies 1-1
1-6	Physical Description 1-1
1-8	Unit Description 1-1
1-9	Physical Characteristics and Operational Parameters 1-1
1-10	Keyboard/Printer 1-2
1-11	Paper Tape Reader. 1-2
1-12	Paper Tape Punch 1-2
1-13	Power Supplies 1-2
1-14	Logic Chassis. 1-2
1-15	Equipment Supplied 1-2
1-16	Equipment and Publications Required But Not Supplied 1-5
1-17	Field And Factory Changes. 1-5
1-18	Tape Bin 1-5
2	Operation. 2-1
2-1	Introduction 2-1
2-2	General Description. 2-1
2-3	Switches and Indicators. 2-1
2-4	Control Panel. 2-1
2-5	Power Panel. 2-1
2-6	Keyboard/Printer 2-1
2-7	Input/Output Devices 2-1
2-8	Keyboard 2-1
2-9	Paper Tape Reader. 2-1
2-10	Paper Tape Punch 2-1
2-11	Printer. 2-4
2-12	Operating Procedures 2-4
2-13	General. 2-4
2-14	Operator Turn-On Procedures. 2-4
2-15	Perforator Tape Loading. 2-4
2-16	Loading Tape 2-4
2-17	Loading Tape of Different Widths 2-5
2-18	Tape Reader Loading. 2-11
2-19	Tape Rewinding 2-11
2-20	Console Turnoff Procedure. 2-14
2-21	Operational Modes. 2-14

TABLE OF CONTENTS (Contd)

Chapter/Paragraph		Page
2-22	On-Line Mode	2-14
2-24	Off-Line Mode.	2-18
2-25	Print From Tape.	2-19
2-26	Punch From Tape.	2-19
2-27	Print and Punch From Tape.	2-20
2-28	Print From Keyboard.	2-20
2-29	Print and Punch From Keyboard.	2-21
2-30	Emergency Operation.	2-21
3	Functional Description	3-1
3-1	Overall Functional Description	3-1
3-2	Introduction	3-1
3-4	Modes of Operation	3-1
3-6	On-Line Mode	3-1
3-8	Keyboard/Printer	3-3
3-9	Paper Tape Reader.	3-3
3-10	Paper Tape Punch	3-3
3-11	Off-Line Mode.	3-3
3-12	Keyboard-to-Printer.	3-3
3-13	Keyboard-to-Printer and Paper Tape Punch	3-4
3-14	Paper Tape Reader-to-Paper Tape Punch.	3-4
3-15	Paper Tape Reader-to-Printer	3-5
3-16	Paper Tape Reader-to-Paper Tape Punch and Printer.	3-6
3-17	Keyboard/Printer Operation	3-7
3-18	Model 35 Keyboard/Printer.	3-7
3-20	Keyboard	3-7
3-22	Printing Unit.	3-9
3-25	Motor Unit (LMU-3)	3-9
3-26	Electrical Service Unit.	3-9
3-27	Enclosure.	3-9
3-28	Tape Reader Operation.	3-9
3-29	Tape Read System	3-9
3-32	Tape Drive System.	3-12
3-33	Pinch Roller Circuit	3-12
3-34	Brake Circuit.	3-12
3-35	Drive Motor.	3-12
3-36	Tape Stepping.	3-12
3-37	Tape Punch Operation	3-12
3-41	Detailed Functional Description.	3-13
3-42	Symbology.	3-13
3-43	Internal Logic Levels.	3-13
3-44	AND Logic Function	3-13
3-45	Detailed Analysis.	3-13
3-46	OR Logic Function.	3-15
3-47	Detailed Analysis.	3-15
3-48	AND/OR Combination Logic Function.	3-17
3-49	Flip-Flop.	3-17

TABLE OF CONTENTS (Contd)

Chapter/Paragraph		Page
3-51	Component Notation	3-19
3-52	Printed Circuit Modules.	3-19
3-54	Printed Circuit Card Location.	3-20
3-55	Functional Description of Printed Circuit Cards.	3-20
3-57	Logic Description (On-Line Mode)	3-21
3-58	Word Formats	3-21
3-59	Input and Output Data Words.	3-21
3-61	External Function Words.	3-22
3-62	Control Logic, General.	3-22
3-63	Control Logic, Detailed	3-23
3-64	I/O Console Control Enables.	3-23
3-65	Clear OFF-LINE and Disable External Function Request	3-23
3-66	Printer Operation, General	3-54
3-67	Printer Operation, Detailed.	3-54
3-68	External Function Acknowledge Enable	3-54
3-69	External Function Word Conversion and Translation.	3-54
3-70	SET PRINT F/F and Start Printer Motor.	3-54
3-71	Set PRINTER READY F/F After 0.5 Second Delay	3-65
3-72	Clear Output Register.	3-65
3-73	Generate Output Data Request	3-65
3-74	Set ENABLE PRINT F/F, Remove ODR, and Gate Data to Output Register.	3-65
3-75	Enable Serializer.	3-66
3-76	Initiate Serializer, Clear SERIALIZER READY F/F and Disable EFR.	3-66
3-77	Basic Serializer Operations.	3-66
3-78	Generation of Data to Printer Signals.	3-68
3-79	Start.	3-68
3-80	Bit 0.	3-68
3-81	Bit 1.	3-68
3-82	Bit 2.	3-68
3-83	Bit 3.	3-68
3-84	Bit 4.	3-69
3-85	Bit 5.	3-69
3-86	Bit 6.	3-69
3-87	Parity Pulse	3-69
3-88	Stop Mark.	3-69
3-89	Set SERIALIZER RDY F/F and Clear ENABLE PRINT F/F.	3-70
3-90	Clear Output Register.	3-70
3-91	Generate ODR	3-70
3-92	Automatic Termination of ON-LINE Printer Operation.	3-70
3-93	Manual Termination of ON-LINE Printer Operation.	3-72

TABLE OF CONTENTS (Contd)

Chapter/Paragraph		Page
3-94	Depressing the PRINT CLEAR Pushbutton.	3-72
3-95	Depressing the MASTER CLEAR Pushbutton	3-72
3-96	Keyboard Operation, General.	3-72
3-97	Mode 1, Keyboard Entry Via Interrupt	3-72
3-98	Mode 2, Keyboard Entry Via the Computer.	3-72
3-99	Keyboard Operation, Detailed	3-73
3-100	External Function Acknowledge Enable	3-73
3-101	External Function Word Conversion and Translation.	3-73
3-102	Light KEYBOARD and Start Printer Motor	3-73
3-103	Clear Output Register.	3-73
3-104	Disable Output Data Request.	3-73
3-105	Keyboard Coding.	3-74
3-106	Clear KEYBOARD DATA F/F.	3-74
3-107	Enable Serializer.	3-74
3-108	Initiate Serializer and Clear SERIALIZER READY F/F.	3-74
3-109	Disable External Function Requests	3-74
3-110	Set KEYBOARD INPUT READY F/F	3-74
3-111	Basic Serializer Operations.	3-74
3-112	Generation of Keyboard Gating.	3-75
3-113	Serial Transfer of ASCII Code to Input Register	3-76
3-114	Set KEYBOARD DATA F/F.	3-76
3-115	Set SERIALIZER READY F/F	3-76
3-116	Enable EF Request Generator.	3-76
3-117	Set KEYBOARD REQ ENABLE F/F.	3-76
3-118	Generate Input Data Request or Interrupt	3-76
3-120	Clear KEYBOARD INPUT READY F/F, KEYBOARD REQ ENABLE F/F, and INTERRUPT F/F.	3-82
3-121	Drop Input Data Request or Interrupt	3-82
3-122	Clear Input Register	3-82
3-123	Clear Output Register.	3-83
3-124	Serial Data Transmission to Printer During Keyboard Operation	3-83
3-126	Data to Printer Signal Generation.	3-83
3-127	Automatic Termination of On-Line Keyboard Operation.	3-84
3-128	Manual Termination of On-Line Keyboard Operation.	3-85
3-129	Depressing the Keyboard Clear Pushbutton	3-85
3-130	Depressing the MASTER CLEAR Pushbutton	3-85
3-131	Tape Reader Operation, General	3-85
3-132	Tape Reader Operation, Detailed.	3-86
3-133	External Function Acknowledge Enable	3-86
3-134	External Function Word Conversion and Translation.	3-86
3-135	Light READ Indicator and Set START READ F/F.	3-86

TABLE OF CONTENTS (Contd)

Chapter/Paragraph		Page
3-136	Disable Keyboard Mode and Clear INTERRUPT F/F, KEYBOARD REQ ENABLE F/F, and KEYBOARD INPUT READY F/F.	3-87
3-137	Start Reader Motor	3-87
3-138	Set READ READY F/F	3-87
3-139	Clear Input Register and Advance Tape Until Sprocket Pulse is Detected	3-87
3-140	Stop Tape and Gate Data to Input Register.	3-87
3-141	Generate Input Register.	3-88
3-142	Input Acknowledge and Clear READER INPUT REQUEST ENABLE	3-88
3-143	Clear Input Register and Drop INPUT REQ.	3-88
3-144	Set READER INPUT REQUEST ENABLE.	3-88
3-145	Automatic Termination of ON-LINE Reader Operation.	3-89
3-146	Manual Termination of ON-LINE Reader Operation.	3-90
3-147	Raising the Tape Head.	3-90
3-148	Depressing the START READ CLEAR Pushbutton	3-90
3-149	Depressing the READ CLEAR Pushbutton	3-90
3-150	Depressing the MASTER CLEAR Pushbutton	3-91
3-151	Tape Punch Operation, General.	3-91
3-152	Tape Punch Operation, Detailed	3-92
3-153	External Function Acknowledge Enable	3-92
3-154	External Function Word Conversion and Translation.	3-92
3-155	Set PUNCH F/F and Start Punch Motor.	3-92
3-156	Set PUNCH READY F/F.	3-92
3-157	Clear Output Register.	3-93
3-158	Generate Output Data Request	3-93
3-159	Set TAPE FEED F/F, Remove ODR, and Gate Data to Output Register	3-93
3-160	Gate Data to Punch	3-94
3-161	FEED HOLE Signal to Punch.	3-94
3-162	Clear TAPE FEED F/F.	3-94
3-163	Clear Output Register.	3-94
3-164	Automatic Termination of ON-LINE Punch Operation.	3-94
3-165	Manual Termination of ON-LINE Punch Operation.	3-95
3-166	Depressing the PUNCH CLEAR Pushbutton.	3-95
3-167	Depressing the MASTER CLEAR Pushbutton	3-95
3-168	Logic Description, Off-Line Mode	3-96
3-169	Off-Line Mode.	3-96
3-170	Control Circuits, General.	3-96
3-171	Control Circuits, Detailed	3-96
3-172	Prevent Data Transfer to Output Register	3-96
3-173	Disable Inputs, Interrupts, Requests, and Acknowledges	3-96

TABLE OF CONTENTS (Contd)

Chapter/Paragraph		Page
3-174	Off-Line Enables and Set OFF-LINE F/F.	3-96
3-175	OFF-LINE F/F Outputs	3-97
3-176	Tape Reader Operation, General	3-98
3-179	Tape Reader Operation, Detailed.	3-98
3-180	Light READ Indicator	3-98
3-181	Disable Keyboard Mode and Clear INTERRUPT F/F, KEYBOARD REQ ENABLE F/F, and KEYBOARD INPUT READY F/F.	3-98
3-182	Set START READ F/F	3-98
3-183	Start Reader Motor	3-103
3-184	Set READ READY F/F	3-103
3-185	Clear Input Register and Advance Tape.	3-103
3-187	Set PUNCH F/F and Start Punch Motor.	3-103
3-188	SET PUNCH READY F/F.	3-103
3-190	Clear Output Register.	3-104
3-191	Set PRINT F/F and Start Printer Motor.	3-104
3-192	Set PRINTER READY F/F.	3-104
3-193	Stop Tape and Gate Data to Input Register.	3-104
3-194	Set OFF-LINE READ F/F and/or OFF-LINE READ ONE F/F.	3-105
3-195	Simulate Output Acknowledge.	3-105
3-196	Set TAPE FEED F/F and Remove Clear from Output Register.	3-105
3-197	Gate Input Register to Output Register	3-105
3-198	Set ENABLE PRINT F/F, Initiate Serializer and CLEAR SERIALIZER RDY F/F	3-105
3-199	Gate Data to Punch and Clear TAPE FEED F/F	3-105
3-200	Feed Hole Signal to Punch.	3-106
3-201	Clear TAPE FEED F/F.	3-106
3-202	Basic Serializer Operations.	3-106
3-203	Generation of DATA to PRINTER Signals for Start, Bits 0 Through 6, Parity, and Stop.	3-106
3-204	Set SERIALIZER RDY F/F and Clear ENABLE PRINT F/F.	3-106
3-205	Clear Output Register.	3-106
3-206	Simulate Input Acknowledge	3-107
3-207	Clear OFF-LINE READ ONE F/F.	3-107
3-208	Termination of Reader Operations	3-107
3-209	Keyboard Operation, General.	3-108
3-211	Keyboard Operation, Detailed	3-108
3-212	Light KEYBOARD Indicator and Start Printer Motor.	3-108
3-213	Clear Output Register.	3-108
3-214	Set PUNCH F/F and Start Punch Motor.	3-108
3-215	Set PUNCH READY F/F.	3-108
3-216	Keyboard Coding.	3-108
3-217	Clear KEYBOARD DATA F/F and Initiate Serializer	3-108

TABLE-OF CONTENTS (Contd)

Chapter/Paragraph		Page
3-218	Enable Serializer.	3-111
3-219	Initiate Serializer and Clear SERIALIZER READY F/F.	3-111
3-220	Set KEYBOARD INPUT READY F/F and Remove Clear Input Register Signal.	3-111
3-221	Basic Serializer Operations.	3-111
3-222	Keyboard Gating and Serial Transfer of ASCII Code to Input Register	3-111
3-223	Serial Data Transmission to Printer.	3-111
3-224	DATA to PRINTER Signal Generation.	3-111
3-225	Set KEYBOARD DATA F/F and SERIALIZER READY F/F.	3-111
3-226	Set KEYBOARD REQ ENABLE F/F.	3-111
3-227	Set OFF-LINE READ ONE F/F and Simulate Output Acknowledge.	3-111
3-228	Set TAPE FEED F/F and Remove Clear from Output Register	3-111
3-229	Gate Input Register to Output Register	3-112
3-230	Gate Data to Punch and Clear TAPE FEED F/F	3-112
3-231	Clear Output Register.	3-112
3-232	Simulate Input Acknowledge	3-112
3-233	Clear KEYBOARD INPUT READY F/F, KEYBOARD REQ ENABLE F/F, and INTERRUPT F/F.	3-112
3-234	Clear OFF-LINE READ ONE F/F.	3-112
3-235	Clear Input Register	3-112
3-236	Repetitive Keyboard Operations	3-112
3-237	Termination of Keyboard Operations	3-112
3-238	Keyboard/Printer	3-112
3-239	Keyboard	3-112
3-240	Code Bar Mechanism and Signal Generator.	3-112
3-250	Local Carriage Return Mechanism.	3-117
3-251	Local Line Feed Mechanism.	3-117
3-252	Repeat Mechanism	3-117
3-253	Margin Indicator Mechanism	3-118
3-254	Control Key Mechanism.	3-118
3-255	Shift Key Mechanism.	3-118
3-256	Friction Feed Printing Unit.	3-119
3-270	Principles of Operation.	3-122
3-286	Main Shaft	3-125
3-290	One-Stop Clutches.	3-126
3-292	Three-Stop Clutches.	3-130
3-293	Selection.	3-130
3-297	Orientation.	3-134
3-298	Code Bar Mechanism	3-135
3-301	Code Bar Positioning	3-135
3-304	Arrangement of Code Bars	3-136
3-305	Print Box and Print Box Carriage	3-137
3-309	Shift Mechanism.	3-138

TABLE OF CONTENTS (Contd)

Chapter/Paragraph		Page
3-312	Print Box Positioning	3-139
3-319	Print Hammer and Printing Carriage	3-146
3-323	Print Suppression	3-148
3-327	Spacing Mechanism	3-148
3-330	Spacing Function	3-150
3-331	Spacing Suppression	3-150
3-334	Margin Indicator	3-150
3-335	Ribbon Feed Mechanism	3-150
3-339	Functions	3-153
3-344	Carriage Return Function	3-154
3-347	Line Feed Function	3-158
3-354	Stunt Box Contacts	3-160
3-358	Platen Mechanism	3-162
3-359	Synchronous Motor Unit	3-162
3-361	Tape Punch	3-163
3-362	Operation	3-163
3-369	Motor Unit (LMU-6)	3-167
3-373	Synchronization	3-168
3-376	Tape Perforation	3-169
3-380	Tape Feeding	3-170
3-383	Manual Feed Out	3-175
3-384	Tape Reel and Brake Mechanism	3-175
3-385	Low-Tape Mechanism	3-175
3-386	Timing	3-175
3-387	Mechanical	3-175
3-389	Electrical	3-176
3-390	Flywheel Orientation	3-178
3-391	Tape Reader	3-178
3-392	Power Supply	3-178
3-397	Tape Drive System	3-179
3-399	Control Circuitry	3-179
3-402	Pinch Roller and Brake Circuits	3-180
3-408	Tape Read System	3-182
3-411	Data Channel Section	3-183
3-415	Power Distribution	3-184
3-416	General	3-184
3-417	Power Control Circuit	3-184
3-418	AC Power Output	3-185
3-419	DC Power Output	3-185
3-422	Overtemperature Protection Circuits	3-188
4	Scheduled Maintenance	4-1
4-1	Introduction	4-1
4-4	Preventive Maintenance	4-1
4-6	Safety Precautions	4-1
4-8	Scheduled Maintenance Action Index	4-1
4-10	Tools, Materials, and Test Equipment	4-1
4-12	Preventive Maintenance Procedures	4-1

TABLE OF CONTENTS (Contd)

Chapter/Paragraph	Page
5	Troubleshooting. 5-1
5-1	Introduction 5-1
5-2	General Information. 5-1
5-3	Troubleshooting. 5-1
5-4	Trouble Isolation and Testing. 5-1
5-5	Troubleshooting Concept. 5-1
5-6	Troubleshooting Procedure. 5-1
5-7	Test Points. 5-1
5-8	Tape Reader. 5-2
5-9	Tape Punch 5-2
5-10	Maintenance Turn-On Procedure. 5-2
5-11	Console Turn-On Procedure. 5-2
5-13	Console Turnoff Procedure. 5-2
5-14	Relay, Switch, Lamp, and Protective Device Index. 5-2
5-15	Combination Tool 5-2
5-16	Functional Schematic Diagrams. 5-2
5-17	General. 5-2
5-18	Logic Sumbology. 5-43
5-19	Logic Design 5-43
5-20	Logic Symbols. 5-43
5-21	Diagrams 5-43
5-22	Functional Schematic Diagrams. 5-43
5-23	Electrical Schematic Diagrams. 5-43
6	Corrective Maintenance 6-1
6-1	Introduction 6-1
6-4	Adjustments and Alignment. 6-1
6-6	Keyboard Alignment 6-1
6-7	Keyboard Left and Right Margin Adjustment. 6-1
6-8	Keyboard Hammer Bearing Stud Adjustment. 6-3
6-9	Keyboard Hammer Stop Bracket Adjustment. 6-5
6-10	Keyboard Dashpot Adjustment. 6-7
6-11	Keyboard Carriage Adjustment 6-8
6-12	Keyboard Lower Draw Wire Rope Adjustment 6-9
6-13	Keyboard Print Box Alignment 6-10
6-14	Keyboard Rangefinder Knob Alignment. 6-12
6-15	Keyboard Rangefinder Mechanism Adjustment. 6-13
6-16	Keyboard Intermediate Gear Assembly Adjustment 6-14
6-17	Keyboard Signal Generator Gear Clearance Adjustment 6-16
6-18	Reader Adjustments 6-16
6-19	Photodiode Amplifier Adjustments 6-16
6-20	Neutral Density Filter Method. 6-17
6-21	Duty Cycle Method. 6-19
6-22	Reader Pinch Roller Alignment and Adjustment 6-22
6-23	Reader Drive Belt Tension Adjustment 6-24

TABLE OF CONTENTS (Contd)

Chapter/Paragraph		Page
6-24	Punch Adjustments	6-24
6-25	Punch Base Component Adjustments	6-25
6-26	Punch Magnetic Pickup Adjustment	6-26
6-27	Punch Pin, Punch Block Drag Links, Tape Guide, and Biasing Spring Adjustment.	6-27
6-28	Punch Code Hole Interval Adjustment.	6-33
6-29	Punch Stop Plate and Long Toggle Arm Spring Adjustment	6-36
6-30	Punch Armature Springs and Magnet Plate Adjustment	6-37
6-31	Punch Motor and Timing Belt Adjustments.	6-39
6-32	Repair	6-40
6-34	I/O Console Assemblies	6-41
6-35	Logic Chassis Removal and Replacement.	6-41
6-36	Circuit Card Removal and Replacement	6-42
6-37	Power Supply Assembly Removal and Replacement.	6-43
6-38	Reader-Perforator Drawer Removal and Replacement.	6-45
6-39	Fan Assemblies Removal and Replacement	6-45
6-40	Oscillator Horn Removal and Replacement.	6-46
6-41	I/O Console Filter Removal and Replacement	6-46
6-42	I/O Console Capacitors Removal and Replacement.	6-47
6-43	Keyboard/Printer Repair.	6-47
6-44	Keyboard/Printer Lower/Upper Cover Assembly Removal and Replacement.	6-48
6-45	Keyboard Lower Draw Wire Rope Removal and Replacement.	6-48
6-46	Keyboard Upper Draw Wire Rope Removal and Replacement.	6-50
6-47	Printer Paper Roll Removal and Replacement	6-54
6-48	Printer Ribbon Removal and Replacement	6-55
6-49	Keyboard Print Box Removal and Replacement	6-56
6-50	Keyboard Intermediate Gear Assembly Removal and Replacement.	6-59
6-51	Keyboard Carriage Assembly Removal and Replacement.	6-59
6-52	Keyboard Printing Unit Removal and Replacement.	6-61
6-53	Keyboard Platen and Pressure Roller Removal and Replacement.	6-62
6-54	Printer or Punch Motor Unit Removal and Replacement.	6-66
6-55	Electrical Service Unit Removal and Replacement.	6-67
6-56	Electrical Service Unit Circuit Card Removal and Replacement.	6-67
6-57	Electrical Service Unit Fuses Removal and Replacement.	6-67

TABLE OF CONTENTS (Contd)

Chapter/Paragraph		Page
6-58	Reader Assemblies Removal and Replacement. . . .	6-69
6-59	Reader Exciter Lamp, Capstan and Capstan Bearings, Removal and Replacement.	6-69
6-60	Reader Pinch Roller Solenoid Removal and Replacement.	6-71
6-61	Reader Capstan Drive Motor Assembly Removal and Replacement.	6-71
6-62	Reader Brake Coil Removal and Replacement. . . .	6-72
6-63	Tape Reader READY/LOAD Switch Removal and Replacement.	6-74
6-64	Tape Reader Drive Belt Removal and Replacement.	6-74
6-65	Tape Read Head Assembly Removal and Replacement.	6-75
6-66	Tape Guide Head Assembly	6-76
6-67	Punch Unit Removal and Replacement	6-76
6-68	Wire Wrap Technique.	6-77
6-70	Wire Wrap Removal.	6-77
6-71	Precautionary Guidelines	6-77
6-72	Wire Wrap Removal Procedures	6-77
6-73	Modified Wire Wrap	6-77
6-74	Precautionary Guidelines	6-77
6-75	Modified Wire Wrap Procedures.	6-78
6-76	Unacceptable Wire Wraps.	6-78
6-77	Wire Routing	6-78
6-78	Precautionary Guidelines	6-78
6-79	Wire Plane Layout.	6-78
6-80	Wire Routing Designator.	6-80
6-81	Wire Routing Procedures.	6-81
6-82	LHA-1 Class Ships Modifications.	6-82
7	Parts List	7-1
7-1	Introduction	7-1
7-3	List of Field Changes.	7-1
7-4	Printed Circuit Module Complement.	7-1
7-5	List of Major Units.	7-1
7-6	I/O Console Configurations	7-1
7-7	Parts List	7-1
7-9	Numerical Index.	7-3
7-11	List of Manufacturers.	7-3
8	Installation	8-1
8-1	Introduction	8-1
8-3	Installation Control Drawings.	8-1
8-4	Site Information	8-1
8-5	Outline and Dimensional Data	8-1
8-6	Unpacking and Handling	8-1
8-10	Mounting Procedures.	8-2

TABLE OF CONTENTS (Contd)

Chapter/Paragraph	Page
8-12	Cabling Requirements 8-2
8-14	Input Requirements 8-2
8-18	Cooling. 8-2
8-19	Grounding Requirements 8-2
8-23	Cabinet Ground 8-7
8-24	Intercabinet Ground. 8-7
8-26	Cable Assemblies and Connector Data. 8-9
8-27	Installation 8-9
8-28	Installation Procedures. 8-9
8-32	Installation Checkout. 8-9
8-33	Phase One, Installation Inspection and Preenergizing Procedures 8-9
8-34	Phase Two, Turn-On and Preliminary Tests 8-10
8-35	Installation Checkout Procedures 8-10
8-36	Power Supply 8-12
8-37	Temperature Sensing and Power Control Circuits 8-13
8-38	Indicators and Switches. 8-15
8-39	Phase Three, Installation-Verification Test. 8-16

LIST OF ILLUSTRATIONS

Figure		Page
1-1	I/O Console Physical Arrangement	1-3
1-2	I/O Console Functional Sections.	1-4
1-3	I/O Console to Computer Signal Interface	1-5
2-1	I/O Console Control Panel.	2-5
2-2	I/O Console Power Panel (Hood Assembly).	2-6
2-3	Keyboard/Printer, Controls and Indicator	2-7
2-4	Keyboard/Printer Keyboard Arrangement.	2-12
2-5	Punch Reader Drawer Extender	2-13
2-6	Tape Reel and Brake Assembly	2-14
2-7	Typical High-Speed Tape Punch Set.	2-15
2-8	Tape Orientation on Tape Reader.	2-16
2-9	Threading Tape Reader (Upper Cover Assembly Removed)	2-17
2-10	Loading and Unloading the Tape Rewinder.	2-18
3-1	I/O Console Functional Block Diagram	3-2
3-2	Keyboard Operation	3-4
3-3	Printer Operation.	3-5
3-4	Paper Tape Reader Operation.	3-6
3-5	Paper Tape Punch Operation	3-7
3-6	Block Diagram of Keyboard/Printer Operation.	3-8
3-7	Paper Tape Reader Block Diagram.	3-10
3-8	Paper Tape Reader Logic Diagram.	3-11
3-9	Paper Tape Stepping Control.	3-13
3-10	Binary Permutation Code.	3-14
3-11	Illustration of Circle Level Notation.	3-15
3-12	Basic AND Gates.	3-16
3-13	Low Input, High Output AND Gate.	3-17
3-14	Basic OR Gates	3-18
3-15	Low Input, High Output OR Gate	3-19
3-16	AND/OR Combination Gate.	3-20
3-17	Flip-Flop.	3-21
3-18	Flip-Flop Notation	3-22
3-19	Logic Gate Notation.	3-23
3-20	Inverter, Pulse Delay Card Type 250770	3-24
3-21	Flip-Flop, Card Type 7002000	3-25
3-22	Amplifier Driver, Card Type 7002013.	3-26
3-23	Flip-Flop, Card Type 7002020	3-27
3-24	Inverter, Card Type 7002030.	3-28
3-25	Inverter, Card Type 7002050.	3-29
3-26	Inverter, Card Type 7002060.	3-30
3-27	Inverter, Card Type 7002070.	3-31
3-28	Inverter-Input, Card Type 7002090.	3-32
3-29	Amplifier-Control Driver, Card Type 7002130.	3-33
3-30	Amplifier Driver, Card Type 7002141.	3-34

LIST OF ILLUSTRATIONS (Contd)

Figure		Page
3-31	Inverter, Card Type 7002220.	3-35
3-32	Amplifier, Differential, Card Type 7002321	3-36
3-33	Amplifier, Control Line, Card Type 7002332	3-37
3-34	Amplifier, Data Line, Card Type 7002342.	3-38
3-35	Amplifier Driver, Card Type 7002810.	3-39
3-36	Time Delay, Card Type 7002821.	3-40
3-37	Inverter Delay, Card Type 7002830.	3-41
3-38	Network Bias, Card Type 7002840.	3-42
3-39	Flip-Flop, Card Type 7002900	3-43
3-40	Inverter, Card Type 7002920.	3-44
3-41	Flip-Flop, Card Type 7002930	3-45
3-42	Amplifier Driver, Card Type 7002940.	3-46
3-43	Inverter, Card Type 7002990.	3-47
3-44	Capacitor Assembly, Card Type 7003180.	3-48
3-45	Amplifier Driver, Card Type 7003290.	3-49
3-46	Time Delay, 1.2 to 16.5 msec, Card Type 7003480.	3-50
3-47	Time Delay, 1.5 to 15 msec, Card Type 7003580.	3-51
3-48	Time Delay, Card Type 7105470.	3-52
3-49	On-Line Control Circuits, Operational Flow Sequence Diagram.	3-55
3-50	I/O Console Operational Sequence Flow Diagram (4 sheets) . . .	3-57
3-51	Serializer Timing Gates and Pulses	3-67
3-52	Example of Pulse Train Received from Keyboard when Key is Depressed	3-75
3-53	OFF-LINE Control Circuits, Operational Sequence Flow Diagram.	3-97
3-54	Off-Line Reader-Punch-Printer, Operational Flow Sequence Diagram (2 sheets)	3-99
3-55	Off-Line Keyboard/Printer-Punch, Operational Flow Sequence Diagrams	3-109
3-56	Code Bar and Code Lever Universal Bail Mechanism	3-113
3-57	Code Bar Bail Mechanism.	3-114
3-58	Code Bar Selection	3-115
3-59	Signal Generator Transfer Lever Mechanism and Contact Box Mechanism.	3-116
3-60	Wedglock Mechanism.	3-118
3-61	Local Carriage Return Mechanism.	3-119
3-62	Local Line Feed Mechanism.	3-120
3-63	Repeat Mechanism	3-121
3-64	Margin Indicator Mechanism	3-122
3-65	Friction Feed Printing Unit.	3-123
3-66	Eleven Unit Transmission Pattern	3-125
3-67	Eleven Unit Transmission Pattern Signaling Code.	3-126
3-68	Printing Unit Block Diagram.	3-127
3-69	Main Shaft	3-129
3-70	Three-Stop Clutch.	3-130
3-71	One-Stop Clutch (Disengaged)	3-131
3-72	One-Stop Clutch (Engaged).	3-132
3-73	Selector Clutch and Rangefinder.	3-133

LIST OF ILLUSTRATIONS (Contd)

Figure		Page
3-74	Selecting Mechanism and Transfer Mechanism	3-134
3-75	Code Bar Mechanism	3-136
3-76	Code Bar Shift Bar Positioning	3-137
3-77	Vertical Arrangement of Code Bars.	3-138
3-78	Print Box Pallet Arrangement	3-139
3-79	Draw Wire Rope Drums	3-140
3-80	Shift Mechanism.	3-141
3-81	Shift Mechanism Positioning.	3-142
3-82	Right Side Plate Mechanisms.	3-143
3-83	Clutch Trip Mechanisms	3-144
3-84	Horizontal Positioning Mechanisms.	3-145
3-85	Stop Slide Positioning	3-146
3-86	Print Hammer and Carriage.	3-147
3-87	Print Suppression Mechanism.	3-149
3-88	Spacing Mechanism.	3-151
3-89	Ribbon Feed and Reverse Mechanisms	3-152
3-90	Stunt Box (Function Linkage Unselected).	3-155
3-91	Typical Stunt Box (Bottom View).	3-156
3-92	Stunt Box (Rear View).	3-157
3-93	Reset Bail Mechanism	3-158
3-94	Function Bar Selection	3-159
3-95	Typical Function Linkage (Unselected).	3-160
3-96	Typical Function Linkage (Selected).	3-161
3-97	Stripper Blade Mechanism	3-162
3-98	Carriage Return Function Mechanism	3-163
3-99	Carriage Mechanism	3-164
3-100	Line Feed Mechanism.	3-165
3-101	Single and Double Line Feed Lever.	3-166
3-102	Typical Box Contact (Unselected)	3-167
3-103	Typical Box Contact (Selected)	3-168
3-104	Friction Feed Platen Mechanism	3-169
3-105	Schematic Diagram, Motor Unit (LMU-3).	3-170
3-106	Schematic Diagram of Punch Operation	3-171
3-107	Paper Tape Punch Timing Diagram.	3-173
3-108	Typical Series (Governed) Motor Unit	3-176
3-109	Schematic Diagram, Typical Series (Governed) Motor Unit (LMU-6).	3-177
3-110	Drive Mechanism.	3-178
3-111	Magnetic Pickup.	3-179
3-112	Perforating Mechanism.	3-180
3-113	Tape Feeding Mechanism	3-181
3-114	Punch Block Assembly	3-182
3-115	Tape Guide Unit.	3-183
3-116	Tape Feed-Out Lever and Armature	3-184
3-117	Tape Reel and Brake Assembly	3-185
3-118	Flywheel Orientation	3-186
3-119	Flywheel Orientation Chart for Punches with 60 Point Timing Scales.	3-187
3-120	Reader Stop Distance	3-189

LIST OF ILLUSTRATIONS (Contd)

Figure		Page
5-1	Circuit Symbols.	5-3
5-2	Printer and Punch Control 1, Functional Schematic.	5-5
5-3	Printer and Punch Control 2, Functional Schematic.	5-7
5-4	Keyboard and Reader Control, Functional Schematic.	5-9
5-5	Mode Selection 1, Functional Schematic	5-11
5-6	Mode Selection 2, Functional Schematic	5-13
5-7	I/O Converter Part 1, Functional Schematic	5-15
5-8	I/O Converter Part 2, Functional Schematic	5-17
5-9	Input Register Bits 00-03, Functional Schematic.	5-19
5-10	Input Register Bits 04-07, Functional Schematic.	5-21
5-11	Output Register Bits 00-03, Functional Schematic	5-23
5-12	Output Register Bits 04-07, Functional Schematic	5-25
5-13	Power Supply, Functional Schematic	5-27
5-14	Power Supply (Modified) Functional Schematic	5-29
5-15	Signal and Voltage Part 1, Distribution Diagram.	5-31
5-16	Signal and Voltage Part 2, Distribution Diagram.	5-33
5-17	AC Power, Distribution Diagram	5-35
5-18	DC Power, Distribution Diagram	5-37
5-19	Console/Computer Interface Cabling, Schematic Diagram.	5-39
5-20	Chassis Map.	5-41
5-21	Test Block Location.	5-43
5-22	Tape Reader Circuit Waveforms (3 sheets)	5-46
5-23	Paper Tape Reader Schematic Diagram.	5-49
5-24	Paper Tape Punch Schematic Diagram	5-51
5-25	I/O Console Power Panel.	5-53
5-26	Combination Tool	5-59
6-1	Left Margin Measurement (Top View)	6-3
6-2	Left Margin Adjustment (Front View).	6-4
6-3	Right Margin Adjustment.	6-5
6-4	Print Box Clutch Trip Lever.	6-6
6-5	Printing Hammer Bearing Stud Adjustment.	6-7
6-6	Print Hammer Stop Bracket Adjustment	6-8
6-7	Dashpot Adjustment (Front View).	6-9
6-8	Printing Carriage Position Adjustment (Top View)	6-10
6-9	Lower Draw Wire Rope Adjustment (Front View)	6-11
6-10	Print Box Alignment.	6-12
6-11	Rangefinder Knob Alignment	6-13
6-12	Intermediate Gear Assembly	6-15
6-13	Signal Generator Frame	6-17
6-14	Reader Panel (Front and Rear Views).	6-18
6-15	LAC Board Locations (2 sheets)	6-20
6-16	Pinch Roller/Capstan Alignment	6-23
6-17	Drive Belt Tension Adjustment.	6-25
6-18	Low Tape Contacts (View from Motor Side)	6-26
6-19	Low Tape Contacts Bracket (Motor Side)	6-27
6-20	Tape Reel Brake Spring	6-28
6-21	Low Tape Lever Spring.	6-29
6-22	Magnetic Pickup Adjustment	6-30

LIST OF ILLUSTRATIONS (Contd)

Figure		Page
6-23	Tape Punch Unit.	6-31
6-24	Punch Pin Adjustment	6-32
6-25	Drag Links Adjustment.	6-33
6-26	Punch Block Adjustment	6-34
6-27	Tape Guide Adjustment.	6-35
6-28	Tape Biasing Spring Adjustment	6-36
6-29	Tape Lid Spring Adjustment	6-37
6-30	Feed Ratchet Detent Arm Adjustment	6-38
6-31	Feed Pawl Spring Adjustment.	6-39
6-32	Wedge Block Adjustment	6-40
6-33	Stop Plate and Toggle Arm Springs Adjustment	6-41
6-34	Code and Feed Level Magnet Assembly.	6-42
6-35	Motor and Timing Belt Adjustment	6-43
6-36	Logic Chassis and Printed Card Location.	6-44
6-37	Carriage Return Mechanism (Front View)	6-49
6-38	Lower Draw Wire Rope Route (Front View).	6-49
6-39	Lower Draw Wire Rope Route (Bottom View)	6-50
6-40	Spring Drum Assembly (Front)	6-51
6-41	Printing Carriage and Print Box Clamps (Top View).	6-52
6-42	Upper Draw Wire Rope Routing (Front View).	6-53
6-43	Looped Upper Drawer Wire Rope.	6-54
6-44	Upper Draw Wire Rope Routing on Spring Drum (Bottom View).	6-55
6-45	Paper Routing (Left View).	6-56
6-46	Path of Printer Ribbon (Top View).	6-57
6-47	Printer Ribbon with Spool.	6-57
6-48	Keyboard Print Box	6-58
6-49	Printing Carriage (Top View)	6-60
6-50	Printing Carriage (Front View)	6-60
6-51	Mounting Printing Unit on Base (Top View).	6-62
6-52	Local Carriage Return Mechanism.	6-63
6-53	Left Platen Mechanism.	6-64
6-54	Friction Feed Platen Mechanism	6-65
6-55	Electrical Service Unit.	6-68
6-56	Pan Assembly	6-69
6-57	Exciter Lamp Holder Assembly	6-70
6-58	Capstan Bearing Preload Adjustment	6-72
6-59	MPC Edgeboard Connections.	6-73
6-60	Solenoid Radial Gap Adjustment	6-74
6-61	Brake Armature Positioning	6-75
6-62	Wire Wrap Procedure.	6-79
6-63	Acceptable Wire Wraps.	6-80
6-64	Wire Wrap Examples	6-81
6-65	Tape Guide for LHA-1 Class Ships	6-83
7-1	Input/Output Console	7-10
7-2	Input/Output Console Subassembly	7-13
7-3	Cabinet Hood Assembly (A1)	7-15
7-4	Logic Assembly (A2).	7-17
7-5	Digital-to-Digital Converter (A2A1) (2 sheets)	7-19

LIST OF ILLUSTRATIONS (Contd)

Figure		Page
7-6	Connector Assembly	7-23
7-7	Terminal Board (A2A1A3).	7-25
7-8	Control-Indicator (A2A2)	7-27
7-9	Paper Tape Reader-Perforator Assembly (A3)	7-29
7-10	Model 2500 Perforated Tape Reader (A3A1)	7-31
7-11	Front Panel Assembly	7-33
7-12	Lampholder Assembly.	7-36
7-13	Brake Assembly	7-38
7-14	Adjustable Guide Lens and Head Assembly.	7-40
7-15	Head Assembly.	7-42
7-16	Solenoid Mount Assembly.	7-44
7-17	Motor Option Assembly.	7-46
7-18	MPC Printed Circuit Board Assembly	7-48
7-19	LAC Printed Circuit Board Assembly	7-50
7-20	Economy Reader Assembly.	7-53
7-21	Paper Type Perforator.	7-56
7-22	Paper Tape Punch Unit (A3A2) (5 sheets).	7-58
7-23	Tape Punch Base (2 sheets)	7-69
7-24	Series Governed Motor.	7-74
7-25	Fan Assembly (A4).	7-78
7-26	Branched Wiring Harness (A5)	7-80
7-27	Power Supply (A6) (2 sheets)	7-82
7-28	Power Supply (A6PS1)	7-85
7-29	Teletypewriter (A7).	7-87
7-30	Upper and Lower Cover.	7-89
7-31	Print Unit	7-92
7-32	Typepallet Box	7-94
7-33	Carriage Assembly.	7-96
7-34	Right Side Linkage and Type Box Carriage Mechanism	7-98
7-35	Front Plate Mechanism, View 1.	7-101
7-36	Front Plate Mechanism, View 2.	7-104
7-37	Front Plate Mechanism, View 3.	7-108
7-38	Carriage Return and Spacing Drum Mechanism	7-110
7-39	Right Ribbon Feed Mechanism.	7-112
7-40	Left Ribbon Feed Mechanism	7-114
7-41	Platen and Line Feed Mechanism	7-117
7-42	Paper Spindle and Reset Bail Mechanism	7-119
7-43	Pressure Roller Mechanism.	7-122
7-44	Keyboard/Printer Base.	7-124
7-45	Intermediate Gear Mechanism.	7-126
7-46	Motor Assembly	7-128
7-47	Control-Indicator.	7-130
8-1	OA-7984(V)/UYK I/O Console Outline and Dimensions (2 sheets)	8-3
8-2	Quasi-Ground Plane System.	8-8
8-3	I/O Console Cable and Ground Connections	8-13
8-4	I/O Console Cabinet Thermostats.	8-16

LIST OF TABLES

Table		Page
1-1	I/O Console Configuration Options	1-2
1-2	Quick Reference Data	1-6
1-3	Equipment, Accessories, and Documents Supplied	1-8
1-4	Equipment and Publications Required but not Supplied	1-9
1-5	Factory and Field Changes.	1-11
2-1	Control Panel Switches and Indicators.	2-2
2-2	Power Panel Switches and Indicators.	2-3
2-3	Keyboard/Printer Controls and Indicator.	2-4
2-4	Keyboard Characters, Actions, and Data Codes	2-8
3-1	I/O Console Input/Output Functions	3-3
3-2	External Function Word Format.	3-53
3-3	Keyboard Characters, Actions, and Data Codes	3-77
3-4	Coefficient of Friction for Perforated Tape.	3-188
4-1	Scheduled Maintenance Action Index	4-2
4-2	Tools, Materials, and Test Equipment	4-2
5-1	I/O Console Power Supply Voltages.	5-44
5-2	Tape Reader Trouble Isolation Guide.	5-44
5-3	Tape Reader Resistance Measurements.	5-46
5-4	Relay Index.	5-54
5-5	Switch Index	5-54
5-6	Lamp Index	5-56
5-7	Protective Device Index.	5-58
6-1	Test Equipment and Special Tools	6-2
6-2	Number of Turns.	6-80
7-1	List of Field Changes.	7-4
7-2	Printed Circuit Module Complement.	7-6
7-3	Input/Output Console OA-7984(V)/UYK, List of Major Units	7-7
7-4	I/O Console Configurations	7-8
7-5	Parts List in Figure and Index Number Sequence	7-9
7-6	Parts List in Part Number Sequence	7-133
7-7	Parts List in Reference Designator Sequence.	7-149
7-8	List of Manufacturers.	7-153
8-1	Input/Output Cable Requirements.	8-7
8-2	Terminal Connector and Conductor Functions	8-10
8-3	Computer Input Cable	8-11
8-4	Summary List of Installation Material.	8-14
8-5	I/O Console Power Supply Voltages.	8-15
8-6	List of I/O Console POFA's Available	8-16

SAFETY SUMMARY

GENERAL SAFETY NOTICES.

The following general safety notices supplement the specific warnings and cautions appearing elsewhere in this manual. They are recommended precautions that must be understood and applied during operation and maintenance of the equipment covered herein. Should situations arise that are not covered in the general or specific precautions, the Commanding Officer or other authority will issue orders as deemed necessary to cover the situation.

DO NOT REPAIR OR ADJUST ALONE.

Under no circumstances should repair or adjustment of energized equipment be attempted alone. The immediate presence of someone capable of rendering aid is required. Before making adjustments, be sure to protect against grounding. If possible, adjustments should be made with one hand, with the other hand free and clear of equipment. Even when power has been removed from equipment circuits, dangerous potentials may still exist due to retention of charges by capacitors. Circuits must be grounded and all capacitors discharged prior to attempting repairs.

TEST EQUIPMENT.

Make certain test equipment is in good condition. If a test meter must be held, ground the case of the meter before starting measurement; do not touch live equipment or personnel working on live equipment while holding a test meter. Some types of measuring devices should not be grounded; these devices should not be held when taking measurements.

INTERLOCKS.

Interlocks are provided for safety of personnel and equipment and should be used only for the purpose intended. They should not be battle-shortened or otherwise modified except by authorized maintenance personnel. Do not depend solely upon interlocks for protection. Whenever possible, disconnect power at power distribution source.

WARNING

High-voltage high-capacitance components may contain voltages dangerous to life. Discharge all high-voltage capacitance components to electrical ground before working. (Page 6-47)

CAUTION

In this unit, the DC return is not tied to the chassis. Therefore, for DC waveform and voltage measurements, signal 0V (pink K of connector J2) must be used for ground reference. (Pages 6-19, 6-37)

CAUTION

Clearance between drive motor and electronics unit printed circuit board (see figure 6-14) must be a minimum of 0.015 inch to prevent shorting to motor. (Page 6-24)

Remove power from the logic circuitry before extending drawer to prevent possible damage to logic module cards. (Page 6-42)

Two people must perform steps 4 through 6 to avoid damage to the drawer and the assemblies therein. (Page 6-45)

Exercise care to avoid chipping the pulley. (Page 6-53)

When lifting printing unit, grasp center of tie rod (located in rear of unit) with one hand, and center of rail plate (located in lower front on unit) with other hand. (Page 6-61)

Detent bail is spring-loaded so care must be exercised when assembly screw is removed. (Page 6-62)

Disconnect power to selector magnet driver assembly before removing circuit card to avoid damaging transistors. (Page 6-67)

Care should be taken when replacing motor assembly to ensure no damage is done to printed circuit components of printed circuit board. (Page 6-72)

When nuts are removed (step 3 d.), washers will fall out. Note location of washers for reinstallation. (Page 6-76)

In the event that an overtemperature condition occurs after power is applied, immediately set LOGIC POWER switch to the OFF position. Correct the cause of the malfunction before attempting to resume normal operation. (Page 8-10)

When using a hot air gun to check operation of overtemperature sensors, use caution to prevent possible heat damage sensor and adjust components and wiring. (Page 8-13)

