



HP Cluster Configuration Support Matrix For Microsoft Windows Server 2003, EE x86/32-bit & HP StorageWorks MSA500 G2

Config	Supported Servers	Server Software	Host Bus Adapters (HBAs)	Multipath Software	Storage Information	Other
#1 Windows Server 2003, EE R2, x86/32-bit	Max supported nodes = 2 ProLiant: <ul style="list-style-type: none"> • DL360 G3, DL360 G4, DL360 G4p SCSI, DL360 G4p SATA, DL360 G4p SAS, DL360 G5 • DL365 • DL380 G3, DL380 G4, DL380 G4 SAS, DL380 G5 • DL385, DL385 SAS, DL385 G2 • DL560 • DL580 G2, DL580 G3, DL580 G3 SAS, DL580 G4 • DL585, DL585 SAS, DL585 G2 • DL740 • DL760 G2 • ML350 G3, ML350 G4, ML350 G4p, ML350 G4p SAS, ML350 G5 • ML370 G3, ML370 G4, ML370 G4 SAS, ML370 G5 • ML530 G2 • ML570 G2, ML570 G3, ML570 G3 SAS, ML570 G4 	SmartStart Ver: 7.70	Smart Array 642 Driver: 5.74.0.32 FW: 2.68 Smart Array 6i * Driver: 5.74.0.32 FW: 2.68 *Note: only used with the DL360 G4 and DL380 G4 servers.	Smart Array Multipath Software Ver: 2.0d	StorageWorks MSA500 G2 Storage Controller FW: 1.56 Storage EMU FW: 2.28 on 2-port 2.30 on 4-port Array Configuration Utility Ver: 7.60.18.0 or later	Product Page Supporting Documentation January 2007
#2 Windows Server 2003, EE R2	Max supported nodes = 2 ProLiant: <ul style="list-style-type: none"> • DL360 G3, DL360 G4, DL360 G4p SCSI, DL360 G4p SATA, DL360 G4p SAS, DL360 G5 • DL365 • DL380 G3, DL380 G4, DL380 G4 SAS, DL380 G5 • DL385, DL385 SAS, DL385 G2 • DL560 • DL580 G2, DL580 G3, DL580 G3 SAS, DL580 G4 • DL585, DL585 SAS, DL585 G2 • DL740 • DL760 G2 • ML350 G3, ML350 G4, ML350 G4p, ML350 G4p SAS, ML350 G5 • ML370 G3, ML370 G4, ML370 G4 SAS, ML370 G5 • ML530 G2 • ML570 G2, ML570 G3, ML570 G3 SAS, ML570 G4 	SmartStart Ver: 7.60	Smart Array 642 Driver: 5.74.0.32 FW: 2.68 Smart Array 6i * Driver: 5.74.0.32 FW: 2.68 *Note: only used with the DL360 G4 and DL380 G4 servers.	Smart Array Multipath Software Ver: 2.0c	StorageWorks MSA500 G2 Storage Controller FW: 1.56 Storage EMU FW: 2.28 on 2-port 2.30 on 4-port Array Configuration Utility Ver: 7.60.18.0 or later	Product Page Supporting Documentation November 2006

<p>#3</p> <p>Windows Server 2003, EE SP1</p>	<p>Max supported nodes = 2</p> <p>ProLiant:</p> <ul style="list-style-type: none"> DL360 G3, DL360 G4, DL360 G4p SCSI, DL360 G4p SATA, DL360 G4p SAS DL380 G3, DL380 G4, DL380 G4 SAS DL385, DL385 SAS DL560 DL580 G2, DL580 G3, DL580 G3 SAS DL585, DL585 SAS DL740 DL760 G2 ML350 G3, ML350 G4, ML350 G4p, ML350 G4p SAS ML370 G3, ML370 G4, ML370 G4 SAS ML530 G2 ML570 G2, ML570 G3, ML570 G3 SAS 	<p>SmartStart Ver: 7.4 utilized with PSP 7.40A</p>	<p>Smart Array 642 Driver: 5.68.0.32 FW: 2.58</p> <p>Smart Array 6j * Driver: 5.68.0.32 FW: 2.58</p> <p>*Note: only used with the DL360 G4 and DL380 G4 servers.</p>	<p>Smart Array Multipath Software Ver: 2.0b</p>	<p>StorageWorks MSA500 G2 Storage Controller FW: 1.52</p> <p>Storage EMU FW: 2.28 on 2-port 2.30 on 4-port</p> <p>Array Configuration Utility Ver: 7.15.19.0</p>	<p>Product Page Supporting Documentation</p> <p>December 2005</p>
<p>#4</p> <p>Windows Server 2003, EE</p>	<p>Max supported nodes = 2</p> <p>ProLiant:</p> <ul style="list-style-type: none"> DL360 G3, DL360 G4 DL380 G3, DL380 G4 DL560 DL580 G2 DL585 DL740 DL760 G2 ML350 G3, ML350 G4 ML370 G3, ML370 G4 ML530 G2 ML570 G2 	<p>SmartStart Ver: 7.1 utilized with PSP 7.10A</p>	<p>Smart Array 642 Driver: 5.62.0.32 FW: 2.26</p> <p>Smart Array 6j * Driver: 5.62.0.32 FW: 2.26</p> <p>*Note: only used with the DL360 G4 and DL380 G4 servers.</p>	<p>Smart Array Multipath Software Ver: 2.0b</p>	<p>StorageWorks MSA500 G2 Storage Controller FW: 1.40</p> <p>Storage EMU FW: 2.28 on 2-port 2.30 on 4-port</p> <p>Array Configuration Utility Ver: 7.15.19.0</p>	<p>Product Page Supporting Documentation</p> <p>September 2004</p>