

SYSTEM CONFIGURATION INFORMATION

Thank you for purchasing a GIMIX 6809 microcomputer system. The following pages consist of a collection of notes on the installation, setup, and use of GIMIX 6809 systems. First-time users should read through this information carefully before setting up the system. Users who are already familiar with GIMIX systems should look through the sheets marked "*", in the list below, indicating new or revised information. If, after reading this and the other appropriate sections of the manual, you have questions concerning the setup and use of this system, please call us.

We welcome suggestions for additions or corrections to this and other sections of the manual. If you have any suggestions, please submit them in writing to: GIMIX Inc., Attn. Mike Magnus, 1337 W. 37th. Place, Chicago IL, 60609.

TABLE OF CONTENTS
SYSTEM CONFIGURATION NOTES

Name	Description	Date/Revision
SYSCON	This page	12/02/82 A
UNPACK	Unpacking your GIMIX system	11/29/82 A*
SERCONN	Serial Interface Connections	11/29/82 A*
PIACENT	GIMIX Parallel to "CENTRONICS" printer	12/02/82 A*

***** IMPORTANT - PLEASE READ *****

UNPACKING YOUR GIMIX SYSTEM

To protect your GIMIX 6809 system during shipping, packing material has been placed INSIDE the system. YOU MUST REMOVE THE TOP COVER AND ALL OF THE PACKING MATERIAL BEFORE APPLYING POWER TO THE SYSTEM. Remove the packing carefully and be sure that all of the boards are fully seated on the motherboard connectors. Check carefully for small parts that may have been packed inside. In most systems the AC line cord and keys are packed inside the cabinet. Small parts, such as cables, may also be packed inside. You should also check the system carefully for any damage that may have occurred during shipping. If damage is apparent, contact GIMIX and the carrier immediately.

The system can be operated with the cover removed to facilitate initial setup and testing; however, we recommend that the cover be kept in place as much as possible during normal operation to insure proper cooling. (This is especially important with hard disk systems.)

We suggest that you retain the original box and packing material, in case it is ever necessary to ship the system.

***** IMPORTANT - PLEASE READ *****

CONFIGURATION INFORMATION FOR THE GIMIX TWO PORT SERIAL I/O BOARD

This notice outlines the recommended procedure for connecting serial peripherals (terminals , printers, etc.) to the GIMIX Two Port RS-232C serial interface board. Failure to follow the recommended procedure can result in random I/O errors caused by noise pickup on unused handshake lines (CTS and/or DCD). The errors are most noticeable on interrupt driven systems (OS-9 and UniFLEX) where noise can cause the generation of interrupts that cannot be identified by the operating system.

As shipped, the jumpers on the Two Port serial boards are normally configured as shown in figure "B" of the "JUMPER CONFIGURATIONS" drawing included with the board. The following chart shows the DB-25 connector pinouts for this configuration.


Signal	Pin#	Direction	
		Computer	Peripheral
RX	2	<-----<	
TX	3	>----->	
	4		----->
	5		----->
GND	7	<-----<	
RTS	8	>----->	
DCD	12	<-----<	
CTS	20	<-----<	

High-speed terminals normally require a simple three wire cable, without handshake, connecting pins 2,3, and 7 of the I/O board to the corresponding pins on the terminal. THE UNUSED HANDSHAKE INPUTS (DCD and CTS) MUST BE PROPERLY TERMINATED TO PREVENT NOISE PICKUP. It is especially important to terminate these inputs if a 25 conductor cable is used.

There are two recommended methods for terminating DCD and CTS. The first is to REMOVE (from JA-1 and/or JA-2) the jumpers that connect DCD and CTS to the I/O cable. These jumpers MUST BE REMOVED even if the corresponding pins on the I/O connector are unconnected since even the length of cable from the board to the back-panel connector is sufficient to pick up noise from the system. Pull-up resistors on the board force the inputs to the required active level for proper operation of the board. This method should be sufficient in most cases.

The second method connects the RTS output from the board to the DCD and CTS inputs. Using the output driver (RTS) to hold the handshake inputs at the proper level. Caution: This method will only work if the software initializes the RTS output of the ACIA to the active level. Operating systems supplied by GIMIX (FLEX, OS-9, and UniFLEX) initialize the ACIA properly. Software from other sources, that directly accesses the ACIA, should be checked for proper initialization. There are two ways to implement this method, depending on the type of cable used to connect the board and the peripheral. If a discrete-wired cable is used, jumpers can be installed in the connector at the computer end of the cable, to connect RTS, CTS, and DCD together. (In the case of the jumper configuration shown above, pins 8, 12, and 20 would be connected together) If a mass-terminated or ribbon type cable is used, the jumpers for RTS, DCD, and CTS can be removed from JA-1/JA-2 and wire-wrap techniques used to connect RTS, DCD, and CTS together at the jumper strips.

Printer interfaces normally require handshake to prevent the computer from outputting data faster than the printer can accept it. Software provided by GIMIX uses the CTS input to the serial board for printer handshaking. The CTS input must be connected to an output from the printer that is high (positive level) when the printer is ready to accept data and low (negative level) when it is not ready. The DCD input is not used in this application and should be terminated as described in the preceding section. If printer handshake is not required (if, for example, the baud rate will be set slow enough to prevent printer over-run) the CTS input should also be terminated as described above. Note: Some serial printers require that their handshake inputs (DSR/DCD) be placed in an active state before they will accept data. This can usually be accomplished by connecting an unused output from the printer (DTR) to its handshake inputs, at the printer end of the cable. See the example diagrams below and the printer documentation.



NOTE: The above diagrams assume that the 2-port serial board is jumpered as shown in figure "B" of the hardware documentation.

GIMIX PIA-30 to CENTRONICS TYPE PRINTER INTERFACE

GIMIX PIA BOARD
DB-25 CONNECTOR

"CENTRONICS"
36-PIN CONNECTOR

PIN	SIGNAL	PIN
1 >-----	DATA 0 -----	> 2
2 >-----	DATA 1 -----	> 3
3 >-----	DATA 2 -----	> 4
4 >-----	DATA 3 -----	> 5
5 >-----	DATA 4 -----	> 6
6 >-----	DATA 5 -----	> 7
7 >-----	DATA 6 -----	> 8
8 >-----	DATA 7 -----	> 9
9 <-----	ACKNOWLEDGE -----	< 10
10 >-----	STROBE -----	> 1
14 THROUGH 25	<----- SIGNAL GROUND ----->	19 THROUGH 28

NOTE: When using ribbon cable, alternate signal and ground lines for better isolation. When using standard multi-conductor cable, twisted-pairs are preferred, with each signal line paired with its associated ground. Cable length should be kept to a minimum, with 10 feet being the maximum recommended length. Shielded cable may be required if radio interference is a problem.